50 50

100

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception,
which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

50 50

100

HM11 POETABLE WIPELESS SPEAKER

Thanks for choosing our product. We hope you will enjoy music.

SECURITY GUIDANCE

BEFORE USING THE SPEAKER, PLEASE READ OUR SPECS CLEARLY AND KEEP IT FOR FUTURE REFERENCE

01. Stay away from heat, sharp items and direct sunlight.
02. Stay away from open fire.
03. Do not insert any metal objects, avoid short circuit.
04. Don't repair the product by yourself, please contact the authorized manufacturer to repair it.
05. Avoid rain, spray and other liquids.
06. If the product is overheated, damaged or falling into the liquid, stop using it.
07. Use the product according to local standards and regulations.

PACKAGING ACCESSORIES

01. HM11 SPEAKER ·····×1
02. MICRO-USB CHARGING CABLE·····×1
03. AUX AUDIO CABLE ·····×1
04. PRODUCT MANUAL·····×1

BUILT-IN BATTERY

01. Built-in rechargeable battery, it takes 2-3 hours to complete the charge and discharge cycle for the first time.
02. Don't continue to charge a fully when charged battery, as overcharging will shorten the battery life.
03. If it is unused , the fully-loaded battery may be slightly lost.
04. The speaker is placed in a place that is too hot or too cold, which will shorten the life of it.

CHARGING ADAPTATION

01. Please use a standard DC 5V=1A charger to charge.
02. Do not use other types of chargers, otherwise the product may be damaged.
03. Please refer to the status of the charging indicator to determine whether it is charging normally.
04. Please avoid using it while charging as much as possible.

CHARGING FUNCTION

01. Insert the MICRO-USB charging cable, and plug the other end of the charging cable into the DC5V=1A charger.
02. The LED charging indicator of the product is always on red, that is speaker is charging normally.
03. When the product is fully charged, the red LED indicator is off.

PAIRING CONNECTION

01. After the speaker is fully charged and in shutdown mode, press the power-on button for 3s to turn on. The speaker will sound a "Bluetooth Mode" prompt tone, that is will enter Bluetooth pairing mode.
02. The mobile phone or other device turns on the Bluetooth function and search for "HM11" to select and complete the pairing. After the pairing connection is successful, a "Bluetooth Connect" prompt tone is issued.
03. After the speaker is turned on, if the speaker has been paired to connect to the mobile phone or other device, the speaker will be automatically connected back within the connection range.
04. During the pairing process of "HM11", if you need to pass the password, you can enter the initial pass word "0000" to pair the connection normally.



OPERATION FUNCTION

① LED bluetooth indicator
② Previous song
③ Play/pause/turn on/off/hands-free
④ Next song
⑤ Volume knob
⑥ Volume scale
⑦ TF card jack
⑧ MICRO-USB charging port
⑨ LED charging indicator
⑩ USB jack
⑪ AUX jack
⑫ Passive diaphragm

01. Button ① When it power on will flashes and enters Bluetooth pairing mode.
02. When you playing music, press the button ② for the previous song.
03. Long press button ③ for 3s to turn on, the "Bluetooth Mode" prompt sound. When you playing music, click the button ③ to play / pause the music. When you have an incoming call, click the button ③ to make a hands-free call.
04. When you playing music, press the button ④ for the next song.
05. Rotate the button ⑤ to the left to decrease the volume, another right to increase the volume.
06. Button ⑥ shows the level of the volume.
07. Button ⑦ in the power-on state, when the TF card is inserted will be played automatically.
08. Button ⑧ can be charge to speaker through the MICRO-USB charging cable.
09. Button ⑨ can be know whether the charging state is normal.
10. Button ⑩ in the power on, when the USB flash drive is inserted will be played automatically.
11. Button ⑪ in the power on, insert the audio cable will automatically enter the AUX mode.
12. Button ⑫ mean make the bass more powerful.

TROUBLESHOOTING

Failure phenomenon	Possible reason	Solution
Unable to search for Bluetooth	The battery is out of power and shut down	Charging the speaker
Can't pair with Bluetooth	The speaker is already paired with another device The device does not enter pairing mode	Turn off other paired devices Search again then pair

SPECIFICATIONS

Bluetooth version	BT 5.0
Pairing/Model	HM11
Transmission frequency	60MHz-120MHz
Bluetooth receiving distance	Straight line barrier-free ≥10m
Trumpet	40mm 4Ω 3W
Battery	3.7V/400mAh
Charging voltage	DC 5V=600-800mA
Product weight	≥200g
Charging time	≥2H
Working hours	≥2H at the maximum volume, ≥3H at the minimum volume (Note: The type of mobile phone is different from the actual situation, and the time will be different)