Car Smart Converter

User Manual

Wireless CarPlay Adapter

READ ME FIRST

This adapter is designed for iPhone to use Apple CarPlay wirelessly on factory car multimedia system which has built-in wired Apple CarPlay. Please refer to the next page for how to check a carhas Apple CarPlay or not.
However, NOT every car with built-in CarPlay could fit this adapter. If there is any issue while using the adapter, please do not hesitate to contact us.

Function	Convert OEM Apple CarPlay to wireless Apple CarPlay
Compatibility	Car: with OEM Apple CarPlay
	iPhone: running iOS 10 or newer
Control	OEM touch screen, steering wheel, and joystick control
Input Power	USB 5V
Connectivity	Bluetooth

1. Contents

- Wireless adapter * 1
- USB cable (Type-C to A) * 1
- USB cable (Type-C to C) * 1
- User manual * 1

2. How to check a car has CarPlay or not

1. Plug an iPhone (running iOS 10 or newer) into the car USB ports with genuine factory lightning cable. If there is a notification pop up on iPhone like below, that your car has built-in Apple CarPlay.



2. If there is a CarPlay icon in the car stereo menu,that your car has built-in Apple CarPlay.



3. Contact your car dealer for help.

3. Connection diagram



NOTE ! The adapter should be plugged into the USB port that is for wired Apple CarPlay connecting if there are multi USB ports in your car.

4. How to use wireless CarPlay

Turn on your iPhone's Bluetooth, thenpair to the Bluetooth named "smartBox-xxxx"
Tap"Pair-Allow-Use CarPlay" on the iPhone pop up notifications
It will then connect to CarPlay wirelessly after a few seconds.

NOTE ! Before pairing to a new iPhone, pleasedisconnect the currently connected phone from Bluetooth.

5. How to update or report

Firmware updating is NOT recommended when every function works well.

- If your iPhone is connecting to the wireless CarPlay, enter 192.1681.101 on iPhone's browser, next tap "Update" if there is an update available.
- If your iPhone could not connect to the wireless CarPlay, please join the adapter's network [smartBox-xxxx] by manual and the password is 88888888.
- Next enter 192.168.1.101 on iPhone's browser, tap "Update".
- At the same web interface, you could also fill in the car make, model years, and issue details, next tap "Submit" to report the issue. After the success notification appears, take a screenshot and emailus. We will fix it as soon as possible.

NOTE ! The blue LED indicator will flash while updating. Wait for more 30s after the indicator is always on, then disconnect and reconnect the adapter from USB port to finish the whole update.

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception,which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference

By one or more of the following measures:

-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC' s RF Exposure guidelines, This equipment should be installed and operated with minimum 20cm distance between the radiator and your body: Use only the supplied antenna.