SELFIE STICK

User Manual

M08S

Compatible ☑ ios ☑ Android

How to use

1. **Power on:** press and hold the camera buttonfor 3 seconds.
2. **Bluetooth pairing:** the indicator flashes for 3 seconds to enter the pairing state, and the whiteindicator fashes. Use the mobile phone tosearch for "VIP" to match. After the pairing issuccessful, the white ndicator goes out.
3. **Photographing:** When the self timer isconnected with the mobile phone, briefly pressthe photo key, and the white light flashes.
4. **No pairing:** after power on, in the state of nopairing connection, it will automatically shutdown without operation for 5 minutes,
5. **Pairing:** after power on, when the self timer isconnected to the mobile phone, it will enter thesleep state without operation for 10 minutes, andit will automatically shut down after 10 minutes.
6. **sleep:** After entering the sleep state, press thephoto key to connect the mobile phone.

Key Function

Use after taking out the Selfie and connectingthe phone.

How to open a tripod

The bottom of the handle can be opened toopen the tripod.

Clip phone

Use one end of the phone to push the clip upwards.



Take out the Bluetooth

Diagram

Adjust various angles

Adjust various angles to shoot.

Extendable

Extended and stable pole can be extended

How to use fill light

Press and hold to turn on and off
The first long press to start,
light cold white : (50%),
Second press : (100% cold white)
Third press : (50% warm white)
Fourth press : (100% warm white)
Fifth press : (red light)
Sixth press : (green)
Seventh press : blue light,
Press 1~7 for the eighth time and flash : (0. 5 seconds),
Press the ninth stop in the current : Cycle in sequence.

Specification

Name	Selfie Stick Tripod
Model	M08S
Main Material	ABS+Aluminium alloy
Folded Length	230mm
Extended Length	820mm
Product Size	230x31mm
Product Weight	185g
Battery	Polymer battery

(Batteries must not be exposed to sunlight, fire or similarexcessive heat)

Remid

The selfie stick is compatiblewith Android 4.4 and above & iOS 5.0and above. (Androiddevice: If youchange your volumekey functionon the camera, be sure to changeit to the default value.Or take a pictureand let the selfie stick to work normally)

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user ' s authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.ct.

The device has been evaluated to meet general RF exposure requirement.