JP Wireless
Washable Easy Clean Keyboard & Mouse Set
User Manual



Installation

AAA battery is required for the keyboard and AA battery is required for the mouse (batteries are not included). Insert included USB dongle (inside the battery compartment in mouse) to any available USB port on computer. Switch to On position on the bottom of mouse. No software is needed.

Cleaning Guide

Quick disinfect a JP Keyboard by entering Clean Mode (Fn +) and switch mouse to OFF position. For deep cleaning, remove the silicone covers.

Quick Cleaning (Wiping)

- Use only non-abrasive soft materials, such as microfiber towels, soft bristle brushes, wipes, terry cloths, or bamboo cloths
- Approved Disinfectants and Cleaners: Hydrogen Peroxide, Ethanol and Isopropanol, HPV (Hydrogen Peroxide Vapor), and disinfecting wipes
- Always follow the approved concentrations and guidelines by your facility

Deep Cleaning

- Rinse and/or submerge the keyboard and mouse silicone covers into a soapy water solution or disinfect with a dishwasher

Don’ts

- Do not use abrasive materials for cleaning
- Sharp objects may puncture the silicone surface

Functions

1. Fn + Clean Mode
2. DPI Setting 800 / 1000 / 1200
3. Scroll Up
4. Scroll Down
5. ON / OFF Switch

www.jopaktech.com sales@jopaktech.com 951-569-3013

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Radiation Exposure Statement
The device has been evaluated to meet general RF exposure requirement in portable exposure condition without restriction.