43-inch Smart Tower Fan

USER MANUAL

Model: TF-T43S

CONTENS

01 IMPORTANT SAFETY INSTRUCTIONS 01
02 ASSEMBLING YOUR TOWER FAN 02
03 CONNECTING TO YOUR TOWER FAN 03
04 CONNECTING TO YOUR TOWER FAN 04
05 USING YOUR TOWER FAN 05
06 CLEANING AND MAINTENANCE 06
07 TROUBLESHOOTING 07
08 FCC STATEMENT 08
09 EXCEPTION CLAUSES 09
10 WARRANTY 10

SOMMAIRE

01 CONSIGNES DE SÉCURITÉ IMPORTANTES 01
02 ASSEMBLAGE DE VOTRE VENTILATEUR TOUR 02
03 CONNEXION À VOTRE VENTILATEUR TOUR 03
04 COMMENCEMENT DE VOTRE VENTILATEUR TOUR 04
05 UTILISATION DE VOTRE VENTILATEUR TOUR 05
06 NETTOYAGE ET ENTRETIEN 06
07 DÉPANNAGE 07
08 CLAUSES D'EXCEPTION 08
09 GARANTIE 09

01 IMPORTANT SAFETY INSTRUCTIONS

EN-1

Read all instructions before using the appliance. Save these instructions.

Do not use outdoors. Do not use under a bathtub, shower or swimming pool. Do not touch the appliance with wet hands or while barefoot.

Only use the appliance for its intended purpose. Do not use the appliance for any other purpose than described in this manual. Improper use may cause injury or damage to the appliance.

General Safety

1. Children shall not play with the appliance. Cleaning and maintenance shall not be carried out by children without supervision.
2. Use the appliance on a stable flat surface. Keep away from heat and flammable materials. Do not block the air vents on the front and back of the appliance.
3. The appliance can be used by children aged eleven years and upwards and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a way that they understand the hazards involved.

Operation Safety

1. Check the voltage printed on the unit to be sure it matches your mains voltage.
2. Do not immerse in water and avoid other liquids.
3. Do not use the appliance if the power cord is damaged.
4. Do not insert your fingers and foreign objects into the grille while in operation.
5. Do not cover the air inlet and outlet. Do not bring obstacles (for example the qualified accessories).

Electricity Safety

1. Make sure that the voltage (your electricity supply) is the same as that indicated on the rating plate.
2. Always unplug the appliance by removing the appliance cassette for a long period of time, when moving it, before cleaning it, or if it develops a fault.
3. Do not operate any fan with a damaged cord or plug. Discard them or return to an authorized service facility for examination or repair.

As for our non-stick cutter assembly, the non-stick cutter and mirror cups, cutters, or similar coverings, do not come in contact. Remove all appliances, storage bags and wrap. Check carefully and remove all foreign substances.

Remove all packaging materials, such as tape, stickers, etc. and wipe the tower fan with a soft cloth or sponge. Do not use any cleaning agents or abrasive cleaners.

Do not place the tower fan on a surface that is flammable or heat sensitive. Keep at least 30 cm of clearance on all sides of the tower fan. Do not place the tower fan on a surface that is unstable or uneven.

Do not place the tower fan in a location where it may be knocked over or where children can reach it.

Do not place the tower fan in a location where it may be exposed to direct sunlight or other heat sources.

Do not block the air inlet and outlet of the tower fan. Keep at least 30 cm of clearance on all sides of the tower fan.

Do not place the tower fan in a location where it may be exposed to rain or moisture.

Do not place the tower fan in a location where it may be exposed to dust or other contaminants.

Do not place the tower fan in a location where it may be exposed to chemical fumes or vapors.

Do not place the tower fan in a location where it may be exposed to vibration.

Do not place the tower fan in a location where it may be exposed to electromagnetic interference.

Do not place the tower fan in a location where it may be exposed to high humidity or condensation.

Do not place the tower fan in a location where it may be exposed to high temperatures.

Do not place the tower fan in a location where it may be exposed to low temperatures.

Do not place the tower fan in a location where it may be exposed to high altitude.

Do not place the tower fan in a location where it may be exposed to low altitude.

For Household Use Only Read And Save These Instructions

Device Overview	Specifications
Power Supply	AC100-240V~ 50/60Hz
Power Consumption	45W
Product Size	43.1*18.5*108.5cm
Net Weight	4.5kg
Gross Weight	5.5kg
Battery Type	CR2032

Please refer to Device Overview for more details on product specifications.

Please keep this manual for future reference.

02 ASSEMBLING YOUR TOWER FAN

Assembly Instructions

After unpacking the appliance for the first time, remove the wrapping and place the parts by following the steps below.



FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC’s RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.