Condition	Mode	Frequency (MHz)	Antenna	Measured Frequency (MHz)	Frequency Error (Hz)	Deviation (ppm)	Limit (ppm)	Verdict
NVNT	n40	5190	Ant2	5189.96	-40000	-7.71	25	Pass
NVNT	n40	5230	Ant2	5229.96	-40000	-7.65	25	Pass
NVNT	ac20	5180	Ant2	5180	0	0	25	Pass
NVNT	ac20	5200	Ant2	5200	0	0	25	Pass
NVNT	ac20	5240	Ant2	5239.98	-20000	-3.82	25	Pass
NVNT	ac40	5190	Ant2	5190	0	0	25	Pass
NVNT	ac40	5230	Ant2	5229.96	-40000	-7.65	25	Pass
NVNT	ac80	5210	Ant2	5209.92	-80000	-15.36	25	Pass

Test Graphs

Freq. Stability NVNT n40 5190MHz Ant2



Freq. Stability NVNT n40 5230MHz Ant2



Freq. Stability NVNT ac20 5180MHz Ant2



Freq. Stability NVNT ac20 5200MHz Ant2



Freq. Stability NVNT ac20 5240MHz Ant2



Freq. Stability NVNT ac40 5190MHz Ant2



Freq. Stability NVNT ac40 5230MHz Ant2



Freq. Stability NVNT ac80 5210MHz Ant2



D.6 Duty Cycle

Condition	Mode	Frequency (MHz)	Antenna	Duty Cycle (%)	Correction Factor (dB)	1/T (kHz)
NVNT	a	5180	Ant1	94.56	0.24	0.91
NVNT	a	5200	Ant1	94.56	0.24	0.91
NVNT	a	5240	Ant1	94.56	0.24	0.91
NVNT	n20	5180	Ant1	93.67	0.28	1.07
NVNT	n20	5200	Ant1	93.77	0.28	1.07
NVNT	n20	5240	Ant1	93.67	0.28	1.07
NVNT	n40	5190	Ant1	97.23	0.12	0.46
NVNT	n40	5230	Ant1	97.23	0.12	0.46
NVNT	ac20	5180	Ant1	93.72	0.28	1.06
NVNT	ac20	5200	Ant1	93.82	0.28	1.06
NVNT	ac20	5240	Ant1	93.72	0.28	1.06
NVNT	ac40	5190	Ant1	97.19	0.12	0.46
NVNT	ac40	5230	Ant1	97.24	0.12	0.46
NVNT	ac80	5210	Ant1	94.32	0.25	0.97

Test Graphs

Duty Cycle NVNT a 5180MHz Ant1



Duty Cycle NVNT a 5200MHz Ant1



Duty Cycle NVNT a 5240MHz Ant1



Duty Cycle NVNT n20 5180MHz Ant1



Duty Cycle NVNT n20 5200MHz Ant1



Duty Cycle NVNT n20 5240MHz Ant1



Duty Cycle NVNT n40 5190MHz Ant1



Duty Cycle NVNT n40 5230MHz Ant1



Duty Cycle NVNT ac20 5180MHz Ant1



Duty Cycle NVNT ac20 5200MHz Ant1



Duty Cycle NVNT ac20 5240MHz Ant1



Duty Cycle NVNT ac40 5190MHz Ant1



Duty Cycle NVNT ac40 5230MHz Ant1



Duty Cycle NVNT ac80 5210MHz Ant1



Condition	Mode	Frequency (MHz)	Antenna	Duty Cycle (%)	Correction Factor (dB)	1/T (kHz)
NVNT	a	5180	Ant2	94.65	0.24	0.91
NVNT	a	5200	Ant2	94.56	0.24	0.91
NVNT	a	5240	Ant2	94.56	0.24	0.91
NVNT	n20	5180	Ant2	93.77	0.28	1.07
NVNT	n20	5200	Ant2	93.67	0.28	1.07
NVNT	n20	5240	Ant2	93.77	0.28	1.07
NVNT	n40	5190	Ant2	90.3	0.44	1.73
NVNT	n40	5230	Ant2	90.14	0.45	1.74
NVNT	ac20	5180	Ant2	93.82	0.28	1.06
NVNT	ac20	5200	Ant2	93.72	0.28	1.06
NVNT	ac20	5240	Ant2	93.72	0.28	1.06
NVNT	ac40	5190	Ant2	90.2	0.45	1.72
NVNT	ac40	5230	Ant2	90.36	0.44	1.72
NVNT	ac80	5210	Ant2	86.79	0.62	2.42

Test Graphs

Duty Cycle NVNT a 5180MHz Ant2



Duty Cycle NVNT a 5200MHz Ant2



Duty Cycle NVNT a 5240MHz Ant2



Duty Cycle NVNT n20 5180MHz Ant2



Duty Cycle NVNT n20 5200MHz Ant2



Duty Cycle NVNT n20 5240MHz Ant2



Duty Cycle NVNT n40 5190MHz Ant2



Duty Cycle NVNT n40 5230MHz Ant2



Duty Cycle NVNT ac20 5180MHz Ant2



Duty Cycle NVNT ac20 5200MHz Ant2



Duty Cycle NVNT ac20 5240MHz Ant2



Duty Cycle NVNT ac40 5190MHz Ant2



Duty Cycle NVNT ac40 5230MHz Ant2



Duty Cycle NVNT ac80 5210MHz Ant2