Duty Cycle NVNT ac20 5260MHz Ant0



Duty Cycle NVNT ac20 5300MHz Ant0



Duty Cycle NVNT ac20 5320MHz Ant0



Duty Cycle NVNT ac40 5270MHz Ant0



Duty Cycle NVNT ac40 5310MHz Ant0



Duty Cycle NVNT ac80 5290MHz Ant0



Duty Cycle NVNT ac160 5250MHz Ant0



Duty Cycle NVNT ax20 5260MHz Ant0



Duty Cycle NVNT ax20 5300MHz Ant0



Duty Cycle NVNT ax20 5320MHz Ant0



Duty Cycle NVNT ax40 5270MHz Ant0



Duty Cycle NVNT ax40 5310MHz Ant0



Duty Cycle NVNT ax80 5290MHz Ant0



Duty Cycle NVNT ax160 5250MHz Ant0



Condition	Mode	Frequency (MHz)	Antenna	Duty Cycle (%)	Correction Factor (dB)	1/T (kHz)
NVNT	a	5260	Ant1	94.65	0.24	0.91
NVNT	a	5300	Ant1	94.56	0.24	0.91
NVNT	a	5320	Ant1	94.56	0.24	0.91
NVNT	n20	5260	Ant1	97.29	0.12	0.44
NVNT	n20	5300	Ant1	97.29	0.12	0.44
NVNT	n20	5320	Ant1	97.29	0.12	0.44
NVNT	n40	5270	Ant1	97.23	0.12	0.46
NVNT	n40	5310	Ant1	97.23	0.12	0.46
NVNT	ac20	5260	Ant1	97.34	0.12	0.44
NVNT	ac20	5300	Ant1	97.34	0.12	0.44
NVNT	ac20	5320	Ant1	97.34	0.12	0.44
NVNT	ac40	5270	Ant1	97.19	0.12	0.46
NVNT	ac40	5310	Ant1	97.24	0.12	0.46
NVNT	ac80	5290	Ant1	94.32	0.25	0.97
NVNT	ac160	5250	Ant1	90.94	0.41	1.95
NVNT	ax20	5260	Ant1	97.34	0.12	0.44
NVNT	ax20	5300	Ant1	97.3	0.12	0.44
NVNT	ax20	5320	Ant1	97.3	0.12	0.44
NVNT	ax40	5270	Ant1	97.19	0.12	0.46
NVNT	ax40	5310	Ant1	97.19	0.12	0.46
NVNT	ax80	5290	Ant1	94.32	0.25	0.97
NVNT	ax160	5250	Ant1	89.18	0.5	2.43

Test Graphs

Duty Cycle NVNT a 5260MHz Ant1



Duty Cycle NVNT a 5300MHz Ant1



Duty Cycle NVNT a 5320MHz Ant1



Duty Cycle NVNT n20 5260MHz Ant1



Duty Cycle NVNT n20 5300MHz Ant1



Duty Cycle NVNT n20 5320MHz Ant1



Duty Cycle NVNT n40 5270MHz Ant1



Duty Cycle NVNT n40 5310MHz Ant1



Duty Cycle NVNT ac20 5260MHz Ant1



Duty Cycle NVNT ac20 5300MHz Ant1



Duty Cycle NVNT ac20 5320MHz Ant1



Duty Cycle NVNT ac40 5270MHz Ant1



Duty Cycle NVNT ac40 5310MHz Ant1



Duty Cycle NVNT ac80 5290MHz Ant1



Duty Cycle NVNT ac160 5250MHz Ant1



Duty Cycle NVNT ax20 5260MHz Ant1



Duty Cycle NVNT ax20 5300MHz Ant1



Duty Cycle NVNT ax20 5320MHz Ant1



Duty Cycle NVNT ax40 5270MHz Ant1



Duty Cycle NVNT ax40 5310MHz Ant1



Duty Cycle NVNT ax80 5290MHz Ant1



Duty Cycle NVNT ax160 5250MHz Ant1



Condition	Mode	Frequency (MHz)	Antenna	Duty Cycle (%)	Correction Factor (dB)	1/T (kHz)
NVNT	a	5260	Ant2	94.65	0.24	0.91
NVNT	a	5300	Ant2	94.56	0.24	0.91
NVNT	a	5320	Ant2	94.65	0.24	0.91
NVNT	n20	5260	Ant2	97.29	0.12	0.44
NVNT	n20	5300	Ant2	97.29	0.12	0.44
NVNT	n20	5320	Ant2	97.33	0.12	0.44
NVNT	n40	5270	Ant2	97.18	0.12	0.46
NVNT	n40	5310	Ant2	97.23	0.12	0.46
NVNT	ac20	5260	Ant2	97.34	0.12	0.44
NVNT	ac20	5300	Ant2	97.3	0.12	0.44
NVNT	ac20	5320	Ant2	97.3	0.12	0.44
NVNT	ac40	5270	Ant2	97.19	0.12	0.46
NVNT	ac40	5310	Ant2	97.19	0.12	0.46
NVNT	ac80	5290	Ant2	94.32	0.25	0.97
NVNT	ac160	5250	Ant2	91.1	0.4	1.95
NVNT	ax20	5260	Ant2	97.34	0.12	0.44
NVNT	ax20	5300	Ant2	97.34	0.12	0.44
NVNT	ax20	5320	Ant2	97.3	0.12	0.44
NVNT	ax40	5270	Ant2	97.24	0.12	0.46
NVNT	ax40	5310	Ant2	97.19	0.12	0.46
NVNT	ax80	5290	Ant2	94.32	0.25	0.97
NVNT	ax160	5250	Ant2	89.18	0.5	2.43

Test Graphs

Duty Cycle NVNT a 5260MHz Ant2



Duty Cycle NVNT a 5300MHz Ant2



Duty Cycle NVNT a 5320MHz Ant2



Duty Cycle NVNT n20 5260MHz Ant2



Duty Cycle NVNT n20 5300MHz Ant2



Duty Cycle NVNT n20 5320MHz Ant2



Duty Cycle NVNT n40 5270MHz Ant2



Duty Cycle NVNT n40 5310MHz Ant2



Duty Cycle NVNT ac20 5260MHz Ant2



Duty Cycle NVNT ac20 5300MHz Ant2



Duty Cycle NVNT ac20 5320MHz Ant2



Duty Cycle NVNT ac40 5270MHz Ant2



Duty Cycle NVNT ac40 5310MHz Ant2



Duty Cycle NVNT ac80 5290MHz Ant2



Duty Cycle NVNT ac160 5250MHz Ant2



Duty Cycle NVNT ax160 5250MHz Ant2



Duty Cycle NVNT ax20 5260MHz Ant2



Duty Cycle NVNT ax20 5300MHz Ant2



Duty Cycle NVNT ax20 5320MHz Ant2



Duty Cycle NVNT ax40 5270MHz Ant2



Duty Cycle NVNT ax40 5310MHz Ant2



Duty Cycle NVNT ax80 5290MHz Ant2



Duty Cycle NVNT ax160 5250MHz Ant2