QI-540

Wireless Charger With Speaker

USER MANUAL







① Bluetooth/Sleeping Machine Mode button

② Timer setting button

③ Power on/off, Pause Button

④ Previous track or volume down button

⑤ Next track or volume up button

⑥ Wireless Charger indicator

⑦ Timer Indicator including 15/30/60 Minutes

⑧ Charging & Mode Led indicator

⑨ Wireless Charging Area

⑩ Type C Power input Slot

BASICAL FEATURES

Battery: 500MAH

Input: 5V/500MA

Charging time: 1H

Working time: 3-6H

Speaker

Bluetooth: V5.3

Speaker: 40MM,3W

Sleeping Machine

Six Sleeping Sounds: Stream,Brahms Lullaby,Sea Wave,Silent Night, Fetal,White Noise

Three Timer Modes: 15/30/60MINS

Wireless Charging

Input: 9V/2A(QC 3.0 required)

Output: 15W(Max)

HOW TO USE

SLEEPING MACHINE

Long Press the power button “ ” two seconds to turn on the device, then start playing the first default therapy song-stream automatically, the “ ” Led light has no display; there are 6 optional Sleeping therapy sounds including sea waves ,crackling fire, white noise,lullaby song, rain & thunder,brook;

Press once “ ” or “ ” to choose the best sound you like, or long press “ ” or “ ” to get Volume down or up,
Short press the button “ ” to pause the playing song;
Sleeping sounds timer function as below:
Short Press once the Button “ ” icon for 15MIN countdown;
Short Press twice the Button “ ” icon for 30MIN countdown;
Short Press three times the Button “ ” icon for 60MIN countdown;

BLUETOOTH SPEAKER

Short press once the Mode button “ M ” to switch to Bluetooth mode from Sleeping machine mode, Start pairing automatically once Bluetooth On, Follow the operating instruction of your Bluetooth device(phone, pad etc) and allow it to search Bluetooth state, after a few seconds your mobile will discover the Bluetooth speaker under “**SM06**” ,Select this and your device will confirm this pairing. You can start play music through the speaker.

Short press the button “ ” to pause the Bluetooth Playing;

Press once “ ” or “ ” to change the tracks, or long press “ ” or “ ” to get Volume down or up,

the blue led indicator will get fast flicker while waiting for pairing;
the blue led indicator will get constant when paired;
the blue led indicator will get slow flicker while playing music;

WIRELESS CHARGER

Put the smart phone to Wireless charging area, meet the phone's suitable area for wireless charger , then start charging automatically, the white led indicator on right side will start breathing once the wireless charging working.
Make sure your phone with wireless charging function such as IPHONE 8 or upper version; if your phone is without wireless charging function, please insert a wireless charging adaptor to your phone for wireless charging;

The output is 15W max, and compatible with 10W/7.5W/5W;
While you use the wireless charger, you must use a correct adaptor.

BUILT-IN BATTERY

Battery capacity is 500MAH, Please charge this device by the Type-C charging cable provided. It will last 1-2H for full charge;

LOW battery: if the power voltage is lower than 3.2V, the device will alarm each 2 minutes- "Low battery, please charge" total three times and then power off automatically to protect the battery, Please Charge the unit using the Type-C charging cable provided.
The red charging indicator will be constant while charging,and then turns off Once it is fully charged;

NOTICE

Do not let children play the product.
Do not hit or beat the product.
Do not use in very humid and high temperature environments
Do not throw the product into fire.
Do not block speaker's net above the body
Please send to repair when the product is broken. Do not disassemble it by yourself.
It's not covered under warranty when the product has metal of rust, surface spelling and other natural oxidation.

BATTERY REMOVAL/DISPOSAL

Your product contains batteries which cannot be disposed with normal household waste. Doing so may harm the environment. Please inform yourself about the local rules on separate collection of batteries because correct disposal helps to prevent negative consequences for the environmental and human health. Should your product develop a fault and your battery needs replacing PLEASE DO NOT REMOVE THE BATTERY!

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

For wireless charger

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.