COMPACT BLUETOOTH SPEAKER



Charging Status Indicator

Red light on — Being Charged
White light on — Fully Charged
Red light flashes — Low Battery

Power On

Press and hold the button for 2 seconds.

Make sure the speaker is fully charged before first use.

Power Off

Press and hold the button for 3 seconds.

Connecting devices

1. Turn on Bluetooth on your mobile device.

2. Turn on the speaker, find "OSKULL03" in the list of pairable devices, and click to connect the speaker.

3. Once the device is connected, the indicator light on the speaker will turn off automatically.

Music Control

Play / Pause
Click the button once

Volume up
Click the + button once

Volume down
Click the − button once

Previous track
Press the − button for 1 second

Next track
Press the + button for 1 second

Call management

Answer / Hang up
Click the button once

Reject Call
Press the button for 1 second

Voice Assistant

Click the button twice

Pairing Troubleshooting

Pairing Failed

1. Turn the speaker off and then back on.

The speaker will automatically enter pairing mode and wait for a connection. If the above solution does not work, follow the instructions below to reset the pairing history.

2. Remove the speaker from your paired list.

When the speaker is turned on and not connected to any device, press the multi-function button three times in succession to clear the pairing record, and then wait for the speaker to connect to the mobile device.

Can't Pair with Mobile Device

After the speaker is turned on, it will automatically pair with the last connected device. If it is not paired, you need to connect manually.

NOTE: If disconnected or pairing time exceeds 3 minutes, the speaker will automatically power off.

Device status indication

Low Battery Warning
-The speaker plays a low battery warning prompt.
-Red light flashes.

Low Power Shutdown
-The speaker plays a power off prompt.
-Red and blue lights flash alternately

Charging status

-Red light on — The speaker is charging
-White light on — The speaker is fully charged
-White light off — Disconnected from charging

Note:
1. Make sure the speaker is fully charged before first use.
2. It is recommended to fully charge before use to maintain the health of the battery
3. If not used for a long time, please charge it at least once every 45 days.

Product Specifications

Model:OSKULLCBS01
FCC ID:2BMB4-OSKULLCBS01

Bluetooth Version : V5.4
Waterproof Level : IP67
Rated Voltage / Current: 5V / 1A
Rated Power : 300mW
Frequency Response : 20Hz - 20kHz
Battery : 3.7V / 560 mAh

Supported Profiles :
A2DP1.4 / AVCTV1.4 / AVDTP1.3 / AVRCP1.6.2
HFP 1.8 / SPP 1.2 / RFCOMM1.2 / PNP1.3/ HID1.1.1
SDP CORE5.4 / 12CAP CORE5.4

Audio Codec : AAC / SBC
Driver Unit Impedance / Power : 2Ω / 2W
Mic Sensitivity : -42dB ± 1dB
Transmission Distance : 10 meters
Working Time : 14 hours (@80% Volume)
Standby Time : About 400 days
Charging Time : About 2 hours
Product Weight : 62g

OSKULL

OSKULL.COM

BLUE WHALE BRAND MANAGEMENT CO., LTD.
DESIGNED BY OSKULL

蓝牙音箱

使用说明书

充电时指示

红色灯亮 — 正在充电
白色灯亮 — 电已充满
红色灯闪烁 — 低电量警告

开机

按住 按钮持续2秒

第一次使用前请将音箱电量充满

关机

按住 按钮持续3秒

连接设备

1. 请将要连接设备的蓝牙功能打开。

2. 确保音箱在开机状态，在可配对设备列表中找到“OSKULL03”，然后点击连接。

3. 连接成功后，音箱上的指示灯会自动熄灭。

音乐控制

播放 / 暂停
轻按 按钮一次

音量提高
轻按 + 按钮一次

音量降低
轻按 − 按钮一次

上一首歌曲
按住 − 按钮维持1秒

下一首歌曲
按住 + 按钮维持1秒

来电管理

接听 / 挂断
轻按 按钮一次

拒绝来电
按住 按钮维持1秒

语音助手

轻按 按钮两次

配对故障排除

配对失败

1. 先关闭音箱再重新打开

此时音箱将自动进入配对模式并等待连接。
如果仍然不起作用，请按照第二项说明将音箱从配对列表中删除。

2. 将音箱从配对列表中删除

当音箱处于开机状态且未连接任何设备时，连续按三次多功能键清除配对记录，然后等待音箱连接到移动设备。

无法与移动设备配对

音箱开机后会自动与上次连接的设备配对。
若未配对则需要手动连接。

注意：如果断开连接或配对时间超过 3 分钟，音箱将自动关闭。

设备状态提示

低电量警告
-音箱将播放低电量语音提示。
-红色指示灯闪烁。

极低电量关机
-音箱将播放极低电量关机语音提示。
-红色蓝色指示灯交替闪烁。

充电状态
-红色指示灯亮 — 音箱正在充电中
-白色指示灯亮 — 音箱已经充满电
-白色指示灯灭 — 音箱断开充电

注意：
1. 第一次使用前请将音箱电量充满。
2. 请定期次使用前都将电量充满，以保持电池的健康状态。
3. 如长期不使用，每45天请至少充一次电。

产品规格

型号:OSKULLCBS01
FCC ID:2BMB4-OSKULLCBS01

蓝牙版本 : V5.4
防水等级 : IP67
额定电压/电流: 5V / 1A
额定功率 : 300mW
频率响应: 20Hz - 20kHz
电池 : 3.7V / 560 mAh

支持协议 :
A2DP1.4 / AVCTV1.4 / AVDTP1.3 / AVRCP1.6.2
HFP 1.8 / SPP 1.2 / RFCOMM1.2 / PNP1.3/ HID1.1.1
SDP CORE5.4 / 12CAP CORE5.4

音频编解码器 : AAC / SBC
驱动单元阻抗/功率 : 2Ω / 2W
麦克风灵敏度 : -42dB ± 1dB
有效连接距离 : 10 米
工作时间 : 14 hours (@80% 音量)
待机时间 : 约 400 天
充电时间 : 约 2 小时
产品重量 : 62g

OSKULL

OSKULL.COM

BLUE WHALE BRAND MANAGEMENT CO., LTD.
DESIGNED BY OSKULL

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.
Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.
This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.