Smart Blacklight Clock Camera

Email: serviceus@wesecuu.net

This manual is suitable for various types of cameras.

(The appearance may be different due to different batches. The details are subject to the receipt. This manual is only for the installation instructions of this series of equipment)

clock camera

Key Function Description

1. power button

Long press the power button to turn the device on/off. Note: Time display and camera are turned on/off together.

2. Time button

- Long press Time button to enter setup mode
- Press "+" or "-" to switch between 12 hour or 24-hour system.
- Press the Time button again
  → Hours blink (Press the "+" or "-" button to adjust the hour.) (Note that if there is no PM icon on the left side of the screen, it is morning time by default, and if there is a PM icon on the screen, it is afternoon time)
- Press Time button once more
  → Minutes blink (Press the "+" or "-" button to adjust the minute.)
- Short-press the time button again to save the setting.

3. Alarm button

- Short-press the Alarm button : It will show current alarm time.
- Press again: Turn alarm ON
  (Note: the clock icon will light up in the lower left corner of the screen).
- Press a third time: Turn alarm OFF.
- Press the Time button to exit setup,or Waiting for 5 seconds will automatically end the setting.

- Long press the alarm button to turn on the alarm directly and enter the alarm time setting
  → Hours blink; Press the "+" or "-" button to adjust the hour. (Note:If there is no PM icon on the left side of the screen, it is morning time by default, and if there is a PM icon on the screen, it is afternoon time)
- Short-press Alarm button → Minutes blink: Press the "+" or "-" button to adjust the minutes.
- Short-press Alarm button again → the minutes will flash, allowing you to adjust the snooze time. Press the "+" or "-" button to adjust the minutes (you can set it to 5-60 minutes).
- Short-press Alarm button saves settings and exits, or Waiting for 15 seconds will automatically end the setting.

4. snooze mode

Press "+" or "-" → Activates snooze mode (Alarm icon blinks ⏾ left side of screen)
➤Short-press Alarm button → Stops alarm sound immediately.

5. "+" button

In normal mode, press the "+" button to adjust the brightness of the time display light.
Low brightness →High brightness →Display OFF (Repeated press cycle through all three states)

6. Night Light button

Short-press the Night Light button to switch brightness levels: Low → High → Night Light OFF (Repeated taps rotate through all three states)

Battery Specifications
Input: 5V/2A charger
Capacity: 5200mAh
Charging Time:
➤ Approximately 10 hours (0% → 100%)
Usage Time:
➤ ~12 hours when fully charged
(With night light OFF + display at low brightness)

When device operates while charging:
➤ Charges battery simultaneously
➤ Charging indicator blinks during charging
➤ Indicator stays solid at 100% charge

Battery Level Indicators:
➤ 30% (0%-30% remaining)
➤ 60% (31%-60% remaining)
➤ 100% (61%-100% remaining)

Important Notes:

Power Source Transition

When disconnecting the power adapter during normal operation:
➤ Device automatically switches to battery power within 1 second
➤ System will reboot during this transition

Battery Management

If device shuts down due to depleted battery:
➤ Recharge within 30 days using power adapter (Preserves long-term battery health)

APP Download and Installation

Users can search"Wesecuu" on APP store or Google Play, or scan the QR code below to install the APP.

Note: For iOS system, it requires iOS 9.0 version or above.For Android,Android 5.1 or above.

*"Before adding a camera, please make sure that the Bluetooth function of the mobile phone has been turned on, and do not turn off the Bluetooth during the adding process.If a prompt box pops up during the adding process to enable Bluetooth or Bluetooth authorization please follow the steps in the prompt to enable it;

If you are prompted to open certain permissions, (such as location, message notifications, etc.) during APP installation, click Allow (agree)

Log in the App
Clickon"Registra" the app
begininterface. Sign up and follow theinscreen instructions to complete the

Wesecuu

Q1: Why is the pairing network unsuccessful?

1. Please make sure that the distance among the camera, the router and the mobile phone should be close enough when configuring the network.
2. Please make sure that the WIFI signal connected to the mobile phone 2.4G Wifi and 5G WiFi are both ok.
3. Please check whether the WIFI name and password are correct.
4. Please long press the reset button for 5 seconds and try again after restoring the camera to the factory settings.

Q2: Why is there no playback?

1. Make sure that the TF card has been inserted into the camera and try to turn on/off the camera.
2. Enter the camera settings menu to check the storage status "in good condition" (if the status is «Abnormal click to "Format the memory card").

Q3: Why is the camera offline?

1. It may caused by router WIFI signal interference or network reasons. Power off and restart the optical modem, router or camera.
2. The camera maybe too far away from the WIFI router, try to get the camera next to the WFI router.
3. Whether the WIFI password has been changed, try to reset the camera and try pairing again.

Q4: Why my phone does not have an alarm push function or two way audio?

1. Check your mobile phone permission settings, and make sure that enable the notification permission of "Wesecuu" App.
2. Open your phone's Settings > Apps and Notifications select Apps and Notification Management respectively, find the "Wesecuu" app, and turn on all permissions.

1. Thanks for your purchase and support, we appreciate all your valuable feedback.
2. If you have any questions about our products, please feel free to contact us.

Email: serviceus@wesecuu.net

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment of fand on, the user is encouraged to try to correct the interference by one or.

More of the following measures:

Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver .
Connect the equipment into an outlet on a circuit different from thatto which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

Important: Change or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority tooperate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) this device must accept any interference received, including interference that may cause undesired operation.

Connection Video

https://m.hihiesuns/video/tiktok/84.3.5/aed0KC9gk.k1