W&P

Portable Dual Connector Power Bank
User Manual

G50WP

● Technical Parameters

Product Name:	Portable Dual Connector Power Bank
Model:	G50WP
Apple Watch Charger Wireless Output:	2.5W Max
USB-C Port Input:	5V⎓2A, 9V⎓2A, 12V⎓1.5A(18W Max)
Foldable USB-C Connector Input:	5V⎓2A, 9V⎓2A, 12V⎓1.5A(18W Max)
Foldable USB-C Connector Output:	5V⎓2.4A, 9V⎓2.22A, 12V⎓1.67A(20W Max)
Foldable Lightning Connector Output:	5V⎓2.4A, 9V⎓2.22A, 12V⎓1.67A(20W Max)
Lithium Battery::	18Wh (3.6V/5,000mAh)
Rated Capacity:	2,630mAh (5V⎓2A)
Energy Conversion Rate:	65%
Total Output:	5V⎓3A (Max)
Item Weight:	130g (4.58oz)
Dimension:	80mm*45mm*33.6mm (3.15"x1.77"x1.32")

● Product Introduction:



● Charging Instructions

USB-C Connector:
Compatible with Phone, Tablet and etc. with USB-C Port.

Watch Magnetic Charger:
Compatibe with Apple Watch.

Lightning Connector:
Compatible with iPhone and iPad with Lightning Port.



● Folding Stand Use Method

Folding Stand Use Method:

Unfold The Stand According Your Need To Adjust The Angle

● LED Indicator & Button Description

LED INDICATOR SHOWS THE STATUS	● ● ● ●	100%-75% Power
	● ● ● ○	75%- 50% Power
	● ● ○ ○	50%-25% Power
	● ○ ○ ○	25%-1% Power

FUNCTION OF THE BUTTON	Once Clap	Turn On/Check Power
	Twice Clap	Turn Off

● How to keep it?

○ Use it everyday-Just need to recharge it when you need.
○ Won't use for a long time-Pls keep 50% power remains in it.
○ Pls recharge it every 3 monthes if you don't use it for a long while.
○ Pls use it safely. and don't give it to your kids.

● Attention

○ Charge the product itself before using it to charge other products.
○ Do not place or use the product in very hot or humid environment; do not place or use it in direct sunlight (ambient temperature for use: charging 0°C ~ 45°C; discharging -10°C ~ 60°C; ambient temperature for storage -20°C ~ 60°C).
○ Do not throw this product into fire or water, so as to avoid possible fire and explosion.
○ Please keep the product out of the reach of children.
○ Do not use it when nobody is around.
○ Do not dismantle or assemble the product yourself; the product does not have any part that needs users to dismantle, assemble or maintain by themselves.

● Attention

○ Do not shake it, tap it or hit it.

○ Do not use it if any liquid leaks out of the product. If the liquid goes into your eyes, do not rub your eyes, but quickly flush your eyes with running water. If necessary, go to see a doctor.

○ It is normal that the product gets hot under proper operations.

○ Please use with care when using or finishing using the product.

○ Original transmission cables and connectors are required for all operations. Use of non-original products may lead to severe or deadly injuries or monetary loss.

○ Do not use paper or other objects to cover or shield the product, which may affect heat dissipation and cooling.

○ Check the voltage before using the product, so as to avoid unnecessary damage to the product caused by improper use under inaccurate voltage or power.

○ Please charge and discharge the product once every three months if it is not used for a long time. This can ensure the life cycle of the product

○ Once discharged, please recharge the product fully so as to prepare for later use, for example, for charging digital products.

○ Unplug the power cable when product is not in use, so as to avoid injury or property loss.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and

(2)This device must accept any interference received, including interference that may cause undesired operation.