多功能智能眼镜
使用说明书

开、关机

1. 开机：长按电源键5秒，红蓝交替闪烁（提示音：开机）即开机
2. 关机：长按电源键5秒，红灯亮1秒灭（提示音：关机）即关机
3. 自动关机：开机后不连接手机或手机断开将自动关机

配对连接

1. 开机进入配对模式，LED指示灯持续闪烁，与蓝牙设备连接
2. 手机配对：如配对成功，指示灯熄灭（提示音：蓝牙已连接）

按键操作说明

1. 开机后：按4次电源键中英文切换（未连接蓝牙状态下使用）
2. 通话模式：（已连接蓝牙状态下使用）
(1) 按1次开机键挂断电话
(2) 按4次开机键唤醒语音助手，单击开机键关闭
(3) 左右两边往前滑动接听电话
(4) 按5次开机键回拨电话
3. 音乐模式：（已连接蓝牙状态下使用）
(1)双击开机键暂停音乐/播放音乐
(2)左边向前滑动播放下一曲
(3)左边向后滑动播放上一曲
4. 音量调节：
(1)右边向前滑动：音量+
(2)右边向后滑动：音量 -
5. 音乐与打电话切换：
先暂停音乐（双击），4击开机键，根据语音提示操作
6. 音乐与导航切换：
先暂停音乐（双击），4击开机键，根据语音提示操作
7. 拍照功能：
开启相机状态下双击开机键，有些手机不兼容该功能

充电

充电中，LED 指示灯红灯长亮。充电完成，LED指示灯红灯自动熄灭。

低电报警

语音提示【3分钟语音播报2次，只报2次就关机】，红灯长亮1秒，LED 指示灯灭。

•声明

首先对您使用本公司的产品表示感谢!在使用之前请先详细阅读此说明书，正确使用此产品。为了更好的服务本用户手册的内容可能变更。因为产品的性能和功能而发生的变更将不得另行通知。

•产品简介

本产品是具有立体声音响功能的蓝牙眼镜，操作简便，美观实用，便于携带。采用蓝牙芯片，兼容主流品牌手机和平板电脑等蓝牙设备,达到CD级高品质音质，持久续航，左右双喇叭,开放式定向发音,无障碍接收外界声音,不影响获取周围环境信息，安全、智能、健康、便捷。

•包装清单

智能眼镜、智能眼镜充电线、使用说明书、眼镜清洁布

•产品使用提示

1. 使用本产品前请仔细阅读说明书，并保留本说明书。
2. 首次使用，请先将本产品充满电。
3. 如果产品长期(超过两周)不充电,使用前请对其充电。

•警告

1. 请勿以任何理由拆除或维修改装本产品，否则可能会导致起火，电子击穿甚至彻底损坏本产品。
2. 请勿将设备置于温度过低或过高(0°C以下或45°C以上)环境下。
3. 请勿将产品接触腐蚀性液体。
4. 不能将眼镜放在阳光下长时间曝晒，否则容易变形、老化、折断。
5. 请勿将充电线碰吸端靠近金属物体，以防磁吸金属物体后引起的短路危险。

•重要安全信息

1. 在使用本产品前，请先阅读所有安全信息以确保正确和安全使用.
2. 使用未经原制造商认可的电源，充电器或电池，可能引发火灾，爆炸或其他危险
3. 请使用本制造商认可且与此型号设备配套的配件。
4. 请在温度0°C~35°C范围内使用本产品，当环境温度过高或过低时，可能会引发设备故障。
5. 本设备使用不可拆卸的内置电池，请勿 自行更换电池，以免损坏电池或设备，电池只能由授权服务中心更换.
6. 如充电完毕，请断开充电器与本设备的连接，并从电源插座上拔掉充电器。连续充电时间请勿超过12小时。
7. 请保持设备干燥。
8. 若设备或其他任何部件不能正常工作，请勿自行维修产品。
9. 连接其他设备时，请参考使用说明书的连接方法，不要随意连接不配套的设备。

⚠ 为避免听力受损，请勿长时间使用高音量。
⚠ 请遵循相关法律法规，不要在以下环境使用。

· 如加油站，油库，化学仓库附近等存储有易燃易爆物或化学品的环境，严禁使用设备。
· 请勿在医院手术室、急诊室、深切治疗部等场所使用此设备；为避免干扰医疗仪器工作，使用此设备时请远离心脏起搏器、助听器、植入耳蜗等医用设备，请保持此设备和起搏器之间超过15厘米的距离。
若要在个人医疗设备附近使用此设备请咨询医师和设备制造商。
· 请遵守有关驾车时使用此设备的所有安全警告和规定。
· 雷雨天气时，为避免雷击事故，请勿在室外使用
· 请勿在浴室等高湿度的地方对产品进行充电,否则会导致触电,人身伤害，起火和充电器损坏。
· 请遵守在任何环境里明确禁止使用的相关法律规定。

•产品参数

镜架材质：PC1414/TR90/五金
镜片材质：PC/TAC
镜片规格：透明渐变、墨镜等
蓝牙协议：5.4
充电时间：2H
使用时间：5H
待机时间：180H(蓝牙连接状态)
电池容量：100mAh
声道：双喇叭、立体声
充电电压和电流：DC5V/1A最大充电电流达160mAh

温馨提示:

充电时间：1-2小时。
长期不使用时，每2个月对电池至少充电一次

产品保修凭证

产品保修期内出现非人为损坏的性能故障可以享受下列三包服务:

· 自收货之日起7日内，产品出现非人为损坏的性能故障，用户可选择退回货款或者更换同型号同规格的产品。
· 自收货之日起15日内，产品出现非人为损坏的性能故障，用户可选择更换同型号同规格的产品。
· 自收货之日起一年内，产品出现非人为损坏的性能故障，用户可寄商家维修。

以下情况不在“三包”服务范围之内:

· 未经授权的维修、误用、碰撞、跌毁、盗用、进液、事故、改动或撕毁、涂改产品标签、封象。
· 超过“三包”服务有效期的。
· 因火灾、水灾、雷击等不可抗力造成的损坏。
· 因人为原因导致的产品性能故障。
· 未按说明书要求使用而造成损坏的。

保修卡

尊敬的用户，本保修卡是您将来申请保修的凭证，请您配合销售商填写并妥善保管备用。

用户信息	用户姓名	
	联系电话	
	通讯地址	
	电子邮箱	
	邮政编码	
产品信息	产品名称	
	产品型号	
	产品条码	
销售商信息	名　称	
	地　址	
	联系电话	
	邮政编码	
	销售日期	
	发票号码	
备注		

Multifunctional Smart Glasses Instruction Manual

Turn on and off

1. Power on: Press and hold the power button for 5 seconds. When the red and blue lights alternately (prompt tone: Power on), the power is turned on
2. Power off: Press and hold the power button for 5 seconds. The red light will light up for 1 second and then go off (prompt tone: Power off), indicating the power off
3. Automatic shutdown: The device will automatically shut down if it is not connected to the phone after startup or the phone is disconnected

Pairing connection

1. When the device is turned on and enters the pairing mode, the LED indicator light keeps flashing, and it is connected to the Bluetooth device
2. Mobile phone pairing: If the pairing is successful, the indicator light will go out (prompt tone: Bluetooth connected).

Key operation instructions

1. After startup: Press the power button four times to switch between Chinese and English (when not connected to Bluetooth).
2. Call mode: (Used when Bluetooth is connected)
(1) Press the power button once to hang up the phone
(2) Press the power button four times to wake up the voice assistant, and click the power button to turn it off
(3) Swipe forward on both sides to answer the phone
(4) Press the power button five times to call back
3. Music Mode: (Used when connected via Bluetooth)
(1) Double-click the power button to pause or play the music
(2) Slide forward on the left to play the next song
(3) Slide the left side backward to play the previous song
4. Volume adjustment:
(1) Swipe forward on the right: Volume +
(2) Slide the right side backward: Volume -
5. Switching between music and phone calls:
First, pause the music (double-click), press the power button four times, and follow the voice prompts to operate
6. Switching between music and navigation:
First, pause the music (double-click), press the power button four times, and follow the voice prompts to operate
7. Camera function:
Double-click the power button when the camera is on. Some mobile phones are not compatible with this function

Charging

During charging, the red LED indicator light remains on all the time. When charging is completed, the red LED indicator light will automatically go off.

Low electricity alarm

Voice prompt [Voice broadcast twice within 3 minutes, only twice before shutdown], the red light remains on for 1 second, and the LED indicator light goes off.

• Statement

First of all, we would like to express our gratitude for your use of our company's products! Please read this manual carefully before use and use this product correctly. The content of this user manual may be changed in order to provide better service. Changes due to the performance and functions of the product will not be notified separately.

• Product Introduction

This product is a Bluetooth glasses with stereo sound function. It is easy to operate, beautiful and practical, and convenient to carry. It adopts a Bluetooth chip and is compatible with mainstream brand mobile phones, tablets and other Bluetooth devices, achieving CD-level high-quality sound quality, long battery life, and dual speakers on the left and right. Open directional pronunciation, unobstructed reception of external sounds, no impact on obtaining information about the surrounding environment, safe, intelligent, healthy and convenient.

• Packaging list

Smart glasses, smart glasses charging cables, user manuals, glasses cleaning cloths

• Product Usage Tips

1. Please read the instruction manual carefully before using this product and keep it.
2. For the first use, please fully charge this product.
3. If the product is not charged for a long time (more than two weeks), please charge it before use.

• Warning

1. Do not dismantle or modify this product for any reason, otherwise it may cause fire, electronic breakdown or even complete damage to the product.
2. Do not place the device in an environment with temperatures that are too low or too high (below 0°C or above 45°C).
3. Do not let the product come into contact with corrosive liquids.
4. Do not expose glasses to the sun for a long time, otherwise they are prone to deformation, aging and breaking.
5. Do not place the magnetic end of the charging cable close to metal objects to prevent the risk of short circuit caused by magnetic attraction of metal objects.

• Important security information

1. Before using this product, please read all the safety information first to ensure correct and safe use.
2. Using power supplies, chargers or batteries that have not been approved by the original manufacturer may cause fire, explosion or other dangers
3. Please use the accessories approved by this manufacturer and compatible with this model of equipment.
4. Please use this product within the temperature range of 0°C to 35° C. When the ambient temperature is too high or too low, it may cause equipment failure.
5. This device uses a non-removable built-in battery. Please do not replace the battery by yourself to avoid damaging the battery or the device. The battery can only be replaced by an authorized service center.
6. If the charging is complete, please disconnect the charger from this deviceConnect and unplug the charger from the power socket. When charging continuously,Please do not exceed 12 hours.
7. Please keep the equipment dry.
8. If the equipment or any other components do not work properly, please do notSelf-repair products.
9. When connecting other devices, please refer to the connection instructions in the user manualMethod: Do not connect incompatible devices at will.

⚠ To avoid hearing damage, do not use high volume for a long time.
⚠ Please abide by relevant laws and regulations and do not use in the following environments.

· It can be stored near gas stations, oil depots, chemical warehouses, etcThe use of equipment is strictly prohibited in an environment with flammable, explosive substances or chemicals.
· Please do not be in the operating room, emergency room, intensive care unit, etc. of the hospitalThe place uses this equipment; To avoid interfering with the operation of medical instruments,When using this device, please keep away from pacemakers, hearing AIDS and implantsWhen inserting medical devices such as cochlear implants, please keep these devices and pacemakersA distance of more than 15 centimeters between them.If you need to use this device near your personal medical equipment, please consult a doctorTeachers and equipment manufacturers.
· Please abide by all safety warnings regarding the use of this device while drivingNotice and regulations.
· During thunderstorm weather, to avoid lightning strike accidents, do not use outdoors
· Do not charge the product in high-humidity places such as bathrooms, otherwise it may cause electric shock, personal injury, fire and damage to the charger.
· Please abide by the relevant legal regulations that explicitly prohibit its use in any environment.

• Product parameters

Frame material: PC1414/TR90/ hardware
Lens material: PC/TAC
Lens specifications: Transparent gradient, sunglasses, etc
Bluetooth Protocol: 5.4
Charging time: 2 hours
Usage time: 5 hours
Standby time: 180 hours (Bluetooth connection status)
Battery capacity: 100mAh
Channel: Dual speakers, stereo
Charging voltage and current: DC5V/1A, with a maximum charging current of 160mAh

Warm reminder:

Charging time: 1-2 hours.
When not in use for a long time, charge the battery at least once every two months

Product warranty certificate

The following three guarantees service can be enjoyed for performance faults that occur during the product warranty period due to non-human damage:

· Within 7 days from the date of receipt, if the product has performance faults that are not caused by human factors, the user can choose to refund the payment or replace it with a product of the same model and specification.
· Within 15 days from the date of receipt, if the product has a performance failure that is not caused by human factors, the user may choose to replace it with a product of the same model and specification.
· Within one year from the date of receipt, if the product has performance faults that are not caused by human factors, the user can send it to the merchant for repair.

The following situations are not covered by the "three guarantees" service:

· Unauthorized repair, misuse, collision, negligence, abuse, liquid ingress, accident, alteration or tearing, defacement of product labels and seals.
· Beyond the validity period of the "three guarantees" service.
· Damage caused by force majeure such as fire, flood and lightning strike.
· Product performance failures caused by human factors.
· Damage caused by failure to use in accordance with the instructions.

Warranty card

Dear user, this warranty card serves as your proof for future warranty applications. Please cooperate with the seller to fill it out and keep it properly for future use.

User name	
Tel No.	
Address	
Email	
Post code	
Product name	
Model No.	
Barcode	
Reseller name	
Reseller address	
Reseller tel.	
Postcode	
Purchasing date	
Invoice no.	
Remark	

FCC Warning
15.19 Labeling requirements.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

15.21 Information to user.
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

15.105 Information to the user.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on , the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

FCC RF Radiation Exposure Statement:
1.This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
2. This equipment complies with RF radiation exposure limits set forth for an uncontrolled environment.
This equipment should be installed and operated with minimum distance 5mm between the radiator and your body.