E30智能眼镜英文说明书　　单页尺寸：65mm×145mm　　展开尺寸：260mm×145mm

CHASESUN

SMART GLASSES

User Manual

Power On / Power Off



Power on: Press and hold the power button for 3 seconds. A voice prompt will announce "Power On," and the LED indicator will start flashing continuously.
Power off: Long press the right button for 3 seconds to turn off, or automatically turn off if not connected for 5 minutes.

Bluetooth Pairing



1.Open the settings and go to Bluetooth.
2.Ensure the glasses are powered on. Turn on Bluetooth on your phone or tablet and search for the device name: E30.
3.Tap the device name to connect. Once the connection is successful, the indicator light will turn off.

Playing Music



Play/Pause Music: Press the power button.
Next Track: Double-click the power button.
Previous Track: Double-click the secondary button.
Volume Up: Triple-click the power button (increase volume by one level).
Volume Down: Triple-click the secondary button (decrease volume by one level).

Fashion Sunglasses



UV Protection: The smart glasses are equipped with polarized lenses that reduce glare and block 90% of UV rays, effectively protecting your eyes from harsh sunlight. They are suitable for outdoor activities such as fishing, driving, walking the dog, etc. Keeping your eyes comfortable and healthy.

Low Battery Indicator



Low Battery Alert: A voice prompt will announce, "Low battery, please charge," and the LED indicator will flash red intermittently as a reminder.

Low Battery Shutdown: A voice prompt will announce, "Power off," and the LED indicator will flash red before the device shuts down.

Making and Answering Calls



Answering a Call: Press the power button once when an incoming call is received to answer it.
Ending a Call: Press the power button once during the call to end it.
Rejecting a Call: Double-click the power button when an incoming call is received to reject it.

Charging Method



Charging Method：Type-C Charging Port
Charging Specifications: Type-C, 5V/1A
Friendly Reminders:Fast charging is not recommended, as it may shorten battery life. Use the original charging cable to ensure proper charging and avoid potential issues.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
•Reorient or relocate the receiving antenna.
•Increase the separation between the equipment and receiver.
•Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
•Consult the dealer or an experienced radio/TV technician for help.
Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

RF Exposure Information
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.