产品使用手册

T34



磁吸无线音响

使用产品前请仔细阅读本手册

产品功能介绍



产品使用说明

1. **开/关机：**在关机状态下长按2S开/关机按键，听到提示音后产品开机，在开机状态下长按2S开/关机按键，听到提示音后产品关机；短按开机键可实现暂停和播放切换。
2. **氛围灯调节：**双击按键可实现氛围灯开启和关闭以及氛围灯模式切换。
3. **TWS：**在两台机器开机状态下，三击按键可实现TWS连接和断开功能。

蓝牙连接

1. **主机和设备蓝牙连接：**在主机和设备开启蓝牙模式状态下，设备搜索蓝牙名“T34”进行连接，听到提示音后蓝牙连接成功.

注意事项

1. 本品使用锂电池，过充或者过放都将影响产品使用寿命，使用过程中请及时充电以及充满电后断开电源。
2. 本产品非儿童玩具，10岁以下儿童请在监护人看护下使用。
3. 本产品为非防水设计，请勿将产品丢入水中。
4. 请使用符合国家标准的适配器充电。

产品参数

产品名称：磁吸无线音响　　产品型号：T34
额定输入：DC 5V⎓1A　　电池容量：350mAh
产品单重：约65g　　产品尺寸：57*57*39mm
执行标准: GB4706.27-2008　GB4943.1-2022

温馨提示：
在废弃产品时必须将电池取出，在取出电池时必须要断电。电池取出后应安全处置。

包装清单

主机 x1　说明书 x1　数据线 x1　引磁片 x1

三包凭证

1. 妥善保管保修卡，以做维修时的凭证。
2. 保修期为产品购买之日起半年以内。
3. 保修期内，本产品在正常使用的情况下发生故障，经本公司查验属实，厂家将提供免费维修。

以下情况恕不提供免费维修

本公司产品实行保修年限之内的有限保修，属于下列情况的设备故障或损坏，不在有限保修之列，本公司不承担免费的保修义务；

1. 设备或部件已经超出有效的保修期。
2. 用户未按照说明书的要求，错误的安装，保管以及使用而造成的设备故障或损坏。
3. 由非本公司授权机构或人员拆卸而造成的设备故障或损坏。
4. 因意外因素或人为原因（包括但不限于操作失误，刮伤，搬运，磕碰，输入不适当电压电流等）导致的设备故障或损坏。
5. 因自然灾害（如地震，火灾等）原因造成的设备故障或损坏。

Instructions

T34



Magnetic wireless speaker

Please read this manunal carefully before using the product

Product Function Introduction



Host usage instructions

1. **Power on/off:** Long press the 2S power on/off button in the off state, and the product will turn on when you hear a prompt sound. Long press the 2S power on/off button in the on state, and the product will turn off when you hear a prompt sound; Short press the power button to pause and switch between playback.
2. **Atmosphere light adjustment:** Double click the button to turn on and off the atmosphere light and switch the atmosphere light mode.
3. **TWS:** When two machines are turned on, pressing three buttons can achieve TWS connection and disconnection functions.

Bluetooth connectivity

1. **Bluetooth connection between host and device:**When the host and device are in Bluetooth mode, the device searches for the Bluetooth name "T34" to connect. After hearing the prompt sound, the Bluetooth connection is successful.

Matters needing attention

1. This product uses lithium battery, overcharge or overdischarge will affect the service life of the product, please charge it in time during use and disconnect the power supply after full charge.
2. This product is not a children's toy, children under the age of 10 should be used under the supervision of a guardian.
3. This product is not waterproof, please do not throw the product into water.
4. Please use an adapter that meets the national standard for charging.

Product parameters

Product Name: Portable wireless speaker
Product Model: T34
Rated input: DC 5V⎓1A　　Battery capacity: 350mAh
Unit weight: about 65g　　Product size: 57*57*39mm
Executive Standards：GB4706.27-2008　GB4943.1-2022

Tips

The battery must be removed when the product is discarded, and the power must be de-energized when the battery is removed. Batteries should be disposed of safely after removal.

Packing List



Machine x1　Instructions x1

USB cable x1　Adhesive Metal Disc x1

Certificate of three guarantees

1. Keep the warranty card properly as a proof of maintenance
2. The warranty period is within half a year from the date of purchase of the product
3. During the warranty period, if the product fails under normal use, the manufacturer will provide free maintenance if it is verified by the company

No free repair will be provide for the following conditions

The company's products are subject to a limited warranty within the warranty period, and equipment failure or damage in the following situations is not included in the limited warranty, and the company does not assume free warranty obligations

1. The equipment or parts have exceeded the valid warranty period. The user does not follow the requirements of the manual, and the.
2. Equipment is malfunctioned or damaged due to improper installation, storage and use.
3. Equipment failure or damage caused by dismantling by non-authorized institutions or personnel of the Company.
4. Equipment failure or damage caused by unexpected factors or human reasons (including but not limited to operation error, scratches, handling, bumps, improper input voltage and current, etc.).
5. Equipment failure or damage caused by natural disasters (such as earthquakes, fires, etc.).

FCC Warning

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any inte rference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interferenceto radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.