Product Specifications

Model: FERRAVUTTI BD7
Bluetooth Version: 5.4
Battery: Li-ion(Earbuds: 30mAh*2, Charging case: 300mAh)
Charging Time: Earbuds ~1.5 hours, Charging case ~2 hours
Listening Time: 5-6H （full charge for single use/volume 50%)
Total Working Time With Charing Case: up to 25 hours
Frequency Range: 20Hz-20kHz
Grade of Waterproof: IPX4
Bluetooth Power: 10dBm
Speaker Dimensions: Φ10-32Ω
USB-C Input: DC 5V/300mAh
Support: A2DP/HFP/HSP/AVRCP
Charging Port: Type-C

TRADEMARKS

All compay brand and product name are trademarks or registered trademarks of their respective copanies. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc.
Specifications are subject to change without notice.

WEEE NOTICE

This product should not be disposed of with household waste.It is your responsibility to act in accordance with local environmental laws and guidelines by depositing it at a collection point for recycling of electronic equipment.

EU CONFORMITY

Cayon Technology Limited. hereby declares that this device complies with the essential requirements and other relevant provisions of EC Directive 2014/53/EU, as applies to energy-related products, and RoHS Directive 2011/65/EU, as applies to restricted use of hazardous substances.

PREVENTION OF HEARING LOSS

Caution: Listening to music at high volume levels for long periods of time can cause permanent damage to hearing. To avoid hearing loss, we recommend lowering the volume of the music player before starting playback and then gradually increasing the volume to a comfortable, moderate listening level.

TOUBLESHOOTING

1. Make sure the charging case is full of power.
2. Put the earbuds to the charging case to charge for a while.
3. Take the earbuds out of the case till the white led light flash alternately, this method is only applicable when the earbuds can't pair to the device. If the earbuds have not been paired, double click the right earbud to pair it.
4. Connection failed, check whether the earbuds are paired or not, check your device's Bluetooth search function, and turn off other bluetooth device.
5. Low sound volume or distortion of sound, check the volume of bluetooth device, and turn it to the proper volume.
6. The earphones should be used correctly according to the requirements, in order to ensure smooth connection, pay attention to the influence of the use environment on the earphone. It is suggested that the distance between the device and the earphones shoud be within 10M.
7. Wipe the hardware contacts of the headset and charging case when the earbud is not charging.

SERVICE NOTE

If your problem is not answered above, please contact us via email: service@ferravutti.com
We will respond within 24 hours.

FC CE RoHS

©2025 FERRAVUTTI All Rights Reserved.
FERRAVUTTI is a trademark of Cayon Technology Limited.
All trademarks and trade name are property of their respective owners.
Cayon Technology Limited, Room 804A, Loon Kee Building, 267-275 Des Voeux Road Central, Hong Kong.
Designed by Cayon in Hong Kong. Made in China.

FERRAVUTTI BD7

Wireless Noise Canceling Earbuds

User Manual

Product Description



1. LED indicator light
2. Multifunctional touch control
3. Microphone
4. Charging case LED indicator light
5. Type-C charging port

Packing List

1 x Wireless earbuds with charging case
1 x USB-C Charging cable
6 x Ear caps (2 small size, 2 medium size, 2 large size)
1 x User Manual

Note Before Use

Before the first use, please remove the protective transport film from the earphone charging contacts (if any). Then, put the earbuds back into the charging case and connect them.
Fully charge the product before using it for the first time.

Using The Earbuds

Pair with your mobile device：
1. Open the cover of the charging case, remove the earbuds and they will automatically power on.
2. Earbuds will automatically pair, then the main earbud will flash white (pairing mode).
3. Turn on Bluetooth mode on your device.
4. Select "FERRAVUTTI BD7" in the Bluetooth setting of your device to initiate pairing, and the earbuds will automatically connect with your Bluetooth device, indicated by a tone.
Automatic Connection: After the first pairing, the earbuds will automatically connect to your device.

Answering a Call： When a call is coming, tap the L/R Touch Control to accept the call, or answer the call via your mobile phone.

Ending a Call： Tap the L/R Touch Control twice to end the call, or hang up via your mobile phone.

Rejecting a Call： Press and hold the L/R touch control for 2 seconds to reject an incoming call.

Music Play/Pause： Double-tap the Touch Control of either earbud to Pause/Play the music.

Previous/Next Track:
Previous track: Triple-tap the Touch Control of Left earbud.
Next track: Triple-tap the Touch Control of Right earbud.

Volume Adjustment:
Increase volume: Tap the Touch Control of Right earbud.
Decrease volume: Tap the Touch Control of Left earbud.

Voice Assistant: Press and hold the L and R Touch Control for 2 seconds to activate voice assistant, then also use the same method to close it.

ANC/Transparent Mode/ANC OFF: Long press for 1.5 seconds and release the hand upon hearing the prompt sound.

Reset: Tap the L/R Touch Control 10 times to reset the earbuds.

Charging Earbuds: To charge your earbuds, simply slide each earbud into its corresponding dock until the earbud is fully seated. The earbuds will begin charging, indicated by a steady white light on the earbud. When fully charged, earbuds light will stay white light 30s then turn off. When earbuds are on low battery, red light flash each 5s.

Charging Charging Case: To charge your charging case, plug the included Type-C charging cable into the slot on the back of the charging case. Plug the other end into a USB power source. The case will automatically begin charging, indicated by flashing red light. When it is fully charged, the red light will stay on. When charging case is on low battery, the red light flash.
Note: An audible tone will notify you when the earbuds need to be recharged.

Turning On/Off Earbuds:
Turn on:
Method 1: Open the cover of the charging case, remove the earbuds and they will automatically power on.
Method2: Press and hold the Touch Control on both earbuds for 5 seconds.

Turn off:
Method 1: Place the earbuds back into the charging case, and close the cover of the case.
Method 2: Press and hold the Touch Control on both earbuds for 5 seconds.

Note: The earbuds will turn off automatically after it is disconnected for more than 5 minutes.

Precautions for Use

1. Earbuds should be stored in a dry and ventilated environment to avoid contact with oil, water vapor, steam, moisture and dust, so as not to affect product performance.
2. Avoid using irritating, organic solvents or items containing these ingredients to clean the earbuds.
3. To ensure a smooth connection, it is recommended that the distance between the phone and the earbuds be within 10 meters.
4. Keep the earbuds away from magnets, electrical appliances and speaker.
5. If the headset is not connected or the communication is not smooth, etc., please do not disassemble the headset body and its accessories, otherwise it will not to be guaranteed.
6. To ensure that you use your headset properly, make sure that the headset is fully charged.

SAFETY WARNING

1. Do not expose the product to fire or sources of excessive heat. Keep away from extreme ambient temperatures below-10℃ or above 50℃.
2. Do not disassemble the product. Do not attempt to replace the product's internal batteries.
3. Keep away from corrosive liquids.
4. Do not touch the earbuds with sharp objects and do not use heavy objects to squeeze.
5. Do not use the product in thunderstorm weather.
6. If it has not been used for more than a month, please charge and maintain it in time to ensure that it is safe.
7. Avoid accidents by keeping the product packaging and accessories out of reach of children and pets.
8. Do not drop, hit, scratch, twist, bump, knock, or roll the earphones into water.

Battery Warning

This product has built-in lithium battery.
Do not expose the product to strong sunlight, fire or throw it into the fire to avoid explosion.
Aviod using and charging the battery under extreme temperatures.

FCC Warnning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection againstharmful interference in a residential installation. This equipment generates, uses and can radiateradio frequency energy and, if not installed and used in accordance with the instructions, maycause harmful interference to radio communications. However, there is no guarantee thatinterference will not occur in a particular installation. If this equipment does cause harmfulinterference to radio or television reception, which can be determined by turning the equipmentoff and on, the user is encouraged to try to correct the interference by one or more of thefollowing measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.