# 4一出二模L285*100MM风琴折

## 便携三模式无线键盘

## 蓝牙+2.4G

Windows　Mac OS　Androld

为了您能更好的体验本品功能，请在使用前阅读本说明书

型号:K919

### 产品特点：

1.支持跨设备来回切换
2.三系统模式切换，通用市场主流设备
3.蓝牙3.0+5.0更好的兼容新老设备
4.连接5.0版本，休眠唤醒，更快回既
5.高频设备切换，键盘运行不卡机

### 连接说明：

注:FN键在键盘左下角第二个按键

1.将电源开关拨动到ON开启键盘
2.2.4G模式：(系统默认)
3.蓝牙模式：
长按CONNECT或是键盘上FN+蓝牙1，蓝牙2，组合长按3秒，
蓝灯闪烁，蓝牙设备1进入被搜索状态
设备端一打开系统设置一开启蓝牙一搜索添加即可使用

### 多设备连接：

1.FN+Q:连接蓝牙设备1
2.FN+W:连接蓝牙设备2
3.FN+E:连接USB，2.4G无线接收
4.FN+Q,W,E,组合单按：可以切换已配对过的设备
5.FN+Q,W,组合长按3秒:闪灯,可启动被搜索状态(连接新设备)

### 连接补充说明：

1.初次连接需要将键盘切换至对应系统(Windows)
2.未切换可能导致功能按键不能正常使用
3.键盘使用距离5-10m,不同设备与环境因素对距离有关

### Fn组合功能按键:

| 连接切换 | | 多媒体按键 | |
|---|---|---|---|
| FN+Q | 组合长按3秒,闪灯 | FN+F1 | 搜索 |
| FN+W | 可搜索添加新设备 | FN+F2 | 快捷 |
| FN+E | 切换至USB无线接收 | FN+F3 | |
| | | FN+F4 | 复制 |
| FN+A | 苹果 IOS 模式 | FN+F5 | 剪切 |
| FN+S | 安卓模式 | FN+F6 | 上一曲 |
| FN+D | Window模式 | FN+F7 | 播放暂停 |
| FN+1 | Windows，1-0 | FN+F8 | 下一曲 |
| FN+Q | 组合单按 | FN+F9 | 声音减少 |
| FN+W | 可切换已配对设备 | FN+F10 | 声音增加 |
| FN+E | | | |
| | | | |
| | | | |

### 故障排除：

1.当键盘不能被搜索到，尝试开关设备端蓝牙再次搜索
2.当键盘开机没有指示灯时，尝试给键盘进行充电
3.连接其他设备后，再次回连原设备 需要删除老记录才可连接
4.当配对失败时，需要删除失败的配对记录，再进行二次配对

| 用户信息 | |
|---|---|
| 用户姓名： | 联系电话： |
| 通信地址及邮件： | |
| E-mail地址： | |
| 购买本产品型号： | 购买日期： |

《充电压不能高5V，电不能高于2A》

919三模

## Portable three mode wireless keyboard

## Bluetooth+2.4G

Windows　Mac OS　Androld

For better usage experience of the product,please read this manual before using it.

Model: K919

### Product features:

1.Support switching back and forth across devices
2.Three-system mode switching; the mainstream equipment of the general market
3.Bluetooth 3.0+ 5.0 is better compatible with new and old devices
4.Connect version 5.0 to hibernate and wake up faster
5.With high frequency equipment switching, the keyboard works smoothly

### Connection Description:

Note: FN key is the second key in the bottom left corner of the keyboard

1.Turn the power switch to ON to turn on the keyboard

2. Bluetooth mode:
Press and hold FN, then press 1, and then press and hold for 3 seconds,
the blue light flashes,and Bluetooth device 1 enters the searched state
on the device side-open the system settings---turn on Bluetooth --search and add

### Multi device connection:

1.FN +Q: connect Bluetooth device 1 .
2.FN +W: connect Bluetooth device 2 .
3.FN +E: Connecting USB wireless reception
4.FN +Q,W,E: combination single press: you can switch the paired devices
5.FN +Q,W: combined long press for 3 seconds: flashing light, can start the searched state (connect new equipment)

### Connection supplement:

1.The initial connection keyboard needs to switch the device to the corresponding system (Windows)
2. If the system is not switched, the function key may not work normally!
3.The use distance of keyboard is 5-10m, and the distance is related to different equipment and environmental factors

### FN combination function key:

| Connection switching | | Multimedia buttons | |
|---|---|---|---|
| FN+Q | Combined long press for 3seconds, flashing light,consearch to add new device | FN+F1 | Search |
| FN+W | | FN+F2 | Mute |
| FN+E | Switch to USB wireless reception | FN+F3 | screenshots |
| FN+A | Apple IOS mode | FN+F4 | screen |
| FN+S | Android mode | FN+F5 | Meter oplus |
| FN+D | Windows mode | FN+F6 | Pl a Song |
| FN+F | Windows，1-0 | FN+F7 | Play/Pause |
| | | FN+F8 | The next song |
| | | FN+F9 | Turn down the volume |
| FN+Q | Combined single press can switch paired devices | FN+F10 | turn up the volume |
| FN+W | | | |
| FN+E | | | |
| | | | |

### Troubleshooting:

1. When the keyboard can't be searched，try Bluetooth on the switchdevice to search again
2. When the keyboard is turned on and there is no indicator light, try tocharge the keyboard
3.After connecting other devices, you need to delete the old records beforeconnecting back to the original devices
4.When the pairing fails, the failed pairing record needs to be deleted andthe second pairing is performed

| User information | |
|---|---|
| Uuser name: | Cortact phone: |
| Mailing address: | |
| E-mail address： | |
| Produsi model: | Date of purchase: |

The charging voltage cannot behigher than5V,
and the electricity cannot be higher than2A

919三模

### FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation.If this equipment does cause harmful interference to radio or television reception,
which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.