UNIVERSAL WIRELESS MICROPHONE

USE MANUAL

UNIVERSAL WIRELESS

Conference Microphone Series

Diagram of the Handheld

Diagram of the Receiver

1.Audio Output

6.35mm plug

2.Battery Compartment

Insert 18650 rechargeable battery, open the battery cover and replace it directly

3.Charging Port

TYPE-C charging port with a specification of DC 5V.

4.Power Switch

Press and hold this switch for 3 seconds to turn on/off power of transmitter

5.Receive antenna

Receive the signal from the transmitter

Operating Steps for Handheld Transmitter and Receiver

1.Long press the power buttons on both the handheld transmitter and receiver to turn them on. The transmitter will automatically scan and pair with the receiver; no manual frequency matching is required.

2.Unscrew the tail tube of the handheld transmitter, short press the SET button to change the frequency channel (32 frequency points for Channel). After adjustment, the receiver will synchronize automatically.

Specification Parameters

RF Carrier Frequency Range: 560.1-591.1MHz
Number of Channels: 32
Sensitivity: -60dB
Oscillation Mode: DSP chip frequency locking
Frequency Stability: ±10PPm
RF Power: 5 dBm
Audio Frequency Response: 40~18000Hz
Distortion: <0.5%
Battery Specification: 18650 Li-ion battery
Use distance: about 10 meters
Usage Time: 6 hours

FCC Statement

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has evaluated to meet general RF exposure requirement. The device can be used be in portable exposure without restriction.