月光灯塔说明书
MOONLIT BEACON MANUAL

使用说明 INSTRUCTIONS FOR USE

温馨提示：所有款式投影灯点亮60分钟后自动关闭；
Reminder: All styles of projection lights will automatically turn off after 60 minutes of illumination;

音箱款/白噪音款

① ON档为开启白噪音同时灯光呼吸模式档,一首音乐循环10分钟后自动切换下一首，三首循环播放。(仅白噪音款)
② OFF档为关闭电源;
③ AUTO档为遥控模式同时开启 音箱功能，手机搜索"MG-008"进行连接;
④ 充电指示灯-红色，充电亮，充满灭。 指示灯-蓝色，等待连接指示灯闪烁，连接成功指示灯长亮。

Speaker / White noise version

① The ON position means turning on the power and turning on the light at the same time;(Only white noise version)
② OFF position means turning off the power;
③ Enable remote control mode and function in AUTO mode search for "MG-008" on your phone to connect;
④ Charging indicator light - red, charging on, fully charged off, indicator light - blue, waiting for connection indicator light to flash, successful connection indicator light to stay on.

FCC Caution:
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

遥控器说明 Remote Control Instructions

音箱款 Speaker



开关：单按全部亮灯，再按切换呼吸灯模式，再按全关；
投影：单按打开投影，再按关闭投影；
定时：单按"10"/"30"，10分钟/30分钟后全部关，设定成功灯光闪烁一次，再次按取消定时且灯光闪烁两次；
亮度：单按"+"亮度调高，单按"-"亮度调低。

Switch : Press to turn on all lights, then press to switch to breathing light mode, and then press to turn off all lightsOFF position means turning off the power;
Projection : Press to turn on projection, then press to turn off projection;
Timing : Press "10"/"30" once, turn off all after 10/30 minutes. If the setting is successful, the lights will flash once. Press "Cancel Timer" again and the lights will flash twice;
Brightness : Press the "+" button to increase the brightness, and press the "-" button to decrease the brightness.

白噪音款遥控器White Noise Remote Control



白噪音控制/White noise control

长按：音量减小 / Long press: sound decreases
单按：切换音乐 / Single press: Switch music
长按：音量增大 / Long press: Volume increases

产品参数 PRODUCT PARAMETERS

产品名称：月光灯塔- 音箱 / 白噪音款
产品型号：MG-A08-4
输入电压：5V ⎓ 1A
额定功率：5W
喇叭功率：4Ω，3W
LED功率：1.5W（5x0.2W/LED模块+1x3W/LED模块）

音箱 ID：MG-008
产品尺寸：70*72*242mm
包装尺寸：94*85*251mm
产品配件：说明书+Type-C数据线
执行标准：GB7000.204-2008 GB7000.1-2015

PRODUCT NAME : Moonlit Beacon-speaker
PRODUCT NUMBER : MG-A08-4 / White noise version
INPUT VOLTAGE : 5V ⎓ 1A
RATED POWER : 5W
SPEAKER POWER : 4Ω，3W
LED POWER : 1.5W（5x0.2W/LED MODULE +1x3W/ MODULE）

SPEAKER ID : MG-008
PRODUCT SIZE : 70*72*242mm
PACKAGE SIZE : 94*85*251mm
PRODUCT ACESSORIES : Manual+Type-C Data cable
ENFORCE STANDARD : GB7000.204-2008 GB7000.1-2015

注意事项 PRECAUTIONS

1.本产品严禁自行拆解,以免造成损坏或发生危险。
2.产品正常使用时，请勿放置在大于6°的斜面上使用。
3.请勿在高温环境下使用，远离火源水体等极端环境。
4.如需丢弃处理本产品，请按照国家的环保法规进行处理。
5.此灯具的光源不可替换，当光源寿终，请替换整个灯具。
6.长期不使用本产品时，应充满电后存放，且每三个月补充一次。
7.当发现本产品在使用过程中出现冒烟、异味、异响等情况，请勿继续使用。
8.此灯具不可被视为玩具,以防发生意外，三岁以下儿童需在父母陪同下使用。
9.若产品过热、损坏或坠入液体中，可能存在漏电、短路等风险，请停止使用。
10.产品不含电源适配器，请配套使用获得CCC认证并满足标准要求的电源适配器进行充电(建议使用5V1A)
若使用超过5V的适配器或供电设备为本产品供电，可能会导致产品或供电设备的损坏，并带来安全隐患!
11.鸿蒙系统连接时需要在手机中打开"设备音量与手机同步"设置

合格证 CERTIFICATE

1.It is strictly prohibited to disassemble this product by yourself to avoid damage or danger.
2. During normal use of the product, please do not place it on an incline greater than 6°.
3. Please do not use it in high temperature environments and keep away from extreme environments such as fire sources and water bodies.
4. If you need to discard this product, please dispose it in accordance with the national environmental protection regulations.
5. The light source of this lamp is not replaceable. When the light source expires, please replace the entire lamp.
6. When this product is not used for a long time, it should be stored after being fully charged and replenished every three months.
7. If you find that this product emits smoke, smells, noises, etc. during use, please do not continue to use it.
8. This lamp cannot be regarded as a toy. In case of accidents, children under three years old must be accompanied by their parents when using it.
9. If the product is overheated, damaged, or falls into liquid, there may be risks such as leakage, short circuit, etc. Please stop using it.
10. The product does not include a power adapter. Please use a power adapter that has obtained CCC certificati on and meets standard requirements for charging (5V1A is recommended)If you use an adapter or power supply device exceeding 5V to power this product, it may cause damage to the product or power supply device , and pose a safety hazard!
11. When the HarmonyOS system is connected, you need to turn on the " device volume sync with mobile phone" setting in your phone