Power Bank

830

User Manual

Thank you for purchasing this product.This manual describes how to use this product and precautions for safe handling. Please read carefully before use.Also, keep this manual in a safe place so that you can read it back at any time.If you encounter any after-sales problems, please turn to the last side of the manual and contact us according to the email.

Package Connect

· 10000mAh Wireless Charger
· User Manual*1
· (To charge the power bank)charging cable*1

Specification

Model	830
Battery Type	Lithium polymer battery
Capacity	3.7V/10000mAh/37wh
Output-Wireless (for mobile phone)	15W(Max)
Output-Wireless(for Apple Watch or Airpods)	1.5W
USB Output	22.5W
Type-C In/Output	5V/3A 9V/2A 12V/1.5A
Lightning Input	5V/2A
Charging Time	4-5h
Size	2.44 x 0.84 x 0.39inch
Net Weight	0.43lb

Note:
Due to the small size of the batteries in watches and airpods, their power is limited and they cannot achieve as high a power input as mobile phones.

Each Part of the Battery Pack

How to Use

•How to check the remaining power?

The number shown on the LCD display is the remaining battery capacity.
When the power button is pressed, the LCD display for the remaining battery level is illuminated. Press the power button again for 2 seconds to turn off the LCD display.

•How to charge the battery pack

Please use the included charging cable to connect the plug and the power bank. When the numbers on the LCD display begin to increase, it indicates that the power bank is being charged.

Note: If you want to fast charge, we recommend using an adapter and charging cable that supports fast charge.

•How to charge the smart device

1.Wireless Charge

Place the smart device against the magnetic charging position. Through the super strong magnetic attraction, the device will automatically display charging, and the number on the LCD display will start to flash, which proves that the wireless charging is working properly.
Notice: If the phone cannot be charged magnetically, please check whether the device supports wireless charging, or remove the phone case and try again.

2.Via Type-c/USB output to Charge

When you connect the applicable cable from the Type-C/USB output port to the device, the remaining power number will light up and power supply will start automatically.
Note: If you use a device and cable that supports quick charging, rapid lightning may occur.

Notice ⚠

Mag-safe compatible function: iPhone 15/14/13/12/series, apple watch SE/2/3/4/5/6/7/8, Airpods 2/Airpods 3rd Gen/ Airpods Pro/Airpods Pro 2nd Gen ONLY.
*Not compatible with non-Mag-safe compatible cases and iPhone models earlier than 12 series.
Taking the below actions may cause heat generation, fire, explosion, liquid leakage, failure, electric shock, injury, etc.
· Do not disassemble or modify the product.
· Do not use power supply other than specified.
· Do not store or leave it unattended to high temperatures (near fires, heaters, strong direct sunlight location, inside a car under the hot sun, etc.)
· Do not use it for a long time when it touches the body.
· Do not give a strong impact such as stepping on it, placing heavy objects on it, or dropping it.
· Do not let it get wet with water, seawater, drinking water, rainwater, etc.
· Do not carry or store the connector together with metal objects such as wires, necklaces, and pairs so that the ports magnetic attach other metal objects.
· Do not put this product in a microwave oven, an open container, or a high-pressure container.

Safety Instructions ⚠

· Please check the device's model before charge, and use a compatible cable to charge your device.
· Check the charging status when the battery pack is charging. Please charge the battery once a month even if it is not used for a long period of time. Do not charge the battery for a long time when you are away.
· If the power level does not rise after charging for a long time, turn off the power bank and turn it on again.
· If you notice any unusual odor, heat generation, discoloration, deformation, or any other abnormalities while using, charging, or storing the battery, stop using it immediately.
· When disposing of this product, please dispose of it correctly according to the instructions of each local government.

Federal Communications Commission Notice
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and , if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.