Musnap Ocean C

Product Introduction

Thank you for purchasing the Musnap Ocean C Smart e-Reader. This guide will help you get started quickly. Please read it carefully before operating the device.

Product Features

Slim & Lightweight

8-Core 2.2GHz



7-inch HD EInk Carta Screen

Smooth Writing with Millisecond Response

Advanced Security Encryption

Quick and Convenient Wireless Book Transfer

Product Introduction

1 Buttons






MUSNAP


Type-C
Port
Mic

- Power Button

  Press and hold for 2-3 seconds to turn the device on or off.

- Type-C Port

  Use a data cable to connect the device to a computer or charger via this port for data transfer and charging.

2 Stylus Pen



Instructions for Replacing the Stylus Tip



- Tip

  The stylus pen requires tip replacement. To replace the tip, gently grip and pull out the old tip, then insert a new one.

3 Bookshelf



- Click ☰ in the top right corner of the interface to perform the following operations:

- Manage: Move or delete books in bulk.
- New Group: Create a new group and move books into it.
- File Manage: View all documents stored on the device and import books from the SD card to the bookshelf.
- Vocabulary Book: While reading, long-press a word or phrase to add it to the vocabulary book for easy review. In the vocabulary book interface, you can view words, categorize or delete them in bulk.

- Long-press a book on the bookshelf or choose to move, pin, or delete the book.

4 Reading





mathematical expressions, formulas and equations clash with the text or degrade when scaled. We consider this unacceptable for *The Feynman Lectures on Physics*, and so we have created a new kind of e-book especially for this edition – one which seamlessly integrates text, mathematics, figures and tables.

Whenever technically feasible, mathematics are presented using HTML and stylesheet formatting; otherwise, vectorized images are used. Great effort has been put into making the mathematical typography rendered by these two different methods indistinguishable. Vectorized images are used for tables

AI Handwritten Instructions for Use

Instructions

1、Stroke Lining : A straight line will be automatically generated below the text.



2、Smart Erasure : The underlined parts with the pen will be deleted automatically.





- While reading a book (as shown in the image), click ①Menus to bring up the main menu. Click ②Previous Page to go back a page, and click ③Next Page to go forward a page.
- Click 〈 in the menu to go back to the bookshelf interface.
- Handwriting is enabled when entering the reading interface, allowing you to annotate text directly on the reading page.
- Click you can open the handwriting bar,and use the following functions:

- Click to switch pen types, thickness, and color.
- Click to erase.
- Click to use features such as Stroke Lining,Smart Erasure,Handwriting Recognition and One-stroke Formation.

- Click to perform a full-text keyword search in the current book.
- Click to add a bookmark to the current reading page.
- Click to disable pen writing, allowing the pen to be used for page turning.
- Click in the menu to view the book's table of contents and added bookmarks.
- Click in the menu to view notes for the book.
- Click in the menu to view the current reading progress and set page-turning methods.
- Click in the menu to adjust font, font size, layout, contrast, etc., while reading.
- In the pop-up menu interface, press the middle of the screen again to exit the menu and return to full-screen reading mode.
- Long-press text on the screen while reading to edit notes, copy, underline, translate the selected text.
- The bottom menu bar allows you to crop edges for Office and PDF documents, and reflow Word and PDF files. Click "More" to share and export Office and PDF files with annotations. Click the bottom menu bar to synchronously adjust the contrast of text and images in PDF



- When reading a PDF document, you can perform the following operations:
  - Click to scroll up and down the document for page-turning.

- Click to perform OCR text recognition on scanned PDFs.

- When reading a PDF, click Aa to perform the following functions:
  - In the De-Watermark, four default gears are provided to adjust the display effect, and custom adjustments are also supported to achieve the best reading effect
  - Click to restore the page to default settings, discarding any current configurations.
  - Click to set page-turning methods, page-turning effects, stealth mode, image ghosting removal, and book layout.
  - Click "Crop " to crop the edges of the current document.
  - Click to automatically crop the document with corresponding margin settings.
  - Click to choose from seven styles, each with different cropping directions, suitable for reading scenarios like comics and academic papers.
  - Click to restore the document to its original style.
- In the pop-up menu interface, tap the middle of the screen again to exit the menu and return to full-screen reading mode.
- During reading, long-pressing the text on the screen allows you to take notes, copy, underline, search, and perform other operations on the selected text.

- When you want to use the notebook and schedule features, you can find them in Mine - Apps and open them for use.

5 Create Notebook





- Click ⊕ at the bottom right corner of the notebook list to create a new notebook.
- Click to switch between different pen types, adjust thickness, and change colors.
- Click to select deleted handwritten content, supporting trajectory erasure, area erasure, stroke erasure, and erasing all：
  - Track Erase: Erase handwritten content point by point.

- Range Erase: Circle the area to erase selected content.
- Stroke Erase: Erase an entire stroke.
- Erase All: Clear all content on the page.

- Click to insert shapes, text, images, notes, books, recordings, etc.
  - Click to insert various shapes into the notebook.
  - Click to insert a text box in the desired area. You can customize the font, size, color, alignment, line spacing, bold, underline, copy, and delete text.
  - Click to insert images from the device into the notebook.
  - Click to insert corresponding notes
  - Click to insert the corresponding book
  - Click to record audio while taking notes. Each notebook supports up to 5 recordings. Click to quickly mark important parts of the recording.
- Click to use AI features such as one-stroke shaping, handwriting-to-text conversion, content-to-graphics conversion, and note blurring:
  - Click to standardize the drawn shapes.
  - Click to recognize handwritten content and convert it into text.
  - Click to use the [Flowchart] template to convert content into a flowchart.
- Click use the lasso tool to select parts of the page.

You can adjust colors, copy, cut, convert handwriting to text, insert links, and clear selected content.

- Click undo the previous action.
- Click to redo an action that was undone.
- Click to add different layers for handwritten notes.
- Click to manage notebook pages with options like select all, copy, cut, paste, star, share, and delete.
- Click to share a single page or the entire notebook in the desired format.
- Click ··· to view more functions.
- Click to change the name of the notebook.
- Click to change the current notebook template style.
- Click to swipe through pages with your finger.
- Click to set the current note page as the device screensaver.
- Click to display the notebook function bar vertically.
- Click 、 to minimize or maximize the display of the notebook function bar.
- Click to set the notebook function bar to display as a floating ball.

6 Notebook



- Search local notebooks and note content through the in the top right corner.
- Click in the top right corner to choose file transfer methods such as WiFi import, File Export and Device Transfer 2.0.

- Click ☰ in the top right corner to perform the following operations:
  - Manage: Move, delete, share.
  - New Group: Create a new group and move notes into it.
  - File Manage: View all documents stored on the device.
  - Sort by: Sort notebooks by modification time, creation time, name, size, etc.
  - Display mode: Three notebook display modes can be selected: six grid, sixteen grid, list mode, etc.
  - Long press notebook: You can modify the name, top, move, delete, share, encrypt and other operations on a single notebook.

7 Schedule




3 4 5 6 7 8 9
Hand-creation
Notes
How to create a To-Do?
Pen
Range Er...
Recogniti...


Statistics
2025-10.13-10.19
Weekly
Monthly
So far this week, a total of 1 To-do have been created（finished 0 to-dos）, and read 3 books.
Mon. 10.13
Tue. 10.14
Musnap
Gramophone, film, type...
Wed. 10.15
Long press to delete or ...
Musnap
[All notes] Musnap
Thur. 10.16
Fri. 10.17
Sat. 10.18
Sun. 10.19

- Supports viewing the calendar, including plan lists, book lists, and note lists for different dates.
- Click to switch pen types, thickness, and color.

- Click to select and erase handwritten content, supporting trajectory erase, area erase, stroke erase, and erase all.
- After completing the handwritten plan, click to convert it into text and add it to your schedule.
- Click to view the weekly schedule report, supporting date navigation.
- Click to view the monthly schedule report, supporting date navigation.

8 Mine



- Within “System Settings” interface, you have access to the following range of features.

  - In “Display”,You can customize:Home View, Theme,Screensaver,Wallpaper,Display Light,Sleep Time.

- In “System”,You can customize Volume,Date&Time,Language Settings,Input Method,Font Style, Screen Rotation.
- In “Auxiliary functions”,You can customize: Global Gestures,Smart Assistant,Pen Button,Smart Cover Wake-up.
- In “Privacy”,You can set file and device passwords on this interface.
- In “System & Updates”,You can check for updates or perform data cleaning operations on this interface.

- In “Read”, you can configure settings such as page-turning methods, page numbers, layout, image ghosting removal, bookmarks, and reading preferences.
- In “Notes”, you can configure settings such as stylus switching, erase mode, note templates, and custom functions.
- In “Schedule”, you can set up schedule screensavers and reminders.
- In “Apps”, you can download and view related applications, and long-press to manage and optimize app display settings.
- In “About”, You can View device information on this interface.

9 Basic Parameters

Creen	7 inches
Resolution	1264*1680
Reading Light	30-level brightness, adjustable color temperature
Interface	Type-C port
Wi-Fi	802.11 a/b/g/n；2.4GHz/5GHz
Storage	64GB
Battery	2400 mAh
Dimensions	157.5*138.7*7.0mm

- Turn on the device: Hold down the power button 2-3 secondis, the device will turn on.
- Charging: When the device shows low battery, connecting the USB datacable to the device and the other end to a computer or charger can charge the device. When fully charged, the device will display a full battery icon.
- Firmware update: OTA update on the device. You can select the update menu in the device's settings menu to perform the OTA upgrade.
- Power input: Please use a 5V-2A charger for charging.
- Power output: When connected to an external device, it supports 5V/0.5A. After enabling the OTG reverse charging function, the maximum output is 5V/0.5A (2.5W).

10 Safe usage guide



The screen is fragile, do not collide or press it



Contains battery, kept away from liquids



Do not disassemble without authorization



Operating environment 0-50 ° C

- View the approved code operation guide:

Settings-About-Certification Mark

- Be careful:
  - The battery inside the product is designed to be non removable and can be disassembled or replaced by stationary users themselves.
  - The screen or back panel is made of fragile material, please do not drop or collide with foreign objects, and any damage caused will require paid replacement.

Low power RF equipment that has been experimentally proven shall not be used by companies, businesses, or users without approval change the frequency, increase the frequency, or modify the characteristics and functions of the design. The use of low-power RF equipment shall not affect flight safety or interfere with legitimate communication. If interference is found, it should be immediately stopped and improved to no interference before continuing to be used. The aforementioned legal communication refers to wireless communication operated in accordance with the Telecommunications Management Act. Low power RF equipment must withstand interference from legitimate communication or industrial, scientific, and medical radio radiation electrical equipment. Avoid affecting the operation of nearby radar systems. High gain directional antennas can only be applied to fixed point-to-point systems.

1) Excessive use may harm vision.
2) Please take a 10 minute break after using for 30 minutes.
3) Children under 2 years old should not watch screens, and children over 2 years old should not watch screens for more than 1 hour per day.
4) Reduce the impact of electromagnetic waves, please use them properly.

Declaration:

The content contained in this Product Introduction is not complete. Please refer to the specific user guide for the relevant model. There may be slight differences between the product images and the actual product. The effect demonstration and schematic diagrams are for reference only Please refer to the actual product for its appearance (including but not limited to color) and functionality.

210-258164

11 Operation steps

1.Select Settings on the home page



2. Select About in Settings





3. Select Certification Mark in About





12 FCC Caution

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.

Specific absorption rate (SAR):

This Device meets the government's requirements for exposure to radio waves. The guidelines are based on standards developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a margin of safety designed to ensure the safety of all people regardless of their age or health. The FCC Statement of Exposure to RF and the SAR limit for the United States (FCC) is 1.6 W/kg average for each gram of tissue. This device was tested for typical operations of use on the body, with the back of the Device at 0mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a distance of 0mm between the user's body and the back of the Device. The use of belt clips, covers and similar accessories must not contain metallic components in their assembly. The use of accessories that do not meet these requirements may not meet FCC RF exposure requirements and should be avoided. Functioning in the body This device was tested for typical operations of use in the body. To comply with exposure requirements, a minimum separation distance of 0mm must be maintained between the user's body and the Device, including the antenna. Third-party accessories such as belt clips, covers and similar accessories used with this device should not contain metallic components, accessories that do not meet these RF exposure requirements and should be avoided from use on the body. Use only the supplied antenna or an approved antenna.

FCC ID: 2BQD6-SM07A-OCEANC

⓭ CE Caution

Risk of explosion if battery is replaced by an incorrect type.

Dispose of used batteries according to the instructions.
CAUTION:
Do not replace battery with an incorrect type.
Do not disposal battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.
Do not leaving battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.
Do not leaving battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.
Do not used in low air pressure at high altitude condition.
Do not used in high or low extreme temperatures.

MUSNAP

Shenzhen Zhangyue Technology Co., Ltd

Website： www.musnap.com

Address： Room 907-909, 9th Floor, Building 8, Weixin Software Technology Park, No. 009 Gaoxin South 9th Road, High tech Zone Community, Yuehai Street, Nanshan District, Shenzhen, Guangdong Province, China