How to pair with Bluetooth

Bluetooth pairing: In the off state, press and hold the power button for 3 to 5 seconds, the light into the red and blue flashing state, and then enter the pairing state. Turn on the Bluetooth (cell phone/computer) on the device and search for he device name "WY518", click the device"WY518"to pair and connect.

Bluetooth / MP3 mode switching: Double click the power button (multi-function composite button) to freely switch between Bluetooth and memory mode.

Emphasis: The power on automatically default Bluetooth mode status

Song download: Connect the original charging data cable to the computer and headset to read Take a USB flash drive and copy the computer song to the USB flash drive

TF card playback mode switch: In TF card mode (when playing songs), double tap the power button for the first time to switch to sequential playback mode/triple tap the power button to switch to random playback mode (with memory function)

Warm tip: Bluetooth headphone will automatically search for the latest device to connect after powering on. When the Bluetooth headphone and the device deviate from the effective distance of 10 meters (33 feet), the Bluetooth headphone will be disconnected from the device, and they will be reconnected only when they are placed within 10 meters again. If theBluetooth headphone is disconnected from the device for too long, then you need to click the multi-function button on the Bluetooth headphone to reconnect.

Function	headphone status	Operation
Voice control	Bluetooth is connected	Press and hold the On/Off button fro 1 second

Description: In the Bluetooth connection state,long press the power on button for 1 second to wake up, after hearing the tone you can voice manipulate the phone, save the time to operate the phone, fast and intelligent.

Indicator

Charging	Red linght(always on)
Charging completed	Blue light (always on)
Search for pairing	Flash in red and blue alternately
Bluetooth music playback	Blue light flashes slowly for 5 seconds

* Charging time: About 2 hours
  Distance: Bluetooth 10 meter
* Battery: 200mAh
* Play: More than 6 hours@70% volume
  Agreement: a2dp1.3.2\avctp1.4\avdtp 1.3\ avrcp 1.6.2\hfp 1.8 \spp 1.2\rfcomm 1.1\pnp 1.3\hid1.1.1\ sdpcore5.3\l2cap core 5.3
* BT Version: 5.4
  Input: 5V/180mA
* Music format support WAV, FLAC, WMA, AAC, MP3, APE, M4A
* Waterproof: IPX8

Maintenance and cleaning.

- The headphone can not soak seawater/salt water for a long time, they use fresh water to rinse and dry. Charging electromagnetic suction part is easy to corrode.
- If not used for a long time, please at least once a month ful charge.
- Please do not disassemble any parts of the product, such as the discovery of product defects immediately stop using the product, and contact the seller after-sales service.
- After each campaign, please wipe the surface of the headphone water, especially the location of the filling electromagnetic suction. to deal with the cleaning in time to prevent sweat, and salt water corrosion charging port, affecting the life of the product.
- Keep the product away from fire ,heat,freezing sources, chemicals, violent impact disassembly and extrusion products are strictly prohibited
- Please use a charging head with an output of 5V1A or less

Certificate of conformity

Q.C.Passed

Product warranty card

This card is a product warranty certificate, please kee it properly

Product name:	Product model:
Purchase date:	Client's name:
Contact:	

Product maintenance records

Date	Bad phenomenon	Solution

Bone Conduction Sports Headphone

WY518

Instructions for usage and warranty

Operating instructions and Warranty description





① Indicator light ② Magnetic suction charging port
③ Volume "-" button ④ On/off button
⑤ Volume "+" button ⑥ Microphone

Charge

The headphone uses a built-in rechargeable battery , the first use of the headphone must be fully charged to the battery .In use . if the voice promps "low battery", the battery is low, and you need to charge the headphone.

The charging cable should be connected to the headphone magnetic charging port , about 2 hours to be fully charged. The charging status indicator's red light is always on, full charge is always on the blue light.

Note : Magnetic charging has a positive and negative polarity correspondence, mutual adsorption can be charged normally, and mutual repulsion will not charge or even cause a short circuit.

Warning : The rechargeable battery of this product must be disposed of properly for recycling. Please do not put the battery into the fire ,so as not to cause an explosion.

Operating instruction

Function	Operation	Indicator
On	Press and hold ④ (around 3-5 seconds)	Light on
Off	Press and hold ④ (around 3-5 seconds)	Light off

Music Play

Function	Headphone status	Operation
Increase volume	Play music	click
Reduce volume	Play music	click +"
Previous song	Play music	Hold for 1 second ' -
Next song	Play music	Hold for 1 second " +
Pause	Play music	Click the on/off butto
Resume	Pause	Click the on/off butto

Answer the phone

Function	Headphone status	Operation
Answer the call	Incoming call	Short press the power button to answer
Decline the call	Incoming call	Long press the power button for 1 second to hang up
volume control	During call	click "+" / "-'
Phone/Bluetooth headset switch	During call	Long press and hold the power on button for 1 second

操作说明

]何蓝牙配对

[牙配对:在关机的状态下，长按3-5秒，指示灯进入红[闪烁状态，此时进入配对状态，打开设备上的蓝牙手机/电脑)搜索设备名称"WY518"点击设备"WY518"]对,连接成功即可使用。

[牙/MP3模式切换: 双击开机键（多功能复合键）自由切换蓝牙和内存模式，

强调: 开机自动默认蓝牙模式状态，

[曲下载: 将原装充电数据线连接电脑和耳机，即可读取U盘，将电脑歌曲复制到U盘，

'F卡播放模式切换: 在TF卡模式中（放歌时），首次双击开机键切换顺序播放模式/三击开机键切换随机播放模式（带记忆功能）

[馨提示:蓝牙耳机在开机后会自动搜索连接最新的设备。当蓝牙耳机与设备偏离10米(33英尺)的有效距离时，蓝牙耳机会与设备断开连接，只有重新置于10米范围内时，它们才会重新连接；如果蓝牙耳机与设备断开的时间过长，那么就需要单击蓝牙耳机上的多功能按键才能重新连接。

AI智能语音控制

手机需支持语音唤醒功能

功能	耳机状态	操作
语音控制	蓝牙已连接	长按开机键1秒

说明：在蓝牙连接状态中，长按开机键1秒唤醒，会听到提示音后就可以语音操控手机，节约操作手机的时间，快捷智能

例如您可以直接操控耳机问:

现在几点钟.... ... .今天天气
导航去深圳世界之窗.. .....打电话给某某
打开网易云音乐.....播放刘德华的冰雨.....下一曲.....音量降低.....
打开美团.....打开喜马拉雅.....打开微信.....播放戏曲....

智能运动，轻松好玩

指示灯

充电中	常亮红灯
充电完成	常亮蓝灯
搜索配对	红蓝灯交替闪烁
蓝牙音乐播放	蓝灯5秒慢闪

产品参数

* 蓝牙版本：5.4
* 充电：约2小时
* 输入：5V/180mA
* 播放：大于6H@70%音量
* 协议：a2dp1.3.2\avctp1.4\avdtp 1.3\ avrcp 1.6.2\hfp 1.8 \spp 1.2\rfcomm 1.1\pnp 1.3 \hid1.1.1\sdpcore5.3\l2cap core 5.3
* 格式支持：WAV,FLAC,WMA,AAC,MP3,APE,M4A
* 防水级别：IPX8 （内存版）
* 电池：200mAh
* 距离：蓝牙10米

注意事项

保养与清洁:

- 耳机不能长时间泡海水/盐水，使用后应用淡水冲洗擦干充电磁吸部分容易腐蚀。
- 如果长时间不使用，请至少一个月充满一次电。
- 请不要私自拆装产品上任何部件，如发现产品有缺陷立即停止产品使用、联系销售方售后处理。
- 每次运动后请将耳机表面的水擦拭干净，特别是充电磁吸位置，要及时处理干净，防止汗水，盐水腐蚀充电口，影响产品寿命。
- 产品远离火源、热源、冷冻源、化学品，严禁暴力撞击拆装挤压产品。
- 请使用输出5V1A及以内的充电头，

合格证
Q.C.Pass

产品保修卡

该卡为产品保修凭证,请妥善保管

产品名称:	产品型号:
购买日期:	客户名称:
联系方式:	

产品维修记录

日期	不良现象	解决方案

骨传导运动耳机

WY518

使用指南及保修说明

Operating instructions and Warranty description



① 指示灯 ② 磁吸充电口 ③ 音量"_"键 ④ 开关键 ⑤ 音量"+"键 ⑥ 麦克风

佩戴演示图

充电

该耳机使用内置可充电电池，首次使用耳机必须给电池充满电。使用者，若语音提示"电量低"时，表示电池电量低，此时需要给耳机充电。

将充电线连接到耳机的磁吸充电口,2小时左右即可充满充电状态指示灯红灯常亮，充满电常亮蓝灯

注意： 磁吸充电有正负极对应，相互吸附可正常充电，相互排斥则无法充电甚至造成短路。

警告:本产品的可充电电池必须妥善处理,以便回收利用。请不要将电池放入火中,以免引起爆炸。

操作说明

功能	操作	指示灯
开机	长按开关键3-5秒	灯亮
关机	长按开关键3-5秒	灯灭

音乐播放

功能	耳机状态	操作
增加音量	播放音乐	单击+键
减少音量	播放音乐	单击-键
上一曲	播放音乐	长按1秒-键
下一曲	播放音乐	长按1秒+键
暂停播放	播放音乐	单击开机键
恢复播放	暂停播放	单击开机键

接听电话

功能	耳机状态	操作
接挂电话	来电时	短按开机键接/挂
拒绝电话	来电时	长按1秒开机键挂断
音量控制	通话中	单击"+"/"-"键
手机/蓝牙听筒切换	通话中	长按1秒开机键

FCC Warning

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any inte rference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interferenceto radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.