WHAT'S INCLUDED

LED whip light x1

RF remote x1

RGB controller x1

STEP#1

Route and connect the light cables to the rgb module making sure to avoid interference with suspension or any moving parts.

Plug-and-playthe auick disconnect connectors whip light and controller. Please note that arrow must be inline to connect and thenscrew together.

STEP#2

Diagram1: Wiring direct to Automotive fuse box and using APP or RF remotecontrol to turn on/off. Need to add 10AMP fuse on red 12V+ wires.



STEP#3

Scan application QR Code or go to Google or APP Store search for the application BLEDIM2 and download it

Please refer to the APP operation guide of the setting page in the APP


AUTO
OFF
Off
Auto
On
ON
1
2
3
Do not support music
1H
2H
3H
Timing
SPEED+
MODE+
Speed/ sensitivity
SPEED-
MODE-
Brightness
Mode
R
G
B
Static
W
White
2.4G music controlier

FCC Warnning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection againstharmful interference in a residential installation. This equipment generates, uses and can radiateradio frequency energy and, if not installed and used in accordance with the instructions, maycause harmful interference to radio communications. However, there is no guarantee thatinterference will not occur in a particular installation. If this equipment does cause harmfulinterference to radio or television reception, which can be determined by turning the equipmentoff and on, the user is encouraged to try to correct the interference by one or more of thefollowing measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.