X114 Ulanzi UT01 定时连拍遥控器说明书

材质:80书纸
印刷颜色:30%K
成品尺寸:55mm*45mm
成形工艺:十字折

注:顺序从上到下,从左到右

裁切线
折痕线
出血线

Ulanzi

使用说明书
User Manual

UT01

扫码获取教程 / Scan the code to access the manual
QRコードをスキャンして取扱説明書を入手してください
Scanner Se den Code, um das Handbuch zu erhalten
Escanee el código para obtener el manual
Escanee o código para acessar o manual

前言

感谢您购买优蓝子的产品。

重要提示

请认真阅读本说明书。
请妥善保管说明书。将产品交给他人使用时，请务必将带本说明书。
请注意所有警告提示并遵守说明书内的所有指令。

⚠ 警告

- 请认真阅读说明书，特别是注意事项，因不当操作导致产品受损，本司不承担责任。
- 请在本说明书规定的工作条件下使用和保存本产品，如不，将损失由使用者承担。
- 此说明书基本公司产品测试制定，设计和规格如有变更，恕不另行通知。

注意事项

- 请勿将本产品放置在有腐蚀性化学物品的地方，以免产品受到腐蚀性液体的影响导致产品功能障。
- 请勿私自拆解本产品。
- 请勿使用超过产品规定电压为产品供电，以免造成工作异常或损坏。
- 请在 0～40℃ 温度环境下使用本品。

zh

物品清单

蓝牙连接操作（首次连接）

❶ 长按快门键开关机，确保设备蓝牙已打开（左上角灯光闪烁）。

zh

❷ 打开手机蓝牙，点击名称为"UT01"的设置器设备。

❸ 根据弹窗提示连接配对。

zh

❹ 左上角蓝牙灯常亮，表示连接成功。

认识U-Timer按键

❶ 拍照模式（0s/3s/5s/10s/ 🔍连拍）
❷ 阅读模式 [ ]
❸ 蓝牙/电量/充电指示灯
❹ 开关机/快门模式切换按键
❺ Type-C充电口
❻ 倒计时切换/翻页按键
❼ 喇叭孔
❽ 挂绳孔

zh

遥控器按键操作指南

⚠ 开始拍照，停止倒计时/连拍进程，切换拍照模式/阅读模式，均需在海报背景下才有效。

功能键	按键功能	操作	注意事项
	开关机	长按2s	开机后蓝牙自动开启
	开始拍照	单击	/
	停止倒计时/连拍进程		需处于倒计时/连拍进程中
	切换拍照模式/阅读模式	双击	/
	切换/选项 倒计时 & 连拍功能	单击	需处于拍照模式
	上/下滑动屏幕		需处于阅读模式
	左/右滑动屏幕&翻页	双击	需处于阅读模式

遥控器指示灯说明

1.蓝牙/电量/充电指示灯

灯长常亮	蓝牙已连接
灯光闪烁	蓝牙等待连接/断开
白灯	电量充足（电量>60%）
红灯	电量不足（电量<20%）

*充电中灯为"红"，未满电显示【红灯】，充满电【白灯】。

2.拍照功能选择 & 阅读模式

照相白灯常亮	选中连续模式
照相白灯闪烁	倒计时拍照进程中（需处于拍照模式）

待机状态与关互

- 进入待机：开机后不使用30min
  - 进入待机状态的1h内，单机快门发送信息端；
  - 待机状态下蓝牙断开，需连拍键蓝牙会自动重新连接。
- 自动关机：开始待机后1h
  - 进入待机状态1小时之内蓝牙连接状态没有任何操作，则蓝牙端自动关机。
  - 关机后需要长按开关机键，重新启动连拍键（连续过的蓝牙设备可以自动重新连接）。

常见问题解答

1.蓝牙频繁的切换设备？

1.解开蓝牙设备自动连接连接方式一：取消蓝牙配对

1. 打开手机蓝牙。
2. 点击我的设备，UT01右侧的更多。
3. 点击忽略此设备。
4. 点击弹窗令的忽略配对。
5. 成功取消配对后，设控器已灯闪烁。

方式二：关闭自动重连

1. 关闭历史手机蓝牙。
2. 设备蓝牙重开后，设控器已灯闪烁。

2.连接异设备，用户蓝牙连接操作（首次连接）？

3.为什么iPhone用户首次连接无法？

*客户反应偶发艺术家用户安装系统更新后连接断开"提示中止"，解决了不自动取不连接的解决。
*非苹果用户无法重写以连接使用（郑重上安每半表明解决正常）。

1. 手机打开【设置】→【辅助功能】→【指导】。
2. 打开【指导】。

***若开启后屏幕变大，三指双击屏幕即可恢复正常；**

3. 设置完成，可以成功上下点击翻页。

zh

规格参数

产品名称	U-Timer
净重	15g
尺寸	35mm x 35mm x 15.9mm
主要材质	ABS
蓝牙名称	UT01
蓝牙连接距离	10m
电池	3.7V / 200mAh / 0.74Wh
理论待机时长	约即将提及次数约10天
理论单次快门续航	约即将提及次数约10万+次
供电接口	Type-C（支持边充边用）
输入功率	5V 0.5A
使用温度范围	0 ～40℃

*实际使用时间、续航、不同的连接状态或设备有所减少，属于正常范围。
*理论单次快门续航是以上表数为基础，实际使用时间、续航、拍照频率、拍摄时长等因素而不同。

Preface

Thank you for choosing Ulanzi products.

Important Notes

Retain this manual for future reference. If transferring the product to another user, ensure this manual is included. Observe all warnings and follow all instructions provided in this manual.

⚠ Warning

- Read this manual carefully, paying special attention to the "Caution" section.
- Any use of the product not in accordance with this manual, or under conditions other than those specified for operation, will be considered misuse.
- This manual is edited based on our company's testing. Design and specifications may change without further notice.

Caution

- Do not place or use the product near corrosive chemicals, as exposure may lead to corrosion and potential product failure.
- Do not disassemble, impact, or modify the product.
- Do not use power sources that exceed the product's specified voltage or current, as this may cause malfunction or damage.
- Use this product in an environment of 0~40℃.

en

Packing List

Bluetooth Connection (Initial Pairing)

❶ Long press to power on(If the Bluetooth is enabled (the top-left indicator flashes).

en

❷ Turn on your phone's Bluetooth and select the pairing named "UT01" to connect.

❸ Follow the tips on your phone to pair.

en

❹ A solid Bluetooth indicator in the top-left corner shows a successful connection.

en

Product Overview

❶ Photo Mode（0s/3s/5s/10s/ 🔍Continuous Shooting）
❷ Reading Mode [ ]

❸ Bluetooth/Battery Indicator/Charging Indicator
❹ Power On&Off/Shutter/Mode Switching
❺ Type-C Charging Port
❻ Countdown Switch/Page Turning Button
❼ Speaker
❽ Lanyard Hole

en

Button Operation Instructions

⚠ The following operations require an active Bluetooth connection:
1.Ready to shot.
2.Start to countdown/ continuous shooting.
3.Switch photo mode & reading mode.

Function Key	Key Functions	Operation	Important Notes
	Power On/Off	Long press 2s	Bluetooth on at power-on
	Ready to Shot Start to countdown/Continuous Shooting	Single press	/
			In countdown/continuous shooting
	Switch photo Mode & Reading Mode	Double press	/
	Switch countdown & continuous shooting mode	Single press	Photo mode required
	Scroll up/down		Reading mode required
	Swipe left/right & Turn pages	Double press	Reading mode required

en

Indicator Instruction

1. Bluetooth & Battery Indicator

Solid Light	Bluetooth Connected
Light Flashing	Bluetooth connecting/disconnected
White Light	Power sufficient (Power > 80%)
Red Light	Power insufficient (Power<20%)

*During charging
Red light: Charging
Light off: Fully Charged

2. Photo Mode Selection & Reading Mode

White Light Solid On	Mode Chosen
White Light Flashing	Countdown Shooting (In photo mode)

Standby Mode & Operation

- Standby: No use for 30 minutes after powering on
  - In one hour, press the shutter to activate shooting.
  - In standby mode, Bluetooth is disconnected, but it will reconnect when shooting is activated.

en

- Auto Power Off: One hour after standby
  - If the remote has no operation within one hour standby, it will automatically power off.
  - After powering off, long press the power button to restart (Previously connected devices will reconnect automatically).

FAQ

1.How to switch to a new device?

1. Disconnect the phone's Bluetooth.
Method 1: Unpair Bluetooth
1. Turn on Bluetooth on your phone.
2. Go to My Device and tap "Forgetting This Device" next to "UT01".
3. Tap "Forget This Device".
4. Confirm.
5. After unpairing, the Bluetooth indicator will flash.

Method 2: Turn off Bluetooth on the phone
1. Turn off Bluetooth on the phone.
2. Once the device disconnects, the Bluetooth indicator will flash.

2.Connect a new device, follow the same steps in【Bluetooth Connection (Initial Pairing)】

en

2.Why doesn't the page turning work for iPhone users?

*The product uses a hidden touch "Zoom Protocol" for page turning for Beta introduction. No semi-transparent assistive touch appears on the screen.
*Android users can use it directly without any settings.
Dis semi-transparent assistive touch appears on the screen)

1.Go to 【Settings】→【Accessibility】→ 【Zoom】on your phone.
2.Turn on 【Zoom】
※If the screen zooms in, double-tap the screen with three fingers to resume.
3.Setting completed and you can turn pages, up and down, left and right.

Settings Accessibility Zoom

en

Specifications

Product Name	U-Timer
Weight	15g
Dimensions	35mm x 35mm x 15.9mm
Main Material	ABS
Pairing Name	UT01
Wireless Range	10m
Battery Capacity	3.7V/200mAh, 0.74Wh
Theoretical Standby Time	Approx. 1 year
Theoretical Single Press Runtime	More than 100,000 presses
Charging Port	Type-C (Support charging and using at the same time)
Output Power	5V 0.5A
Operation Temperature	0 ~ 40℃

Note:
*The data is based on Ulanzi laboratory testing.
*Actual runtime may reduce due to environment, intervals, or connection states. Data comes from Ulanzi laboratory testing.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.These limits are designed to provide reasonable protection against harmful interference in a residential installation.This equipment generates,uses and can radiate radio frequency energy and,if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.However,there is no guarantee that interference will not occur in a particular installation.If this equipment does cause harmful interference to radio or television reception,which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution:Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.
This device complies with part 15 of the FCC Rules.Operation is subject to the following two conditions:1)This device may not cause harmful interference,and 2)this device must accept any interference received,including interference that may cause undesired operation.
RF Exposure Information:
The device has been evaluated to meet general RF exposure requirement.The device can be used in portable exposure condition without restriction.

en

はじめに

お買い上げいただき、誠にありがとうございます。

重要なお知らせ

この取扱説明書をよくお読みください。
取扱説明書は大切に保管してください。 製品を他の人に渡して使用させる場合は、必ずこの取扱説明書を添付してください。
すべての警告に注意し、取扱説明書の指示に従ってください。

⚠ 警告

- 取扱説明書、特に注意事項をよくお読みください。誤った操作による製品の損傷については、当社は一切の責任を負いかねます。
- 本書に規定された使用環境・保管環境下でご使用ください。それを満たさない場合、規定外の使用とみなします。
- 本書の記載内容は、当社の最新なテストに基づいて作成されています。設計及び仕様は予告なく変更することがあります。

注意事項

- 本製品を腐食性化学物質のある場所に置かないでください。腐食により製品が損傷し、故障の原因となる可能性があります。
- 本製品をご自身で分解しないでください。
- 本製品に規定以上の電圧・電流を供給しないでください。動作異常や損傷の原因となります。
- 本製品は0～40℃の環境下で使用してください。

ja

リモコンボタン操作ガイド

⚠ 以下の操作は、Bluetooth接続が確立されてから利用しただけます。
1.写真を撮影します。
2.カウントダウン/連続撮影を中止します。
3.撮影モード/リーディングモードを切り換えます。

機能キー	キー機能	操作方法	注意事項
	リモコンの電源をON/OFFします	長押し2秒	電源ON後、Bluetoothは自動的に起動します
	写真を撮影します	シングルクリック	/
	カウントダウン/連続撮影を中止します		カウントダウン/連続撮影中
	撮影モードとリーディングモードを切り換えます	ダブルクリック	/
	カウントダウンと連続撮影機能を切り換えます	シングルクリック	撮影モード中のみ有効
	画面をZ/Tにスクロールします		リーディングモード中のみ有効
	画面を左右にスクロール、または中		リーディングモード中のみ有効

リモコンインジケーターの説明

1.Bluetooth接続インジケーター バッテリーインジケーター

常時点灯	Bluetooth接続済み
ランプ点滅	Bluetooth接続待機中 / 切断済み
白灯	バッテリー残量十分（80%以上）
赤灯	バッテリー残量不足（20%以下）

*充電中
充電中（通常電源）：赤灯
満電：白灯

2.撮影機能の選択 & リーディングモード

アイコンの白灯が常時点灯	該当モード選択中
アイコンの白灯が点滅	撮影のカウントダウン中（撮影キャンセル）

待機状態とインタラクション

- 待機状態に入って：電源投入後：30分間使用しない場合
  - 待機状態に入ってから1時間以内に、シャッターボタンをシングルクリックすると撮影が開始されます。
  - 待機状態ではBluetoothが切断されますが、撮影を起動すると自動的に再接続されます。
- 自動電源オフ：待機状態開始後1時間
  - 待機状態に入ってから1時間以内にBluetoothリモコンが一切操作されない場合、リモコンは自動的に電源が切れます。
  - 電源を切った後、電源ボタンを長押ししてリモコンを再起動してください（接続済みのBluetoothデバイスは自動的に再接続されます）。

ja

梱包リスト

Bluetooth接続操作（初回接続）

❶ シャッターボタンを長押しして電源を入れ、Bluetoothがオンになっていることを確認してください（左上のインジケーターが点滅）。

ja

❷ お使いのスマートフォンのBluetoothをオンにし、デバイス名「UT01」を選択してください。

❸ ポップアップの指示に従って、ペアリングと接続を完了させてください。

ja

❹ 左上のBluetoothインジケーターが常時点灯に変われば、接続成功です。

U-Timerのボタンについて

❶ 撮影モード（0s/3s/5s/10s/ 🔍連写）
❷ リーディングモード [ ]

❸ Bluetooth/バッテリー/充電インジケーター
❹ 2.電源/シャッターボタン切替ボタン
❺ 4.Type-C充電ポート
❻ カウントダウン切替 / ページ送りボタン
❼ スピーカー穴
❽ ストラップ穴

ja

FAQ

1.リモコンで新しいデバイスを切り替える方法

1.リモコンとスマートフォンのBluetooth接続を切断してください
方法 1：Bluetoothペアリングを解除する
1.スマートフォンのBluetooth設定を開きます。
2.「自分のデバイス」リスト内の「UT01」の右側にある設定メニューをタップします。
3.「このデバイスの登録を解除」を選択します。
4.表示されるポップアップで「デバイスの登録を解除」を確認をタップします。
5.ペアリングの解除に成功すると、リモコンの白色ランプが点滅します。

方法 2：以前接続したスマートフォンのBluetoothをオフにする
1.以前接続したスマートフォンのBluetooth機能をオフにします。
2.デバイスのBluetoothが切断されると、リモコンの白色ランプが点滅します。

2.新しいデバイスに接続してください。操作方法は「Bluetooth接続操作（初回接続）」と同じです。

iPhoneユーザーでページ送り機能が反応しない場合

*本品のページ送り方式は、試作版を用いるため、機種によって未適応のケースがございます。当社ではiPhoneでのページ送りに対応しているモデルのみ、Android機器ではすべて対応しております。
*iPhoneの機種では追加設定が必要です（機種によって未適応のポイントが表示されるケースもございます）。

ja

1.iPhoneの「設定」→「アクセシビリティ」→「ズーム」を開きます。
2.「ズーム」をオンにします。
＊注記：オンにした後、画面が拡大表示された場合は、3本の指で画面をダブルタップすると元のサイズに戻ります。
3.これで設定は完了です。上下左右のページ送りが正常に行えるようになります。

設定 アクセシビリティ ズーム

ja

製品仕様

製品名	U-Timer
重量	15g
寸法	35mm x 35mm x 15.9mm
主要材質	ABS
Bluetoothデバイス名	UT01
Bluetooth通信距離	10m
電池	3.7V / 200mAh / 0.74Wh
理論上の待機時間	約1年
理論上のシャッター耐久性	約2万回
充電ポート	Type-C（充電しながらの使用可）
入力功率	5V 0.5A
使用温度範囲	0 ～40℃

*UT01 Ulanzi 測定値で、はの実際のケースに変わります。
*実際の使用時間、間隔、連続状態によってバッテリー残容時間は減少する場合があり、これは正常範囲です。データはUlanzi研究所による測定です。

ja

CN: 请按照说明进行操作，以确保安全使用本产品。请勿将本产品暴露在极端温度或湿度环境中。
UK: Please follow the instructions for safe use and avoid exposing it to extreme temperatures or humidity.
DE: Bitte befolgen Sie die Anweisungen zum sicheren Gebrauch und vermeiden Sie es, das Gerät extremen Temperaturen oder Feuchtigkeit auszusetzen.
FR: Veuillez suivre les instructions pour une utilisation sûre et évitez de l'exposer à des températures ou à une humidité extrêmes.
IT: Seguire le istruzioni per garantire la sicurezza ed evitare di esporlo a temperature o umidità estreme.
ES: Siga las instrucciones para garantizar un uso seguro del producto y evite exponerlo a temperaturas extremas o humedad.
NL: Volg de instructies voor veilig gebruik en vermijd blootstelling aan extreme temperaturen of vochtigheid.
PL: Należy postępować zgodnie z instrukcjami dotyczącymi bezpiecznego użytkowania i unikać wystawiania go na działanie ekstremalnych temperatur lub wilgotności.
SE: Följ anvisningarna för säker användning och undvik att utsätta den för extrema temperaturer eller fukt.
JP:本製品を安全に使用するために、指示に従ってください。本製品を極端な温度や湿度にさらさないでください。