# Interactive all-in-one machine

# Instruction Manual

# Directory

1. System description ..... 1
1.1. System home page ..... 1
1.1.1. Desktop editing function introduction ..... 1
1.2. Sidebar ..... 4
1.2.1. Function introduction ..... 4
1.2.2. Shortcut operation ..... 5
1.2.3. Sidebar widget ..... 8
1.3. Apply the quick open mode ..... 26
1.3.1. Home page application ..... 26
1.3.2. More applications ..... 26
1.4. Status bar ..... 28
2. System Settings ..... 29
2.1. Wireless and network ..... 29
2.1.1. Ethernet ..... 29
2.1.2. WI-FI ..... 30
2.1.3. Hot spot ..... 30
2.1.4. Bluetooth ..... 31
2.2. Personal ..... 31
2.2.1. Screen Saver ..... 32
2.2.2. Eye Protection Mode ..... 32
2.2.3. Suspension ball tool ..... 33
2.2.4. Hidden navigation bar ..... 33
2.2.5. Custom gestures ..... 33
2.3. Input and Output ..... 34
2.3.1. Sound: ..... 34
2.3.2. Equipment management: ..... 34
2.3.3. Source Settings: ..... 34
2.3.4. HDMI Settings: ..... 35
2.4. System ..... 35
2.4.1. Date time: ..... 35
2.4.2. Language and keyboard: ..... 36
2.4.3. E-mail: ..... 36
2.4.4. Region: ..... 36
2.4.5. Storage Manage: ..... 37

2.4.6. Startup and Shutdown Settings: ..... 37
2.4.7. System Update: ..... 38
2.5. Safe ..... 38
2.5.1. App lock ..... 38
2.5.2. Screen lock password ..... 39
2.5.3. Apply the lock password ..... 39
2.5.4. Unknown source ..... 39
2.6. About ..... 40
3. Software description ..... 41
3.1. Palette ..... 41
3.2. Welcome page ..... 41
3.2.1. Interface description ..... 41
3.2.2. function declaration ..... 42
3.3. Note ..... 46
3.3.1. Interface display ..... 46
3.3.2. Menu ..... 47
3.3.3. Basic operation ..... 54
3.4. Browser ..... 64
3.5. Keeper ..... 65
3.6. File browsing ..... 69
3.6.1. Interface introduction ..... 69
3.6.2. Display mode ..... 69
3.6.3. Tool bar ..... 71
3.6.4. Expand the menu ..... 72
3.7. Screen Share ..... 74
3.7.1. Application instructions ..... 74
3.7.2. operation declaration ..... 74
3.7.3. File sharing ..... 75
3.7.4. Application Settings ..... 76
3.8. Cloud Drive ..... 77
3.9. OPS Settings ..... 79

# 1. System description

## 1.1. System home page

After the startup is complete, the main interface will be entered by default, as shown in the following figure:

### 1.1.1. Desktop editing function introduction

Hold down a blank position on the home page for 5s to enter the desktop editing mode. You can switch wallpapers, switch templates, and drag components to customize layouts.




热点: AndroidAP_7644 密码: kpf7ir2a
02:12
12-06-2024 PM Friday
Search...
Note
Welcome
Browser
Settings
Component
Wallpaper
Template


热点: AndroidAP_7644 密码: kpf7ir2a
02:12
12-06-2024 PM Friday
Search...
Note
Welcome
Browser
Settings
Component
Wallpaper
Template

Pull up the desktop editing menu to enter the category menu, pull down to enter the preview state, click "Finish" to finish the desktop editing, click "Cancel" to exit the desktop editing.



# 1.2. Sidebar

## 1.2.1. Function introduction

The sidebar is divided into left and right sidebars, click on the ICONS / that hover on the left/right side of the screen to bring up the sidebar. The function buttons are Return, Home, Task process, Gadgets, Applications, Bluetooth, WIFI, Hot spot, Wired network, Brightness progress bar and Volume progress bar, Menu, Power, Channel list..

### 1.2.2. Shortcut operation

1) Return

Click the icon to return to or exit the current program.

2) Home page

Click the icon to enter the main screen.

3) Task process

Click the icon to enter the process management screen. You can choose to enter or close the application.

① If no application process is running in the background, no application is displayed.

② If there are multiple application processes in the background, touch the process list area and swipe left and right to view the application process.

a. Touch the process thumbnail and swipe left or right until you are out of the process list area. Release the thumbnail to close the application process.

b. Touch the process thumbnail to enter the application process.

c. Click the X button to clean up all background.

4) Menu

Click the icon to enter the main menu interface.

The menu options are: Audio, Screen, Display and Adjust you can also select some specific scene mode, such as meeting mode, classroom mode or custom mode.



5) Power

Click the icon to enter the shutdown, pause screen, restart selection screen.

6) Source list

Click the icon  to enter the source list interface.



### 1.2.3. Sidebar widget

Click sidebar widget with Mark, Split screen, Camera, Fast file transfer, Record, Crop, Timer, Screen lock , Stopwatch, Freeze, PollKit, Calendar, Touch Overlay, Calculator, Mini Player, Weather, Pip, Spotlight, Prompter, Curtain, Random Pick, Scoreboard, you can also directly open Bluetooth, WIFI, Cable network, Hot spot.

Long press any icon to drag the tool ICONS to customize the sort or reset of these tools.

1) Mark

Click the icon

to open the Mark.

**Toolbar**




**Instructions:**

① Click the icon

to enter the brush mode, and click again to call up the Write menu to set the color and size of the brush

.

② Click the icon

, switch back to the selection mode, need to save the annotated content, the floating bar will not disappear.

③ Click the icon

to highlight the content.

④ Click the icon

to clear all comment traces from the interface.

⑤ Click the icon

to save the current comments to a PNG file.

⑥ Click the icon 

to bring up the app bar.




a. Click the icon

to open the folder and go directly to the comment file saving directory, as shown in the figure.




b. Click the icon 

to insert the current comments into the whiteboard application, as shown in the figure.

c. Click the icon

to generate the two-dimensional code. Users can scan the code to download the current comment file or share the file by sharing the two-dimensional code.

d. Click on the icon

to bring up the list of cloud drive accounts. You can upload the current comment file to the cloud disk. If the list is empty, click to add cloud disk account.




2) Split screen

Tap the icon  to enter the Split screen,, two applications can be displayed at the same time, and the application that supports the split screen mode will be prompted. Tap in to close the current area application, and tap to exchange the area displayed on the two application interfaces.




3) Camera

Click the icon to take a picture and display the camera interface.

4) Fast file transfer

Click the icon 

to open the fast file transfer tool, and the two-dimensional code will be generated for users to scan the code and upload the file.




5) Record

Click on the icon 

to appear 

, and move the position by touching and dragging.

a. Click the icon

to set the resolution and path for saving the screen recording, as shown in the figure:




b. Clicking will start recording when the 3-second countdown ends.

Click to pause the recording, click after the pause to continue the recording, click will expand into

, click again will collapse , click to end the recording and save, after saving will prompt whether to open the file to view.




c. Click

to exit the screen recording tool.

6) Crop

Click the icon

to enter the screenshot mode, drag the position and size of the screenshot box by touching it, click

to save the screenshot (it will prompt you to view the saving path), or click

to cancel the screenshot. Click

the box to select the entire screen, click

will insert the screenshot in the shortcut whiteboard operation editing.

7) Timer

Click the icon

to enter the Timer function, set the countdown time by touching and sliding, click "Start" to countdown, and ring a bell to remind you when it is over.




8) Screen lock

Click the icon 

to lock the screen, you need to set the screen lock password, and you need to enter the screen lock password to wake up the screen after opening.

9) Stopwatch

Click the icon

to enter the stopwatch tool. Click the icon Start to start timing. Click ✕ to close the timer tool.




After starting the timing, you can pause the timing Pause, or count the number of times Lap. After the pause, you can continue the timing Continue or retry the timing Reset.



10) Freeze

After clicking the icon

, the current interface remains unchanged. You can zoom in and out to view the current interface.

11) PollKit

Click the icon

to enter the voting setting, and the quick mode sets the number of options by touching and dragging the number. There are two functions to be selected: whether anonymous or whether multiple selection. After setting, the voting two-dimensional code can be generated, and users can vote by scanning the code. The advanced mode generates a QR code to set more options.

12) Calendar

Click the icon

to enter the calendar tool, you can view the perpetual calendar.




You can also view and create new to-do items + New , and select the time by touching the date to set the time.




13) Touch Overlay

Click the icon to enter the Touch Overlay, click the icon in the lower left corner to lock, and touch the lock after locking. At this time, touching other places is invalid, click again to restore the touch. Note: This icon is automatically hidden and will appear when you click anywhere on the screen.

14) Calculator

Click the icon

to go to the calculator tool.

15) Mini Player

Click the icon

to enter the player page.

Then click OPEN File file, you can open the local or U disk file for playback.

16) Weather

Click on the icon

to view the weather, the weather in your area.




17) Pip

Tap the icon 

to open the picture-in-picture function.



18) Spotlight

Click the icon

to turn on the spotlight function. Click the icon below

to adjust the zoom and transparency.



19) Prompter

Tap the icon

to open the prompter function.




20) Curtain

Click the icon

to open the screen function, click the icon

to set the screen color. On the curtain, "slide left", "slide right", "slide from the middle to both sides" and "slide from both sides to the middle" can realize different opening and closing modes of the curtain.



21) Random Pick

Click on the icon 

to open the Random Pick.






22) Scoreboard

Click on the icon

to open the Scoreboard function.




# 1.3. Apply the quick open mode

## 1.3.1. Home page application

Click on the desktop icon to quickly enter the application interface.




## 1.3.2. More applications

Click the icon 

, pop up more application interface, contains Browser, Cloud Drive, Files, Keeper, Note, OPS Settings, Palette, Screen Share, Settings, Welcome, these applications will be detailed in software instructions, the user can view in this interface or open the system application.

You can create a shortcut by touching and dragging the application icon to the sidebar. Dragging the application icon in the sidebar prompts you to delete the shortcut. Click the prompt to delete the application shortcut and create a new one.



## 1.4. Status bar

The status bar is in the upper right corner of the main interface. Display the current network status of the machine, which can also be used as a shortcut entrance for Hot spots, Wireless network (WIFI), Bluetooth and Ethernet, as shown in the figure:

(1) Click : Enter the Hot spot setting interface. The icon can also indicate the status of the hot spot switch, which is currently on.

(2) Click : Enter the WIFI setting interface, and the icon can also indicate the WIFI connection status, which is not currently being connected.

(3) Click : Enter the Bluetooth Settings interface, and the icon can also indicate the Bluetooth connection status, but it is currently not connected.

(4) Click : Enter the Ethernet Settings interface, the icon can also indicate the Ethernet connection state, currently not connected.

# 2. System Settings

System Settings mainly include Wireless and Network, Personal, Input and Output, System and other functions.

## 2.1. Wireless and network




### 2.1.1. Ethernet

Set Ethernet function on or off, can automatically obtain IP address or manually set Ethernet information such as IP and gateway.



### 2.1.2. WI-FI

Set the WIFI switch status and automatically display the available network after opening.




### 2.1.3. Hot spot

Set the hot spot on or off, you can configure the hot spot name and password.



### 2.1.4. Bluetooth

Set whether Bluetooth is visible to other devices, also rename the Bluetooth device or view the received files, and connect to the device in the list of available devices.




## 2.2. Personal



### 2.2.1. Screen Saver

You can set the default screensaver or add a custom custom screensaver picture.




### 2.2.2. Eye Protection Mode

You can choose ordinary eye protection mode or paper eye protection mode.



### 2.2.3. Suspension ball tool

Two fingers out of the suspension ball, can be a series of quick operations including Home, Back, Note, Setting, etc., can also be customized added, as shown in the figure below.




### 2.2.4. Hidden navigation bar

Hide the navigation bars in all of the channels.

### 2.2.5. Custom gestures




① Five fingers long press: can set the shortcut operation to open the home page, return, screenshot, screen out.

② Five fingers left slide: can set the shortcut operation to open the home page, return, screen capture, screen out, application switch.

③ Five fingers slide right: can set the shortcut operation to open the home page, return, screenshot, screen out, application switch.

④ Five finger grasp: can set the shortcut operation to open the home page, return, screen capture, screen out, multi-task.

⑤ Five fingers slide: can set the shortcut to open the home page, return, screen, screen out, half screen.

## 2.3. Input and Output




### 2.3.1. Sound:

a. Touch sounds can be turned on or off.

b. Set the audio output: Speaker, LineOut, Mixed.

### 2.3.2. Equipment management:

a. Microphone

### 2.3.3. Source Settings:

a. Turn on or off Auto Source Change.

b. Source alias name: You can set the source alias name.

c. No signal power off: select off, power off, screen off, and return channel.




### 2.3.4. HDMI Settings:

HDMI OUT Format 1920 * 1080p@60Hz with 3840 * 2160p@60Hz is optional.

## 2.4. System




### 2.4.1. Date time:

Optional whether to display in 24 hours format, optional whether the system will automatically synchronize the date and time when connected to the Internet, and can set the date format and time zone.




### 2.4.2. Language and keyboard:

Set the system language, switch the input method, virtual keyboard and physical keyboard options.




### 2.4.3. E-mail:

Email accounts can be added.

### 2.4.4. Region:

Select the use country region.

### 2.4.5. Storage Manage:

View internal storage usage, and you can also view running memory usage.




### 2.4.6. Startup and Shutdown Settings:

Startup Auto, Shutdown Auto, Screen Saver, Timing switch.

a. Can set the boot default channel.
b. Automatic shutdown and shutdown action can be set without operation time.
c. You can set the screensaver time and screen saver types.
d. A start / shutdown task can be added.



### 2.4.7. System Update:

The latest upgrade package can be detected for the upgrade.




## 2.5. Safe




### 2.5.1. App lock

After opening, the device lock, remote lock, touch lock, keyPad lock, setting lock and USB lock can be used. After setting, enter the set password for the corresponding device.




### 2.5.2. Screen lock password

After setting it up, going to the large screen will display the password.

### 2.5.3. Apply the lock password

Application lock password is an application that encrypts each application and sets the password. You need to enter the password before entering the application.




### 2.5.4. Unknown source

Set up whether to allow the installation of applications from an unknown source.

## 2.6. About

You can view some device version information and legal information, or choose to restore the factory settings.






# 3. Software description

## 3.1. Palette

New application of palette.




## 3.2. Welcome page

### 3.2.1. Interface description

Click the sidebar (left and right) -> Click All apps 

-> Click the icon 

to enter the app. Click the icon to enter the app home page as shown in the picture. The main interface is divided into custom, birthday party, media, text.




### 3.2.2. function declaration

Preview the open template picture in the main interface for edit:

① Click on the icon to enter the edit mode.




a. Click the icon to set the background picture and upload it locally, as shown in the figure:




b. Click the icon to set the text template, can not customize the text template, you can add text.




c. Click on the icon to edit the text and customize the text content.




d. Click and the icon to zoom in or out of the text font edited in the previous step.

e. Click the icon to make bold version of the edited text.

f. Click the icon to customize the color of the edited text, as shown below:




g. Click the icon to align the left, right and center of the edited text.

h. Click and icons can do and restore unsaved operations.

i. Click on the icon to save the template theme.

j. Click on 

the icon to exit the topic edit to return to the template.

② Click on the icon to take a picture, you need a free camera.

③ Click on the icon to automatically play the slide show.

④ Click on the icon to play the music, and you can upload up to 3 pieces of music locally.

# 3.3. Note

## 3.3.1. Interface display

Click the whiteboard writing icon  on the main interface to start the whiteboard software. The default whiteboard brush tool is selected and can be written directly.



### 3.3.2. Menu

Click the icon in the lower left corner of the interface to pop up and display the lower content menu:




Menu content function description:

1) New: Click the icon

to create a new whiteboard interface. When the previous interface is not saved, it will prompt whether to save it. The new interface can perform editing, saving and other operations.

2) Open: Click the icon 

to open the file under the save whiteboard file directory. Clicking the file to open directly, and can edit again, save and other functions.



3) Save: Click the icon 

to save the current written content, the default time name save, the user can customize the name save, the user can choose built-in storage or U-disk save.




4) Save as: Click the icon 

, that is, save as, and the save function, just save as another file.

5) Import: Click the icon 

, select the file format to import, and then select the path of the file to be imported to confirm the import.




6) Export: Click the icon 

, select the file format you want to export, and then select the path to export the file to save, you can customize the named save.




7) Cloud disk: Click the icon 

, select the type of cloud disk to use, and then you can upload it to the cloud disk.






8) Topic: Click the icon 

to set the template and background, as shown in the figure:




9) Send email: Click the icon 

, the current whiteboard content will be saved and sent through email, need to set the administrator user email address.




10) Settings: Click the icon 

to set the eraser mode, open the multi-finger writing, and open the automatic brightness adjustment and custom toolbar.






11) Custom toolbars: unless some tools are locked in the toolbar, set whether other tools are locked in the toolbar.




12) Exit: After clicking the icon

, you will exit the whiteboard application. If there is any unsaved content, you will ask whether to save it, and then directly return to the main interface.

13) Share: After clicking the icon

, the current whiteboard content will be exported and generate the QR code. You can download the whiteboard file. Users can share the QR code to share the whiteboard file. This function needs to be connected to the Internet.




14) List: Click the icon

to enter the file list. In the current interface, you can create a new file, rename the existing file, view the path, and delete the file.



### 3.3.3. Basic operation

In addition to basic functions such as Select, Pen, Eraser, Clean All, Ruler, Shape, Partition, Table, Browser, Mind map, Globe and more.

1) Select

Click the icon

to enter the selection mode from the writing mode, which can realize the movement, color, beautification, formula, search, flip, top, clone, delete, rotation and zoom functions in the interface. For the mathematical formula, the formula OCR can be selected to select the generated function diagram.









2) Pen

Click the icon

to enter the writing mode, which is also the default mode after the application is opened. Click again to select the pen type, color and thickness, and click the icon to expand the color palette to customize the brush color.




3) Eraser

Click the icon

to enter the eraser mode. Touch to erase the writing content, and click the icon again to adjust the size of the eraser range.




4) Clean all

Click the icon

to completely clear the writing content and shape of the current page. If you want to restore the cleared content, you can click the icon

to cancel the clear operation.

5) Rule

Click the icon

, you can choose the type of the long ruler, the right triangle ruler and the protractor, the ruler scale edge can draw a straight line and have a length display, the protractor can measure the Angle and draw the Angle of any Angle.




6) Shape

Click the icon

, in the whiteboard interface through touch drag to draw the standard graphics, click again to choose the graphics shape, can also switch plane graphics and stereo graphics, but also can customize the color. Click on the icon
can be drawn according to their own rough shape for intelligent beautification, into a neat figure.




7) Partition

Click on the icon

to set it up as the multi-player writing function.



8) Table

Click the icon

, touch and drag to select the table size, and click the icon Insert to insert the table.

Click the icon

to enter the selection mode to drag and edit the table.






9) Browser

Clicking on the icon

opens the browser on the current page.




10) Mind map

Clicking on the icon

inserts an initial brain map into the current page, and editing it by clicking on a node can form a mind map.

Click to add a child node in the current node direction. Click will appear a delete query, and the confirmation can delete the current node.




11) Globe

Click on the icon

to view the 2D globe.




12) Sticky-Notes

Click the icon

to enter the note editor, enter the note content through the soft keyboard, select the color of the note on the side , and click

to

successfully add the note.







13) Preview

Click the icon

to enter the Preview, and zoom the size of the whole page (overall) and move it easy to browse.

14) Grid

Click the icon

to insert the Grid, automatic beautification in the four lines of writing, only support English beautification.




15) Star

Click on the icon

to play the trajectory of the planet.



16) Periodic

Click the icon

to view the periodic table of chemical elements, drag or double-click the element to synthesize the compound.

17) Results the recovery

Click the icon

to cancel the operation before not save, can be revoked many times, when you want to withdraw back many times can click the icon

to restore the cancellation operation, similarly, can be restored multiple times.

18) Add pages

When we want to add a page, click the icon

to add a new page and cut the current interface to the new page.

19) Page selection

When there are multiple pages, you can click

and

the icon to switch the page, or click 

to view all the page thumbnail, select a page thumbnail to switch or delete.




## 3.4. Browser

Click on the main interface icon 

to enter the browser app.



# 3.5. Keeper

Click the sidebar (left and right) -> Click All apps 

-> Click the icon 

to enter the app. Click the icon to enter the app home page as shown in the picture




Click on the home page icon is as follows.

Click on the app icon to display as:




Click on the icon to see the version information.

Click on it to automatically clean up the useless files.




Click one click to optimize memory and clean up garbage.




Click on the network icon to view the network status and then click on the network.



Click on the network speed measurement will show the current network fluctuations.

Clicking the peripheral icon will display as follows, with a sensor device.



# 3.6. File browsing

## 3.6.1. Interface introduction

Click the icon

to enter the file browsing application, enter the left side of the file browser to display the local file, cloud hard disk.




## 3.6.2. Display mode

1) Classify:

The above column 

can classify the contents of the current directory by format and display.

① When clicking "Doc", the main contents are: Word, Excel, PDF, TXT files;

② When clicking "Note", mainly display ENB or JPG files;

③ When clicking the "Picture", display the picture format files, such as PNG, JPG, etc.;

④ When clicking "Media", the audio (MP3) video (MP4) format file is displayed;

⑤ When clicking "Apk", display the application files, such as APP, APK, etc.;

⑥ When clicking "Zip", the file of the compressed package class is displayed.

2) Sort:

Click on the icon

to sort the files by name, type, size, and time.




3) Grid:

Click the icon

, the file in the grid tile display;




4) List:

Click on the icon

, and the file is displayed as a list.




### 3.6.3. Tool bar

1) Renovate:

Click on the icon to refresh the file content.

2) Search:

Click on the icon to enter the file name and search for the file under the current directory.




3) New:

Click the icon New to create a new folder.as shown in the figure:




4) Withdraw from:

Click the icon Exit to exit the file browsing.

### 3.6.4. Expand the menu

Click the icon Select to perform file operations on the file.as shown in the figure:




① Click the box in the upper right corner of the folder to indicate that the file is selected.

② Click the icon Select All to select all of the current directory files, as shown in the figure:




③ Click the icon Cancel to deselect selected content.

④ Click the icon Copy to copy the selected file to the paste board.

⑤ Click the icon Cut to cut the selected file to the paste board.

⑥ Click Paste to paste the contents of the Paste board into the current directory

⑦ Click the icon Delete to delete the contents of the selected files

⑧ Click the icon Rename to rename the selected file (only one selected at a time), as shown in the figure:




# 3.7. Screen Share

## 3.7.1. Application instructions

The main function of the application is: project the content of mobile phone, tablet or computer to the conference all-in-one machine, and truly realize the function of wireless transmission of the projection device and the projected device (Note: mobile phone, tablet or computer should be on the same LAN with the conference tablet).

## 3.7.2. operation declaration

Click the main interface icon 

to enter the main application interface, as shown in the figure:




1) After the phone or tablet is connected, scan the code to download the client and install it.(IOS system can not install the client) the computer to download and install the screen transfer assistant client according to the download address.

2) After installation, the device uses the same network as the all-in-one machine. The Android phone can open the screen transmission assistant and scan the QR code to cast the screen, the iPhone can open the AirPlay connection device to also pass the screen, and the computer can input the screen transmission code to successfully pass the screen.

### 3.7.3. File sharing

Click the icon to enter the file sharing interface. You can share the file to the connected device. Click the icon to upload the local file.



### 3.7.4. Application Settings

Click the icon to expand the setting box, you can open and close the screen code display, device visible, intelligent full screen function, but also can problem feedback and view about the application.as shown in the figure:









## 3.8. Cloud Drive

Click the sidebar (left and right) -> Click All apps 

-> Click the icon

to enter the app. First, it will show that the cloud disk has been added. If there is no cloud disk, you can add the cloud disk account.




Click the icon

to add a cloud disk account, and you will prompt you to

select the cloud disk type.




After selecting the appropriate type, enter the account password to verify the login.

## 3.9. OPS Settings

This function needs to be matched with the source control OPS, click the sidebar (left and right) or click all the applications 

, and click the icon 

to enter the application. After opening, it will automatically pull the application list in the OPS computer. Users can tick the application they want to open and display the corresponding application in the whole application list on the Android terminal, and can open the corresponding application under the Android.






**FCC Statement**

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference receiv ed,including interference that may cause undesired operation.

Caution: Changes or modifications not expressly approved by the party responsible for Compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, p ursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against h armful interference in a residential installation. This equipment generates uses and can radiate radio freq uency energy and, if not installed and used in accordance with the instructions, may cause harmful interfe rence to radio communications. However, there is no guarantee that interference will not occur in a partic ular installation. If this equipment does cause harmful interference to radio or television reception, which c an be determined by turning the equipment off and on, the user is encouraged to try to correct the interfer ence by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help important announcement .

Radiation Exposure Statement

To comply with FCC RF exposure compliance requirements, this grant is applicable to only mobile configurations. The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.