ARM NEXT®

MODEL: W1 BT ADAPTER



USER MANUAL

❶ DIAGRAM

Push the plug side harder.
Make sure the plug is fully
inserted into the socket.



Check that the adapter buckle is fully attached to the ear pad ringbase.



❷ INSTRUCTIONS FOR USE

1. Press and hold for power on/power off.



2. After turn on, searching for “W1 adapter” click for connecting.



3. The adapter will flash blue light when working . if it flash red light, it means the battery is low. you will also hear "battery low" while using it.



LED	Working
☀	Blue Light Every 3 Seconds

4. The device will connect to the adapter automatically if it has been connected before.

Turn off the bluetooth for connecting another device.

5. Sigle click - Play Pause.

Click twice - Activating Voice Assistance.



6. Type C cable for charging. (Included)



❸ QUICK CHARGEING GUIDE

LED		
	Blink Red	Charing
	Stay Blue	Charing Completed
	No Light	Charing Failure

※ *If No light while charing, please contact retailer.*

WARNING:

The battery can not be charged when it is extremely cold or hot.

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception,
which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.