Find it: Menu > **Settings** > **Call settings** > **Additional settings** > **Call waiting**

Restrict outgoing calls

To restrict your phone so that it can only dial a few numbers:

Find it: Menu > **Settings** > **Call settings** > **Fixed Dialing Numbers**

- To turn fixed dialing on, touch **FDN activation**.
- To add or delete the allowed numbers, touch **FDN list**.

Cool down

In very limited circumstances, such as where your phone has been exposed to extreme heat, "Cool Down" message screens will appear. To avoid possible damage to your battery and phone, you should follow these instructions until the phone is within its recommended temperature range. When your phone is in "Cool Down" mode, only emergency calls can be made.

Emergency calls

Note: Your service provider programs one or more emergency phone numbers (such as 911 or 112) that you can call under any circumstances, even when your phone is locked. Emergency numbers vary by country.

DRAFT - MOTOROLA CONFIDENTIAL & PROPRIETARY INFORMATION

Your pre-programmed emergency number(s) may not work in all locations, and sometimes an emergency call cannot be placed due to network, environmental, or interference issues.

1 Open the phone, then touch **Dialer** (if your phone is locked, touch **Emergency Call**).

2 Enter the emergency number.

3 Touch **Call** to call the emergency number.

Note: Your mobile device can use AGPS satellite signals to help emergency services find you ("GPS & AGPS" on page 65).

DRAFT - MOTOROLA CONFIDENTIAL & PROPRIETARY INFORMATION

Contacts

contacts like you've never had before

Quick start: Contacts

Find it: **Contacts**



Contacts List
Touch - open.
Touch & hold - call, text & more.

Tip: To search the list, type a name. When you flick or drag the list, drag the scroll bar that appears to move the list faster.

Import contacts from your SIM

If you need to import the contacts from your SIM card, touch **Contacts**, then touch Menu > **Import/Export > Import from SIM card**.

View, edit or delete contacts

Find it: **Contacts**

To **View contact**, **Add to favorites, Text contact** or **Call contact**, touch and hold the contact.

Create contacts

Find it: **Contacts** > Menu > **New contact**

Touch any entry area to open the touchscreen keyboard.

When you're finished, touch **Done**.

DRAFT - MOTOROLA CONFIDENTIAL & PROPRIETARY INFORMATION

Messaging

sometimes it's best to text or email...

Quick start: Messaging

Find it: > **Messaging**



Create a message

Message List
Touch to open a message. Touch & hold to delete, and more.

Tip: To see more messages, flick or drag up.

Read & reply to messages

- To open a message and all of its replies, touch it.
- To respond to a message, just open it and enter your response in the text box at the bottom.
- To open options, touch the checkbox next to the message.

MOTOROLA CONFIDENTIAL
INFORMATION

Create messages

Find it: > **Messaging** > **Compose New Message**

Enter the recipient and message. Touch Menu for options like **Insert smiley** or **Attach**.

Send & receive attachments

To send a file in a message, open a new message and touch Menu > **Attach**.

When you receive a message with an attachment, open the message and touch the file name to download it. Then, touch the name again to open it. Some file formats can be converted to HTML for faster viewing, and your phone will show **Get HTML version**.

While viewing the attachment, touch it to save it, share it, and more.

Tip: To send and receive large attachments faster, use a Wi-Fi™ connection, in "Wi-Fi™" on page 52.

Set up messaging

To add email accounts, touch Menu > **Settings** > **Accounts** > **Add account**.

- **Corporate Sync** is for Microsoft™ Exchange server work email accounts. Enter details from your IT administrator.

DRAFT - MOTOROLA CONFIDENTIAL & PROPRIETARY INFORMATION

- **Email** is for most personal and other accounts that aren't on a Microsoft™ Exchange Server. For account details, contact the account provider and for setup see "Email" on page 29.

Email

Set up an account

Find it: > **Email**

The email setup wizard will guide you through setting up your email account. For account details, contact the account provider.

Create a new email

Find it: **Email** > Menu > **Compose**

Enter the recipient email address and message, then touch **Send**.

Tip: Touch Menu for options, like **Attach** or **Add Cc**.

Voicemail

When you have a new voicemail, shows at the top of your screen. To hear the voicemail, touch **Dialer**, then touch .

If you need to change your voicemail number, in the home screen touch Menu > **Settings** > **Call settings** > **Voicemail settings**.

DRAFT - MOTOROLA CONFIDENTIAL & PROPRIETARY INFORMATION

Text entry

keys when you need them

Typing tips

To...	
Enter **alternate** characters	From the number keyboard, touch Alternate ALT. Touch again to return to numbers.
Enter **one capital** letter	Touch Shift ⇧.
Enter **only capital** letters, until you touch Shift ⇧ again	Touch Shift ⇧ twice. Touch again to revert to lowercase.
Cut or **Copy** selected text	Touch and hold text, then touch **Cut** or **Copy**.
Paste cut or copied text	Touch and hold location to paste then touch **Paste**.
Delete a character (hold to delete more)	Touch Delete ⌫.

DRAFT - MOTOROLA CONFIDENTIAL & PROPRIETARY INFORMATION

To change your text entry settings and see the dictionary of terms you've used, from the home screen, touch Menu > **Settings** > **Language & keyboard**.

Text input settings

Find it: Menu > **Settings** > **Language & keyboard**

- To edit your dictionary, touch **User dictionary**.
- To change the language and the style for your touchscreen keyboard, touch **Select language**.
- To change the device keypad settings, touch **Device keyboard.**

DRAFT MOTOROLA CONFIDENTIAL & PROPRIETARY INFORMATION

Tips & tricks

a few handy hints

Shortcuts

To...	
Return to the **home screen**	Touch Home .
See **recently dialed** numbers	Touch **Dialer** > **Call log**.
Sleep/wake your phone	Press Power .
Turn **airplane mode** on/off	Press and hold Power > **Airplane mode**.
Turn phone **sounds** on/off	Press and hold Power > **Silent mode**.
Set **screen timeout**	Touch Menu > **Settings** > **Display** > **Screen timeout**.
Turn **Bluetooth™** power on/off	Touch Menu > **Settings** > **Wireless & networks** > **Bluetooth**.
Turn **Wi-Fi** on/off	Touch Menu > **Settings** > **Wireless & networks** > **Wi-Fi**.

DRAFT MOTOROLA CONFIDENTIAL & PROPRIETARY INFORMATION

To...	
Add a shortcut on your home screen	Touch and hold an open area on your home screen to open the **Add to Home screen** menu, then touch **Shortcuts**. Choose an application, bookmark, or shortcut to add.
Move a shortcut or widget	Touch and hold the shortcut or widget until you feel a vibration, then drag it to where you want.
Delete a shortcut or widget	Touch and hold the shortcut or widget until you feel a vibration, then drag it to the trash at the top of the screen.

DRAFT - MOTOROLA CONFIDENTIAL & PROPRIETARY INFORMATION

Battery tips

Your phone is like a small computer, giving you a lot of information and apps, at 3G speed, with a touch display! Depending on what you use, that can take a lot of power. So, if you want to save battery life between charges, you could reduce:

- recording or watching videos, listening to music, or taking pictures.
-

- Bluetooth™ use: touch Menu > **Settings** > **Wireless & networks** > **Bluetooth** (turn off).
- Wi-Fi use: touch Menu > **Settings** > **Wireless & networks** > **Wi-Fi** (turn off).
- GPS use: touch Menu > **Settings** > **Location & security** > **Use GPS satellites** (deselect).
- network searching: if you are out of coverage, to keep your phone from looking for networks, press and hold Power > **Airplane mode**.
- display brightness: touch Menu > **Settings** > **Display** > **Brightness** > *(dimmer setting)*.
- display timeout delay: touch Menu > **Settings** > **Display** > **Screen timeout** > *(shorter setting)*.

DRAFT MOTOROLA CONFIDENTIAL & PROPRIETARY INFORMATION