FUSION® Apollo™ MS-WB670
Quick Start Manual



DRAFT

ENGLISH

FUSIONENTERTAINMENT.COM

Getting Started

⚠ WARNING

See the *Important Safety and Product Information* guide in the product box for product warnings and other important information.

The Apollo WB670 wired remote control is an optional accessory for compatible FUSION® stereos.

To help you understand how the Apollo WB670 remote control works, this manual contains instructions for using the Apollo WB670 remote control with the Apollo MS-RA670 stereo. The available features and functions of the Apollo WB670 remote control may vary based on the stereo being controlled. For specific information about your stereo, see the stereo owner's manual.

Getting the Owner's Manual

You can get the latest owner's manual and translations of manuals from the web.

1. Go to **www.fusionentertainment.com/manuals/ms-wb670**.
2. Select a manual.

Stereo Keys and Status LEDs

Because this device is designed to be installed in a location that may not be easily accessible, almost all playback and device interaction is done through a connected remote control or stereo. In some instances, you may need to reference the LEDs or press the keys on the device itself.

Stereo Keys

⏻	Press to wake up the stereo Hold together with the ✱ key for more than one second to reset the stereo to factory settings
✱	Press to make the stereo discoverable to BLUETOOTH® devices Hold together with the ✱ key for more than one second to reset the stereo to factory settings

Status LEDs

Icon	LED color	LED Indication
	Green	Solid: the stereo is receiving power
	Green	Blinking: the stereo is booting Solid: the stereo is functioning normally
	Green	Blinking: the stereo is communicating over the FUSION PartyBus™ network
✱	Blue	Blinking: the stereo is discoverable to BLUETOOTH devices Solid: the stereo is connected to a BLUETOOTH device

Controls

NOTE: These stereo controls are available when you use a connected remote control, such as a FUSION ERX400. If you control the stereo using a grouped stereo or a different remote control, you should see the owner's manual for that device for more information.

DRAFT

Dial	• Turn to adjust the volume. • Turn to move through the menus or adjust a setting. • Press to make a selection.
⏻	• Press to turn on the remote control. • Press to mute and un-mute the audio. • Press and hold to turn off the remote control and stereo.
☰	• Press to open the menu. • Press to return to the previous screen from the menu. • Press and hold to exit the menu.
⊕	• Press to select a source. **TIP:** You can turn the dial to browse, and press the dial to select the source.
⏮	• Press to tune to the previous station. • Press to skip to the beginning of the track or to the previous track.
▶II	• Press to pause or resume the current track. • Press to cycle through the tuning modes (auto, manual, and presets).
⏭	• Press to tune to the next station. • Press to skip to the next track.

Naming the Device

You should enter a unique name for this device so you can easily identify it when viewing devices on the FUSION PartyBus network.

1 Select ☰ > **SETTINGS**.

2 Select **DEVICE NAME**, and enter a unique name for the device.

Creating or Editing a Group

Before you can create a group, you must connect multiple compatible devices to the FUSION PartyBus network. See the installation instructions provided with your device for installing and configuring the network.

You can combine compatible devices on the network into groups. Grouped devices can select and play sources from any device in the group, and all grouped devices play the selected source simultaneously. This allows you to experience synchronized audio throughout your vessel. You can also control the volume for any zone from any stereo in the group.

1 Turn the dial to open the volume screen.

2 Press the dial.

3 Turn the dial, and select **Edit Group**.

4 Select the devices you want to add to or remove from the group.

5 Select **GROUP** or **UNGROUP**.

Selecting a Source

1 Select ⊕.

2 Turn the dial to highlight a source.

NOTE: If you have more than one device in a group, continue turning the dial past the end of the available sources to access the sources on other devices in the group (page 3).

3 Press the dial to select the source.

Adjusting the Volume

1 Turn the dial to adjust the volume.

2 If necessary, press the dial to view all zones, and select a different zone.

If you have created a group of stereos, you can control the volume of any zone from any stereo in the group (page 3).

TIP: You can select ALL to control all zones at the same time.

Setting the Home Zone

The home zone is the speaker zone that you adjust by default when you turn the dial. The home zone can be assigned to any speaker zone on a compatible device on the FUSION PartyBus network.

1 Select ☰ > **SETTINGS**.

2 Select **ZONE** > **ASSIGN HOME ZONE**.

3 Select a zone.

DRAFT

Media Player Connection

⚠ CAUTION

Always disconnect your media player from the stereo when not in use and do not leave it in your vessel. This helps reduce the risk of theft and damage from extreme temperatures.

Do not remove the media player or use your stereo in a distracting manner while operating the vessel. Check and obey all marine laws in association with use.

The stereo accepts a variety of media players, including smartphones and other mobile devices. You can connect a compatible media player using a Bluetooth® wireless connection or a USB connection to the USB port. The stereo can play media from Universal Plug and Play (UPnP) devices, such as a Network Attached Storage (NAS) device connected to the same network. The stereo can play media from a compatible Apple® device connected to the same network using the AirPlay® feature.

USB Device Compatibility

You can use a USB flash drive or the USB cable included with your media player to connect a media player or mobile device to the USB port.

The stereo is compatible with Android™ devices that support MTP mode.

The stereo is compatible with media players and other USB mass storage devices, including USB flash drives. Music on USB drives must meet these conditions:

- The music files must be formatted as MP3, AAC (.m4a), or FLAC, files.
- If you connect a portable hard drive, you must connect it to an external power source. The USB port on this stereo cannot provide power for a portable hard drive.
- The USB mass storage device must be formatted using one of the following systems:
  - Microsoft®: NTFS[1], VFAT, FAT[2], MSDOS
  - Apple: HFS, HFSPLUS
  - Linux: EXT2, EXT3, EX4

Connecting a USB Device

You can connect a USB device to the USB port on the stereo.

1. Locate the **USB** port on the back of the stereo.
2. Connect the USB device to the **USB** port.
3. Select the USB source.

Connecting a Compatible Bluetooth Device

You can play media from a compatible Bluetooth device using the Bluetooth wireless connection.

You can control the music playback with the media app on a Bluetooth device or using the FUSION-Link™ remote control app (page 5).

1. Select the **BT** source.
2. Select ☰ > **DISCOVERABLE** to make the stereo visible to your compatible Bluetooth device.
3. Enable Bluetooth on your compatible Bluetooth device.
4. Bring the compatible Bluetooth device within 10 m (33 ft.) of the stereo.
5. On your compatible Bluetooth device, search for Bluetooth devices.
6. On your compatible Bluetooth device, select the stereo from the list of detected devices.
7. On your compatible Bluetooth device, follow the on-screen instructions to pair and connect to the discovered stereo.

   When pairing, your compatible Bluetooth device may ask you to confirm a code on the stereo. The stereo does not display a code, but it does connect correctly when you confirm the message on the Bluetooth device.
8. If your compatible Bluetooth device does not immediately connect to the stereo, repeat steps 1 through 7.

The DISCOVERABLE setting is disabled automatically after two minutes.

[1] Software updates are not supported using NTFS file system.
[2] FAT includes most types of FAT file systems except exFAT.

DRAFT

NOTE: On some Bluetooth devices, adjusting the volume on the device affects the volume level on the stereo.

Connecting to a Garmin® Watch

For more information about the watch, see the watch manual at www.garmin.com/manuals.

1. Following the instructions in the watch manual, install the FUSION-Link Lite™ app from the Connect IQ™ store onto the watch.
2. On the stereo, select the **BT** source.
3. Select ☰ > **DISCOVERABLE**.

   The stereo remains discoverable for two minutes.
4. Bring the watch within 3 m (10 ft.) of the stereo.

   NOTE: Stay 10 m (33 ft.) away from other ANT® devices while pairing.
5. Open the FUSION-Link Lite app on the watch.

   The first time you open the app on the watch, the watch automatically pairs with and connects to the stereo. If you need to pair to another stereo, in the FUSION-Link Lite app, select **Settings** > **Pair new**.
6. Control the audio playback using the FUSION-Link Lite app on the watch.

After the devices are paired, they connect automatically when they are turned on, within range, and the app is open on the watch.

Connecting to an ARX70 Remote Control

1. On the stereo, select the **BT** source.
2. Select ☰ > **DISCOVERABLE**.
3. Bring the ARX70 remote control within 10 m (33 ft.) of the stereo.

   NOTE: Stay 10 m (33 ft.) away from other ANT devices while pairing.
4. On the ARX70 remote control, press and hold ⊕ until the status LED starts alternating green and red.

   The remote control searches for the stereo. When the remote control pairs successfully, the status LED turns on green briefly and then turns off.

If the remote control cannot find the stereo, the status LED turns on red briefly and then turns off.

FUSION-Link Wireless Remote Control App

You can use the FUSION-Link remote control app on your compatible Apple or Android device to adjust the stereo volume, change the source, control playback, select and manage radio presets, and adjust some stereo settings.

The app communicates with the stereo using a wireless connection to the mobile device. You must connect your compatible device to the stereo using Bluetooth or Wi-Fi® technology to use the app.

For information about the FUSION-Link remote control app for compatible Apple or Android devices, go to the Apple App Store℠ or the Google Play™ store.

Playing Music

Setting the Tuner Region

You must select the region you are in to receive AM and FM stations properly.

If you are connected to a compatible SiriusXM® tuner and antenna, and have a subscription (USA only), you must select the region you are in to receive SiriusXM stations properly.

NOTE: SiriusXM is not available in all regions.

If you are connected to a compatible DAB module and antenna (not included), you must select the region you are in to receive DAB stations properly.

NOTE: DAB stations are not available in all regions.

1. Select ☰ > **SETTINGS** > **TUNER REGION**.
2. Select the region you are in.

Changing the Radio Station

1. Select an applicable source, such as **FM**.
2. Select ▶II to select a tuning mode.

   You can use AUTO mode to scan stations, MANUAL mode to manually tune to a station, and PRESET mode to select the next preset station.

DRAFT

3 Select ⏮ or ⏭ to tune to the station.

TIP: You can quickly save the selected station or channel as a preset by holding ⏯.

Changing the Radio Station

1 Select an applicable source, such as **FM**.

2 Select ⏯ repeatedly to move through the tuning modes, and select an option:

- Select **AUTO** to scan and stop on the next available station.
- Select **MANUAL** to select a station manually.
- Select **PRESET** to select a saved station preset.

3 Select ⏮ or ⏭ to tune to the station.

When in MANUAL tuning mode, you can hold ⏮ or ⏭ to quickly advance through the stations.

Scanning for DAB Stations

Before you can scan for DAB stations, you must connect a compatible DAB module and antenna (not included) to the stereo. Because DAB signals are broadcast in select countries only, you must also set the tuner region to a location where DAB signals are broadcast.

1 Select the **DAB** source.

2 Select ⏯ to scan for available DAB stations.

When scanning is complete, the first available station in the first ensemble found begins playing.

NOTE: After the first scan is complete, you can select ⏯ again to re-scan for DAB stations. When the re-scan is complete, the system starts playing the first station in the ensemble you were listening to when you started the re-scan.

SiriusXM Satellite Radio

Only SiriusXM brings you more of what you love to listen to, all in one place. Get over 140 channels, including commercial-free music plus the best sports, news, talk, comedy and entertainment. Welcome to the world of satellite radio. A SiriusXM Vehicle Tuner and subscription are required. For more information, go to www.siriusxm.com .

To learn more about activation or operation of the SiriusXM tuner, see the Apollo WB670 Owner's Manual.

Controlling Music Playback on a Bluetooth Device

You can use the remote control to connect and control the music playback of a compatible Bluetooth device to the connected stereo.

1 Select the **BT** source.

2 Select ☰ > **DISCOVERABLE** to make the stereo visible to your compatible Bluetooth device.

NOTE: The stereo is discoverable for only two minutes to prevent interruption to audio streaming over Bluetooth wireless. If more than two minutes pass before you connect a compatible device, you must repeat this step.

3 Enable Bluetooth on your compatible Bluetooth device.

4 Bring the compatible Bluetooth device within 10 m (33 ft.) of the stereo.

5 On the Bluetooth device, search for Bluetooth devices.

6 Select the stereo from the list of detected devices.

7 Follow the on-screen directions to connect to the discovered stereo.

When pairing, your compatible Bluetooth device may ask you to confirm a code on the remote control. The remote control does not display a code, but it connects correctly when you confirm the message on the compatible Bluetooth device.

8 Use the controls on the remote control to control the music playback.

Controlling Music Playback on a USB Source

1 Connect a compatible USB device to the stereo.

2 Select the appropriate source on the stereo.

3 If necessary, select ☰ to browse the music on the USB device.

DRAFT

4 If necessary, launch a music application on the USB device, and begin playback.

You can use the stereo controls to select, play, pause, and skip tracks.

Controlling Music Playback on a Connected Smartphone or Media Player

1 Connect a compatible smartphone or media player to the stereo using USB or Bluetooth (if available).

2 Select the appropriate source on the stereo.

3 Launch a music application on the connected smartphone or media player, and begin playback.

You can use the stereo controls to select, play, pause, and skip tracks.

DSP Settings

This stereo features digital signal processing (DSP). You can select pre-configured DSP settings for FUSION speakers and amplifiers to optimize audio reproduction in their installed locations.

All DSP settings are configured using the FUSION-Link remote control app (page 5). See the owner's manual for more information.

More Information

Registering Your Apollo WB670

Help us better support you by registering the product online.

- Go to **www.fusionentertainment.com**.
- Keep the sales receipt, or a copy, in a safe place.

DRAFT

FUSION SUPPORT

New Zealand	09 369 2900
Australia	1300 736 012
Europe	+44 (0) 370 850 1244
USA	623 580 9000
Pacific	+64 9 369 2900

DRAFT

Garmin®, the Garmin logo, FUSION®, and the Fusion logo are trademarks of Garmin Ltd. or its subsidiaries, registered in the USA and other countries. FUSION-Link™ is a trademark of Garmin Ltd. or its subsidiaries. These trademarks may not be used without the express permission of Garmin.

Apple® is a trademark of Apple Inc., registered in the U.S. and other countries. Android™ is a trademark of Google Inc. Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Garmin is under license. NMEA®, NMEA 2000®, and the NMEA 2000 logo are registered trademarks of the National Marine Electronics Association. All rights reserved. Other trademarks and trade names are those of their respective owners.

FUSIONENTERTAINMENT.COM

190-02670-90
March 2020
Printed in Taiwan