802.11ax-HE20 – Ant 3	
Channel 1 (5955MHz)	
The Reference Level	The Mask Data
	
Channel 49 (6195MHz)	
The Reference Level	The Mask Data
	
Channel 93 (6415MHz)	
The Reference Level	The Mask Data
	

802.11ax-HE20 – Ant 3	
Channel 97 (6435MHz)	
The Reference Level	The Mask Data
Channel 105 (6475MHz)	
The Reference Level	The Mask Data
	
Channel 113 (6515MHz)	
The Reference Level	The Mask Data
	

802.11ax-HE20 – Ant 3	
Channel 117 (6535MHz)	
The Reference Level	The Mask Data
	
Channel 149 (6695MHz)	
The Reference Level	The Mask Data
	
Channel 181 (6855MHz)	
The Reference Level	The Mask Data
	

802.11ax-HE20 – Ant 3	
Channel 185 (6875MHz)	
The Reference Level	The Mask Data
	
Channel 189 (6895MHz)	
The Reference Level	The Mask Data
	
Channel 209 (6995MHz)	
The Reference Level	The Mask Data
	

802.11ax-HE20 – Ant 3	
Channel 229 (7095MHz)	
The Reference Level	The Mask Data
	

802.11ax-HE40 – Ant 3	
Channel 3 (5965MHz)	
The Reference Level	The Mask Data
	
Channel 51 (6205MHz)	
The Reference Level	The Mask Data
	
Channel 91 (6405MHz)	
The Reference Level	The Mask Data
	

802.11ax-HE40 – Ant 3	
Channel 99 (6445MHz)	
The Reference Level	The Mask Data
	
Channel 107 (6485MHz)	
The Reference Level	The Mask Data
	
Channel 115 (6525MHz)	
The Reference Level	The Mask Data
	

802.11ax-HE40 – Ant 3	
Channel 123 (6565MHz)	
The Reference Level	The Mask Data
	
Channel 147 (6685MHz)	
The Reference Level	The Mask Data
	
Channel 179 (6845MHz)	
The Reference Level	The Mask Data
	

802.11ax-HE40 – Ant 3	
Channel 187 (6885MHz)	
The Reference Level	The Mask Data
	
Channel 195 (6925MHz)	
The Reference Level	The Mask Data
	
Channel 211 (7005MHz)	
The Reference Level	The Mask Data
	

802.11ax-HE40 – Ant 3	
Channel 227 (7085MHz)	
The Reference Level	The Mask Data
	

802.11ax-HE80 – Ant 3	
Channel 7 (5985MHz)	
The Reference Level	The Mask Data
	
Channel 55 (6225MHz)	
The Reference Level	The Mask Data
	
Channel 87 (6385MHz)	
The Reference Level	The Mask Data
	

802.11ax-HE80 – Ant 3	
Channel 103 (6465MHz)	
The Reference Level	The Mask Data
	
Channel 119 (6545MHz)	
The Reference Level	The Mask Data
	
Channel 135 (6625MHz)	
The Reference Level	The Mask Data
	

802.11ax-HE80– Ant 3	
Channel 151 (6705MHz)	
The Reference Level	The Mask Data
	
Channel 167 (6785MHz)	
The Reference Level	The Mask Data
	
Channel 183 (6865MHz)	
The Reference Level	The Mask Data
	

802.11ax-HE80– Ant 3	
Channel 199 (6945MHz)	
The Reference Level	The Mask Data
	
Channel 215 (7025MHz)	
The Reference Level	The Mask Data
	

802.11ax-HE160 – Ant 3	
Channel 15 (6025MHz)	
The Reference Level	The Mask Data
	
Channel 47 (6185MHz)	
The Reference Level	The Mask Data
	
Channel 79 (6345MHz)	
The Reference Level	The Mask Data