EUT Internal Photos

Figure 7
For No Surge Protector Model, Internal View (Removed Cover)



Figure 8
For Surge Protector 560J Model, Internal View (Removed Cover)



Figure 9
For Surge Protector 860J Model, Internal View (Removed Cover)



Figure 10
For Surge Protector 1080J Model, Internal View (Removed Cover)



Figure 11
For Surge Protector 1200J Model, Internal View (Removed Cover)



Figure 12
For USB Output (5V 2.4A) Model, Internal View (PCB Front View)



Figure 13
For USB Output (5V 2.4A) Model, Internal View (PCB Back View)



Figure 14
For USB Output (5V 3.4A) Model, Internal View (PCB Front View)



Figure 15
For USB Output (5V 3.4A) Model, Internal View (PCB Back View)



Figure 16
For all Models, Internal View (USB Board, Front View)



Figure 17
For all Models, Internal View (USB Board, Back View)



Figure 18
For Surge Protector 560J Model, Internal View (PCB Front View)

Figure 19
For Surge Protector 560J Model, Internal View (PCB Back View)



Figure 20
For Surge Protector 860J Model, Internal View (PCB Front View)

Figure 21
For Surge Protector 860J Model, Internal View (PCB Back View)



Figure 22
For Surge Protector 1080J Model, Internal View



Figure 23
For Surge Protector 1080J Model, Internal View



Figure 24
For Surge Protector 1080J Model, Internal View



Figure 25
For Surge Protector 1080J Model, Internal View



Figure 26
For Surge Protector 1200J Model, Internal View (PCB Front View)



Figure 27
For Surge Protector 1200J Model, Internal View (PCB Back View)



Figure 28
For all Models, Internal View (PCB Front View)



Figure 29
For all Models, Internal View (PCB Front View)



Figure 30
For all Models, Internal View



Figure 31
For all Models, Internal View (Removed WPC Board)



Figure 32
For all Models, Internal View (WPC Coil Antenna, Front View)



Figure 33
For all Models, Internal View (WPC Coil Antenna, Front View)



Figure 34
For all Models, Internal View (WPC Board, Front View)



Figure 35
For all Models, Internal View (WPC Board, Board View)