- Hyper-Speed Racing On Any Terrain
- Oversized Knobby Tires For Gripping Power
- Full Function Wireless Remote Control
- Bright LED Lights
- Available In 2 Frequencies For Competitive Racing

SPORT QUAD

RADIO CONTROLLED ALL-TERRAIN VEHICLE

SUPER GRIP TIRES FOR FAST RACING

AGES 6+

BOX CONTAINS THE FOLLOWING FREQUENCY:
- [ ] 27 MHz
- [ ] 49 MHz

BATTERY OPERATED PLAY VEHICLE

AGES 6 AND UP

⚠ WARNING! CHOKING HAZARD - Small parts. Not suitable for children under 3 years.

BLUE HAT TOY COMPANY™

TWO FREQUENCIES FOR COMPETITIVE RACING

WIRELESS RC ACTION!

REMOVABLE ACTION RIDER WITH COMPLETE ARTICULATION

SPORT QUAD

RADIO CONTROLLED ALL-TERRAIN VEHICLE

EXCITING 4-WHEELING ACTION!

- *Hyper-Speed Racing On Any Terrain*
- *Oversized Knobby Tires For Gripping Power*
- *Full Function Wireless Remote Control*
- *Bright LED Lights*
- *Available In 2 Frequencies For Competitive Racing*

SPORT QUAD

RADIO CONTROLLED ALL-TERRAIN VEHICLE

KEEP THIS PACKAGE FOR REFERENCE AS IT CONTAINS IMPORTANT INFORMATION.

BATTERY INSTALLATION

Operation requires 6 "AA" 1.5V batteries (not included) for ATV and one 9V battery (not included) for radio controller.

- Carefully remove items from package.
- Locate the battery compartment on the underside of the ATV and wireless controller.
- Turn the battery compartment lock on the bottom of the ATV to remove the battery compartment.
- Insert 6 "AA" 1.5V batteries according to the polarity diagram located on the battery tray. (Fig.1)
- Replace the battery compartment.
- Slide open the battery compartment door of the controller. (Fig.2)
- Insert the one 9V battery following the correct polarity.
- Replace the battery compartment door.

NOTE: For best operation, use on a hard surface.

ON/OFF SWITCH
LATCH
DOUBLE SIDED BATTERY TRAY (REQUIRES 6 "AA" 1.5V BATTERIES)
Fig.1
STEERING ALIGNMENT LEVER
ON/OFF SWITCH IS LOCATED ON FRONT OF CONTROLLER
Fig.2
RADIO CONTROLLER USES ONE "9V" BATTERY (NOT INCLUDED)

BASIC OPERATION

- Switch both the vehicle and controller power switches to the "ON" position.
- Adjust the steering alignment lever located on the bottom of the vehicle (between front wheels) if the vehicle does not run straight when moving forward.

OPERATING CONTROLS

LEFT JOYSTICK FORWARD & REVERSE
RIGHT JOYSTICK LEFT & RIGHT
OFF/ON SWITCH
FULL FUNCTION REMOTE CONTROL

STEERING ALIGNMENT ADJUSTMENT: To fine-tune the steering control, locate the alignment dial on the underside of the chassis. Starting with the dial in the middle position, test drive your car and adjust as needed. Should the car pull to the left or right, simply move the dial until your car drives straight without touching the directional controller.

BATTERY WARNING:
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Insert batteries using the correct polarity. Do not short-circuit the supply terminal.
- Remove batteries when not in use. Recycle or dispose of exhausted batteries according to federal, state, and local laws. Do not dispose of batteries in a fire - they may leak or explode.
- Only use manufacture specified battery(ies), charger(s) and/or adapter, if applicable, specified by the manufacturer.
- Always use, replace, and recharge (if applicable) batteries under adult supervision.

KEEP THIS PACKAGE FOR REFERENCE AS IT CONTAINS IMPORTANT INFORMATION.

SAFETY WARNINGS - PLEASE READ BEFORE USING PRODUCT
- Not recommended for children under 6 years of age. As with all electrical products, precautions should be observed during handling and use to reduce the risk of electrical shock.
- It is recommended that this toy and all accessories be periodically examined for potential hazards and that any potentially hazardous parts be repaired or replaced.

0-3

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio TV technician for help.

2905045 (33539)

6 94202 31556 9

Made in China

WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

FC This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

©2014 MerchSource, LLC. Blue Hat Toy Company, Blue Hat Toy Company logos are trademarks of MerchSource, LLC. All rights reserved.

Distributed by MerchSource, LLC, Irvine, CA 92618.

PATENT PENDING

The artwork and design of this package are protected by US copyright law and may not be reproduced, distributed, displayed, published or used for any purpose without prior written permission. It is not permitted to alter, remove or reproduce any trademarks or copyright notice from this package.