TAIDE TECHNOLOGIES

BT029 User Manual

Brand name：iKANOO

Model name：BT029

FCC ID:OYCBT029

Dear user,

Thank you very much for choosing BT029 Bluetooth SPEAKER. Before use, please read this user manual carefully in order to operate this device correctly and bring its excellent performance into full play.

I. Notice

Please store and use this product in the environment at normal temperature;
DO NOT expose this product to rain or DAMPNESS;
DO NOT toss this product and prevent it from falling and thus being damaged;
DO NOT disassemble, repair and modify this product;
As it is inbuilt with lithium battery, DO NOT cast or place it in fire to avoid danger!

II. Exterior and Functional Interface

III. Parameters

Model: BT029
Bluetooth specification: Bluetooth V2.1+EDR
Transmission distance: ⩽10M (It varies as the environmental factor and the connected Bluetooth equipment are different)
USB charging voltage: DC 5V-300mA
Built-in battery: Lithium battery
Output power: 3W
Frequency response: 90Hz-20KHz
Sensitivity: 80db±2db
S/N ratio: ≥ 76Db

IV. Packing List

1. Sound box 1 set
2. 3.5” audio cable and wire for connecting USB power cable 1 piece
3. User manual/warranty card 1 piece

V. Common Functions

Start: Turn on the switch of the sound box and the sound box will give off the sound of “Ding Ding” as tip. Meanwhile, the blue lamp begins to flicker.

Bluetooth connection: After the power is switched on, the blue lamp begins to flicker. At this moment, open the Bluetooth equipment and the SPEAKER BT029 can be successfully searched. After the match-making is successful, the sound of “Du-Du” as tip will be given off. Besides, the Bluetooth equipment will display successful connection. BT029 will automatically stop if no equipment connection is found within 5 minutes, so as to save the power.
TIP : If the connection fails, please turn off the machine and restart it or please charge it as maybe there is not sufficient power in the battery.

AUX source: Insert the attached audio cable into the AUX port on the sound box and the music player audio port on PC. The player begins to play. The machine will immediately start the music. The sound volume, the selected songs and so on are freely controlled by the player.
TIP: Please never use AUX under the status of Bluetooth.

Smart automatic quick charge: Charge in power-off state. Insert the attached USB power cable with the Mini USB end into the USB power port of the sound box and the other end into the USB port of PC or the USB charger to start charging. After the charging is over, the red indicator lamp will be off.

VI. Troubleshooting

Problem	Troubleshooting
Failure in connection and match-making for many times	1. Inspect whether the sound is in the status of searching, or, restart the machine. 2. The surrounding Bluetooth equipment are plentiful, which causes the difficulty in searching. So, please close the other Bluetooth equipment.
The sound is small or distorted	1. Inspect the sound volume of the Bluetooth equipment and regulate the sound volume to the appropriate position. 2. The voltage of the battery is low, please charge it.
There is discontinuity in the music	See whether the effective connection distance of sound is exceeded, or, whether there is obstacle between the sound box and the Bluetooth equipment.
The indicator light for Bluetooth status is not on	1. It indicates that the power of the battery is not sufficient. Please try again after charging it. 2. Restart the machine.

Hints: Another trouble, please consult the dealer or an experienced radio/TV technician for help.

VII:Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.