U504TL

Quick Start Guide

Contents

Welcome…….. 1

1. What's in the package.....1
2. Getting to know your phone.....2
3. Before you turn on your phone..... 2
4. Getting Started.....3
5. Keep in contact.....5
6. Catch up with friends in your social networks..... 5
7. Send a message.....5
8. Make your first call.....6
9. Capture your big moment..... 6
10. Email.....7
11. Sending an email message..... 7
12. Bluetooth..... 8
13. Wi-Fi.....8
14. Play store.....8

Accessories are available at www.umxmobile.com.

Congratulations on the purchasing of your new Android phone!



This Quick Start Guide is to welcome and familiarize you with the features of this phone.

1. What's in the package

- Mobile device
- Battery
- USB cable
- Travel adapter (charger)
- Quick Start Guide

2. Getting to know your phone

3. Before you turn on your phone

Inserting the battery

1. With your thumb or finger, open the back cover from the notch at the left of your phone.
2. Take the battery out from battery bag and gently push the battery into place.



Charging the battery

1. Connect the micro-USB end of the data cable to the charger port.
2. Connect the other end of the data cable to the Travel Adapter (charger).



NOTE: As the battery is being charged, the notification LED light will turn red .The light will turn green when the phone is fully charged.

Inserting the microSD card / SIM card - Opitional

1. Remove the battery cover
2. Position the microSD card /SIM card into the slot above the battery facing left and slide it into place until it is fully inserted and locked in place.

NOTE: You must remove the battery before inserting the microSD card / SIM card.



4. Getting Started

Turning your device on and off

1. To turn your device on, press and hold the power button for three seconds.
2. To turn your device off, press and hold the power button for three seconds. Tap "Power off" to power off.

Activating your phone

1. Insert battery

2. Turn on your new phone
3. Follow the activation material provided in your package

NOTE: Don't press **Power/Lock** while the phone is being activated.

Using the touch screen

Control your touch screen with the following actions:

· **Tap:** Tap on an icon once with your finger to select or launch a menu, application, or option

· **Tap and hold:** Tap an item and hold it for more than one second to open a pop-up option list.

· **Scroll:** Tap and drag your finger up, down, left, or right to move through items on lists/screens

· **Drag and drop:** Tap and hold your finger on an item, and then drag your finger to move the item up or down

· **Double-tap:** Tap twice quickly with your finger to zoom in or out while viewing photos or web pages

Personalizing your home screen

To make your home screen look just the way you want, choose from a selection of scenes and layouts, or create a custom scene or layout of your own. You can also pick different wallpaper or shortcuts.

Tap and hold an empty spot on one of the home screens to change the wallpaper.

Locking and unlocking the screen

· You can lock the touch screen and keys to prevent accidental calls

1. To lock, press power button.
2. To unlock, turn on the screen by pressing power button, and then flick the grey window with your finger.
3. Set an unlock pattern

· From home screen, tap **Setting**

· Tap **Security & location** -> **Screen lock** -> **Pattern / PIN / Password** to set up.

Setting the ringtone and volume

· To change the phone ringtone, from the home screen.

1. Tap **Setting** -> **Sound** -> **Phone ringtone**.
2. Tap the ringtone you want to use from the list

NOTE: Adjust the volume to your desired level by pressing the volume up or down button on the left side of your phone.

The alarm and media volume can be adjusted separately. Adjusting the media volume changes the volume level of sound notifications, music, or video playback.

5. Keep in contact

Using your phone's icons, it's simple to manage your contacts via phone, messaging, and email.

Adding a new contact

1. From the Home screen, tap **Apps** > **Contacts**.
2. Tap **Create new contact.**
3. If you have more than one account, select an account then enter the information for the contact.

·Tap -> select **Take photo** or **Choose photo from Gallery** to add a picture.

· To add a picture (optional).

· Enter your contact's information.

4. Tap **SAVE**.

6. Catch up with friends in your social networks

Share and get updates from friends in popular networks like Facebook in a single feed. With Facebook, you can easily track your friends' status messages, photo uploads, notifications, and more or comment and post your own.

7. Send a message

1. From the Home screen, tap **Apps** > **Messages**
2. Tap **Create New message**.
3. Enter the phone number in the **To** field. Fill in one or more

recipients. You can enter the first few letters of a contact name or phone number. Matching contacts are displayed. Continue typing or tap a name or phone number from the search results.

- Tap > Select message recipients from your contact list >**Ok**.

4. Tap **Send message** > enter your message.
5. Tap to **Send**.
   - Tap **Back** to save the message as a draft.

NOTE: Your text messages will automatically become multimedia messages when you compose a message over 160 characters long, add a subject or attach an item.

8. Make your first call

1. From the Home screen, tap **Phone**. Or tap **Apps** > **Phone**.
2. Tap the number you want to dial.
   - If you make a mistake, tap to erase a single character. Tap and hold to erase the entire string.
3. Tap **Dial**.
   - The Calling screen is shown and appears in the Status bar while the call is active.
   - To change the volume during a call, press **Volume up** / **Volume down**.
4. To end the call, tap **End Call**.

9. Capture your big moment

Use your phone's 5.0 megapixel camera to take photos and videos.

1. From the Home screen, tap **Apps** > **Camera**.
2. Frame your subject on screen.
   - Tap . The camera brings the image into focus. When the image is in focus, the camera takes a picture. The picture you just took is briefly previewed full-screen, and then is displayed

as a thumbnail in the lower left corner. Tap the thumbnail to view, share, or work with your pictures in Gallery.

- When you're in Camera mode, tap to choose change to camcorder.

10. Email

Check and send email messages directly from your phone. If you have already signed up your Gmail account when you first set up your phone, you'll be able to send and receive Gmail messages from the home screen, by tapping the icon.

Adding your email accounts

1. From the Home screen, tap **Apps** > **Gmail**.
2. Enter the **Email address** and **Password** for your email account >**Next**

11. Sending an email message

1. From the Home screen, tap **Apps** > **Gmail**.
2. Tap to create new Email.
3. Enter a name or email address in the **To** field. If you are sending the mail to several recipients, separate the email addresses with a comma " , ".
   - As you enter text, matching addresses are suggested from your Contacts list.
   - Tap menu to add additional recipient in the Cc/Bcc field.
4. Enter a **Subject** and type your message.
   - To attach an image file, tap **attach** > select the picture you want to attach.
5. Tap **Send**.
   - To save an unsent email message on your phone, tap **Save as draft**.
   - To cancel an email message, tap **Discard**.

12. Bluetooth

1. From the Home screen, tap **Apps** > **Settings**> **Connected devices** > **Bluetooth**.
2. Check or uncheck Bluetooth to turn it on or off.
   - Tap the name of the Bluetooth to set up the phone discoverable name.

13. Wi-Fi

1. From the Home screen, tap **Apps** > **Settings**.
2. Tap **Network & Internet > Wi-Fi**.
3. Select the **Wi-Fi** check box to turn Wi-Fi on.
4. The network names and security settings of detected Wi-Fi networks are displayed.
5. Tap a Wi-Fi network to connect.
   - If you selected a network that is secured, enter the security key and then tap **Connect**. Depending on the network type and security settings, you may also need to enter more information or choose a security certificate.

14. Play store

You can browse and sort applications by category.

1. From the Home screen, tap **Apps** > **Play Store**.
2. Tap **GAMES**, **BOOKS & REFERENCE**, **BUSINESS** or **COMICS**, etc.
   - Scroll to view subcategories and tap one to explore.
3. Tap the subcategory you want.
   - If you selected paid apps, you'll be redirected to the Google Checkout screen.

FCC Regulations:

1. This mobile phone complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This

device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

2. This mobile phone has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiated radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures：

---Reorient or relocate the receiving antenna.

---Increase the separation between the equipment and receiver.

---Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

---Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user‘s authority to operate the equipment.

RF Exposure Information (SAR)

This mobile phone meets the government’s requirements for exposure to radio waves.

This phone is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government.

The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6W/kg. *Tests for SAR are conducted using standard operating positions

accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station, the lower the power output.

The highest SAR value for the model phone as reported to the FCC when tested for use at the ear is 0.97 W/kg and when worn on the body, as described in this user guide, is 0.53 W/kg (Body-worn measurements differ among phone models, depending upon available accessories and FCC requirements.)

While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirement.

The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of www.fcc.gov/oet/ea/fccid after searching on FCC ID: P46-U504TL.

For body worn operation, this phone has been tested and meets the FCC RF exposure guidelines for use with an accessory that contains no metal and the positions the handset a minimum of 1.5 cm from the body. Use of other accessories may not ensure compliance with FCC RF exposure guidelines. If you do not use a body-worn accessory and are not holding the phone at the ear, position the handset a minimum of 1.5 cm from your body when the phone is switched on.

HEARING AID COMPATIBILITY HAC FOR WIRELESS TELECOMMUNICATIONS DEVICES

THIS PHONE HAS A HAC RATING OF M3/T3

WHAT IS HEARING AID COMPATIBILITY?

The Federal Communications Commission has implemented rules and a rating system designed to enable people who wear hearing aids to more effectively use these wireless telecommunications devices. The standard for compatibility of digital wireless phones with hearing aids is set forth in American National Standard Institute (ANSI) standard C63.19. There are two sets of ANSI standards with ratings from one to four (four being the best rating): an "M" rating for reduced interference making it easier to hear conversations on the phone when using the hearing aid microphone, and a "T" rating that enables the phone to be used with hearing aids operating in the telecoil mode thus reducing unwanted background noise.

HOW WILL I KNOW WHICH WIRELESS PHONES ARE HEARING AID COMPATIBLE?

The Hearing Aid Compatibility rating is displayed on the wireless phone box. A phone is considered Hearing Aid Compatible for acoustic coupling (microphone mode) if it has an "M3" or "M4" rating. A digital wireless phone is considered Hearing Aid Compatible for inductive coupling (telecoil mode) if it has a "T3" or "T4" rating.

HOW WILL I KNOW IF MY HEARING AID WILL WORK WITH A PARTICULAR DIGITAL WIRELESS PHONE?

You'll want to try a number of wireless phones so that you can decide which works the best with your hearing aids. You may also want to talk with your hearing aid professional about the extent to which your hearing aids are immune to interference, if they have wireless phone shielding, and whether your hearing aid has a HAC rating.