axess•tel

Advanced Features

Changing Greeting Message

System Reset

Restricting Use of the Phone

Locking / Unlocking the Phone

Changing the Lock Code

CHANGING GREETING MESSAGE

This feature lets you change the greeting message that the phone displays during standby mode.

1. Press MENU, 6 (Configuration).
2. Press 1 (Greeting). Current greeting displays.
3. Press STORE to change greeting.
4. Enter your new greeting message with alphanumeric keys

NOTE: Press MESSAGE to switch between capital and lower case.
Example) To enter "My Phone",
Press 6 MESSAGE 9 9 9 # MESSAGE 7 MESSAGE 4 4 6 6 6 6 6 3 3

5. Press STORE to save change.



SYSTEM RESET

To reset your phone settings to manufacturer's defaults, follow these steps:

1. Press MENU, 7 (Security).
2. Enter lock code.

NOTE: Default Lock code is last 4 digits of your phone number. To change lock code, see page 33.

3. Press 7 (Factory Reset).
4. Select "YES" by press (of *, #).
5. Press STORE.
6. "PHONE INITIALIZATION" blinks while the phone is resetting.

To reset your phone settings to manufacturer's defaults and clear all user data, follow these steps:

1. Press MENU, 7 (Security)
2. Enter lock code.

NOTE: Default Lock code is last 4 digits of your phone number. To change lock code, see page 33.

3. Press 8 (Phone Reset).
4. Select "YES" by press (of *, #).
5. Press MENU.
6. "PHONE INITIALIZATION" blinks while the phone is resetting.

RESTRICTING USE OF THE PHONE

You can restrict the use of the phone by unauthorized persons.

Restricting Outgoing Calls

1. Press MENU, 7 (Security).
2. Enter lock code.

NOTE: Lock code is set as 0000 from the factory.
To change lock code, see page 33.

3. Press 2 (Restrict), 1 (Outgoing).
4. Select 'ON' by pressing (or *, #).
5. Press STORE to save change.

In this mode, when you try to call,"OUTGOING CALL RESTRICTED" displays and no outgoing call goes through.

Restricting International Calls

1. Press MENU, 7 (Security).
2. Enter lock code.
3. Press 2 (Restrict), 2 (International).
4. Select 'ON' by pressing (or *, #).
5. Press STORE to save change.

In this mode, when you try to make an international call (headed by 00), "INTERNATIONAL RESTRICTED" displays and no international call goes through.

Restricting Long Distance Calls

1. Press MENU, 7 (Security).
2. Enter lock code.
3. Press 2 (Restrict), 3 (Long Distance).
4. Select 'ON' by pressing (or *, #).
5. Press STORE to save change.

In this mode, when you try to make a long distance call (headed by 0), "LONG DISTANCE RESTRICTED" displays and no long distance call goes through.

LOCKING / UNLOCKING THE PHONE

You can lock your phone so that calls cannot be made by unauthorized persons. You can still receive incoming calls. Turning the phone off does not unlock the phone; the phone stays in locked mode until you change it.

1. Press MENU, 7 (Security).
2. Enter lock code.
3. Press 3 (Auto Lock).
4. Select 'ON' or 'OFF' by pressing (or *, #).
5. Press STORE to save the change.

NOTE1: When locked, the phone displays "LOCKED".
NOTE2: When locked, you have to enter the lock code to make a call.
NOTE3: You can still receive incoming calls.

CHANGING THE LOCK CODE

The default lock code is the last 4 digits of your phone number. It can be changed to any 4 digit number.

1. Press MENU, 7 (Security).
2. Enter lock code.
3. Press 1 (Change Code).
4. Enter your new lock code.

NOTE: The lock code must be four numeric digits.

5. Press STORE.
6. Re-enter new lock code for verification.
7. Press STORE to confirm.

NOTE: "CODE NOT MATCHED TRY AGAIN!" displays if the second entry does not match the first entry.

axess•tel

Optional Features

Call Forwarding

Call Waiting

Three-way Calling

Call Forwarding

Call Forwarding is a feature that lets you forward your incoming calls to another phone number, even if your phone is turned off or is in no service area. Contact your service provider to activate Call Forwarding.

Call Waiting

Call Waiting alerts you to a second incoming call while you are on the conversation . When there's another incoming call, you will hear warning beep. To respond to the call waiting, press REDIAL or hit shortly the hook switch once. Pressing REDIAL again or hitting the hook again will let you go back to the first call.Contact your service provider to activate Call Waiting.

Three-Way Calling

Three-Way Calling is a feature that lets you set up a three-way conversation with two different parties. While you're in conversation with a party, hit or the hook switch and place another call with the third party. Then press REDIAL or hit the hook switch again to connect the three parties together. Contact your service provider to activate Three-Way Calling.

axess•tel

Miscellaneous

Menu Table
Specification

MENU OPTION TABLE

I	II	III	Explanation
1. PHONE BOOK	SEARCH	NAME	Used when searching for a phone number in the phone book by name/number/ stored memory number
		NUMBER	
		LOCATION	
	STORE		Used when storing a phone number and name in the phone book
	ERASE	NAME	Used when erasing a phone number in the phone book
		NUMBER	
		LOCATIOM	
2. MESSAGES	NEW MESSAGE		Send a new message
	INBOX		Received SMS messages
	SMS SERVICES		Received voice message notifications
	VOICE MSG		SMS Services
	TEMPLATES		Open pre-saved templates
	SAVED MSG		Open saved messages
	ERASE MSG		Erase received messages
	MSG OPTION	MSG ALERT	Set message alert
		MSG ALERT TYPE	Set message alert type
		MSG ACK	Set Message Delivery ACK
		MSG PRIORITY	Set default message priority
		SAVE SENT MSG	Auto-Save sent messages
		AUTO DELETE	Auto-Delete received messages if INBOX is full
		EDIT TEMPLATE	Edit default templates
3. CALL HISTORY	MISSED CALL		Stores phone numbers called recently
	INCOMING		Stores phone numbers of calls received recently
	OUTGOING		Stores missed incoming calls
4. TIME	ALARM		Alarm On/Off
	LAST CALL		Shows time duration of last call
	TOTAL TIME	OUTGOING	Shows accumulated outgoing call time
		INCOMING	Shows accumulated incoming call time
	CLR CALL TIME		Resets accumulated call time
	TIME MODE	AM/PM	Time: AM/PM display mode
		24 HOURS	Time: 24 Hours display mode
5. SOUND	RING TYPE		Determines whether the phone alerts the incoming call with sound or only with message
	RINGTONE		Selects the ring type
	RING VOLUME		Adjust ring volume
	1 MIN ALERT	ON/OFF	Beeps at one minute interval during conversation
	SERVICE ALERT	ON/OFF	Beeps when the phone is getting out of or entering service area
	ALARM TONE	ALARM TONE	Selects alarm sound
	CONNECT ALERT	ON/OFF	Beeps when the call is connected
	VOX PRIV ALRT	ON/OFF	Voice Privacy audible alert
6. CONFI GURATION	CALL TIMER	ON/OFF	Toggles call timer display
	GREETING		change greeting
	MY PHONE NUMBER		Show your phone number

7. SECURITY	CHANGE CODE		Change Lock Code
	RESTRICT	OUTGOING	Restrict outgoing calls
		LONG DISTANCE	Restrict long distance calls
		INTERNATIONAL	Restrict international calls
	AUTO LOCK	ON/OFF	Lock the phone
	VERSION		Show phone information
	ERASE LOGS	OUTGOING	Erase outgoing calls history
		INCOMING	Erase incoming calls history
		MISSED	Erase missed calls history
		ALL CALLS	Erase all calls history
	ERASE NAMES		Erase all phonebook names
	FACTORY RESET		Reset to default settings
	PHONE RESET		Reset to default settings and clears user data
	HOT LINE EDIT		Edit Hot Line number

SPECIFICATIONS

Frequency Range	AXW-L800	RX: 869.64Mhz~893.37Mhz TX: 824.64Mhz~848.37Mhz	
Channel Bandwidth		CDMA 1.25 MHz	
Stability of frequency		0.4 ppm	
External appearance (mm)		173 x 196 x 70 mm	
Weight		600 g	
Sending output		maximum 0.23W E.R.P	
Temperature of operation Relative humidity		-20 ~ +50 degrees Celcius 5% ~ 90%	
Power Adaptor		Input: AC 100~240V 50~60Hz Output: DC 5V/2A	
Battery		Standby	16mA (Slot Cycle Index: 2) 72 hours
		Talk	3 Hours

SAR INFORMATION

THIS MODEL PHONE MEETS THE GOVERNMENT 'S REQUIREMENTS FOR EXPOSURE TO RADIO WAVES.

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF)energy set by the Federal Communications Commission of the U.S.Government.These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluate on of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age and health.

The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6 W/kg.*Tests for SAR are conducted with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output. Before a phone model is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the limit established by the government-adopted requirement for safe exposure.

The tests are performed in positions and locations
(e.g., at the ear and worn on the body) as required by the FCC for each model. The highest SAR value for this model phone when worn on the body, as described in this user guide, is 1.16**W/kg** . (Body worn measurements differ among phone models, depending upon available accessories and FCC requirements). While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirement for safe exposure. The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of http://www.fcc.gov / oet / fccid after searching on **FCC ID : PH7AXWL1900.**

Additional information on Specific Absorption Rates (SAR)can be found on the Cellular Telecommunications &Internet Association (CTIA)web-site at http://phonefacts.net.*In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6watts/kg (W/kg)averaged over one gram of tissue. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any agitations in measurements.

FCC Compliance Information

This device complies with Part 15 of FCC Rules.
Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received.
Including interference that may cause undesired operation.

Information to User

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions,
may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ tv technician for help.

CAUTION

The user who makes changes or modifications to the unit without the express approval by the manufacturer will void user authority to operate the equipment.

Safety Information

1 . SAFETY INFORMATION FOR FIXED WIRELESS TERMINALS
.POTE NTIALLY EXPLOSIVE ATMOSPHERES
Turn your phone OFF when in any area with a potentially explosive atmosphere and obey all signs and instructions. Sparks in such areas could cauls e an explosion or fire resulting in bodily injury or even death.

INTERFERENCE TO MEDICAL DIVICES
Certain electronic equipment may be shielded against RF signal from you wireless phone. (pacemakers, Hearing Aids, and so on) Turn your phone OFF in health c are facilities when any regulations posted in these areas instruct you to do so. RF signals may affect improperly installed or inadequately shielded electronic system in motor vehicles.

.EXPOSURE TO RF ENERGY
Use only the supplied or an approved replacement antenna. Do not touch the antenna unnecessarily when the phone is in use. Do not move the antenna close to, or couching any exposed part of the body when making a call.

SAFETY INFORMATION FOR RF EXPOSURE

Body worn operation

This device was tested for typical body-worn operations with the back of the phone kept 25 mm. from the body. To maintain compliance with FCC RF exposure requirements, use only belt-clips, holsters or similar accessories that maintain a 25 mm. separation distance between the user's body and the back of the phone, including the antenna. The use of belt-clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.