1. External Photograph of EUT

Brand Name: SONY / Model Name: BRH10



Brand Name: SONY / Model Name: BRH10



Brand Name: SONY / Model Name: BRH10



2. Photograph of Accessory

Brand Name: SONY / Model Name: BRH10

Specification of Accessory		
Battery	**Brand Name**	SYNergy
	Model Name	AHB291634PG
USB Cable	**Brand Name**	Sony
	Model Name	EC300

Remark: For accessories equipped with this EUT, please refer to the following photos.

Brand Name: SONY / Model Name: BRH10



Brand Name: SONY / Model Name: BRH10

Battery



Brand Name: SONY / Model Name: BRH10



Brand Name: SONY / Model Name: BRH10

USB Cable