802.11ax-HE20 Power Spectral Density - Ant 0

Channel 1 (5955MHz)



Channel 49 (6195MHz)



Channel 93 (6415MHz)



Channel 97 (6435MHz)



Channel 105 (6475MHz)



Channel 113 (6515MHz)



802.11ax-HE20 Power Spectral Density - Ant 0

Channel 117 (6535MHz)

Channel 153 (6715MHz)

Channel 181 (6855MHz)

Channel 185 (6875MHz)



Channel 189 (6895MHz)



Channel 213 (7015MHz)



Channel 229 (7095MHz)



802.11ax-HE40 Power Spectral Density - Ant 0

Channel 3 (5965MHz)

Channel 51 (6205MHz)



Channel 91 (6405MHz)

Channel 99 (6445MHz)



Channel 107 (6485MHz)



Channel 115 (6525MHz)



Channel 123 (6565MHz)

Channel 147 (6685MHz)



802.11ax-HE40 Power Spectral Density - Ant 0

Channel 179 (6845MHz)



Channel 187 (6885MHz)



Channel 195 (6925MHz)



Channel 211 (7005MHz)



Channel 227 (7085MHz)



802.11ax-HE80 Power Spectral Density - Ant 0

Channel 7 (5985MHz)



Channel 55 (6225MHz)



Channel 87 (6385MHz)



Channel 103 (6465MHz)



Channel 119 (6545MHz)



Channel 135 (6625MHz)



802.11ax-HE80 Power Spectral Density - Ant 0

Channel 151 (6705MHz)



Channel 183 (6865MHz)



Channel 199 (6945MHz)



Channel 215 (7025MHz)



802.11ax-HE160 Power Spectral Density - Ant 0

Channel 15 (6025MHz)



Channel 47 (6185MHz)



Channel 79 (6345MHz)



Channel 111 (6505MHz)



Channel 143 (6665MHz)



Channel 175 (6825MHz)



Channel 207 (6985MHz)



802.11ax-HE20 Power Spectral Density - Ant 1

Channel 1 (5955MHz)

Channel 49 (6195MHz)



Channel 93 (6415MHz)



Channel 97 (6435MHz)



Channel 105 (6475MHz)

Channel 113 (6515MHz)



802.11ax-HE20 Power Spectral Density - Ant 1

Channel 117 (6535MHz)



Channel 153 (6715MHz)



Channel 181 (6855MHz)

Channel 185 (6875MHz)



Channel 189 (6895MHz)



Channel 213 (7015MHz)

Channel 229 (7095MHz)



802.11ax-HE40 Power Spectral Density - Ant 1

Channel 3 (5965MHz)



Channel 51 (6205MHz)



Channel 91 (6405MHz)



Channel 99 (6445MHz)



Channel 107 (6485MHz)



Channel 115 (6525MHz)



Channel 123 (6565MHz)



Channel 147 (6685MHz)



802.11ax-HE40 Power Spectral Density - Ant 1

Channel 179 (6845MHz)

Channel 187 (6885MHz)



Channel 195 (6925MHz)



Channel 211 (7005MHz)



Channel 227 (7085MHz)