802.11ax-HE40 – Ant 0	
Channel 3 (5965MHz)	
The Reference Level	The Mask Data
Channel 51 (6205MHz)	
The Reference Level	The Mask Data
Channel 91 (6405MHz)	
The Reference Level	The Mask Data
	

802.11ax-HE40 – Ant 0	
Channel 123 (6565MHz)	
The Reference Level	The Mask Data
Channel 147 (6685MHz)	
The Reference Level	The Mask Data
	
Channel 179 (6845MHz)	
The Reference Level	The Mask Data
	

802.11ax-HE80 – Ant 0	
Channel 7 (5985MHz)	
The Reference Level	The Mask Data
Channel 55 (6225MHz)	
The Reference Level	The Mask Data
	
Channel 87 (6385MHz)	
The Reference Level	The Mask Data
	

802.11ax-HE80 – Ant 0	
Channel 135 (6625MHz)	
The Reference Level	The Mask Data
Channel 151 (6705MHz)	
The Reference Level	The Mask Data
	
Channel 167 (6785MHz)	
The Reference Level	The Mask Data
	

802.11ax-HE160 – Ant 0	
Channel 15 (6025MHz)	
The Reference Level	The Mask Data
Channel 47 (6185MHz)	
The Reference Level	The Mask Data
Channel 79 (6345MHz)	
The Reference Level	The Mask Data

802.11ax-HE160 – Ant 0	
Channel 143 (6665MHz)	
The Reference Level	The Mask Data

802.11be-EHT20 – Ant 0	
Channel 1 (5955MHz)	
The Reference Level	The Mask Data
Channel 49 (6195MHz)	
The Reference Level	The Mask Data
	
Channel 93 (6415MHz)	
The Reference Level	The Mask Data
	

802.11be-EHT20 – Ant 0	
Channel 117 (6535MHz)	
The Reference Level	The Mask Data
Channel 153 (6715MHz)	
The Reference Level	The Mask Data
Channel 181 (6855MHz)	
The Reference Level	The Mask Data

802.11be-EHT40 – Ant 0	
Channel 3 (5965MHz)	
The Reference Level	The Mask Data
Channel 51 (6205MHz)	
The Reference Level	The Mask Data
Channel 91 (6405MHz)	
The Reference Level	The Mask Data

802.11be-EHT40 – Ant 0	
Channel 123 (6565MHz)	
The Reference Level	The Mask Data
Channel 147 (6685MHz)	
The Reference Level	The Mask Data
Channel 179 (6845MHz)	
The Reference Level	The Mask Data

802.11be-EHT80 – Ant 0	
Channel 7 (5985MHz)	
The Reference Level	The Mask Data
Channel 55 (6225MHz)	
The Reference Level	The Mask Data
Channel 87 (6385MHz)	
The Reference Level	The Mask Data
	

802.11be-EHT80 – Ant 0	
Channel 135 (6625MHz)	
The Reference Level	The Mask Data
Channel 151 (6705MHz)	
The Reference Level	The Mask Data
Channel 167 (6785MHz)	
The Reference Level	The Mask Data
	

802.11be-EHT160 – Ant 0	
Channel 15 (6025MHz)	
The Reference Level	The Mask Data
Channel 47 (6185MHz)	
The Reference Level	The Mask Data
Channel 79 (6345MHz)	
The Reference Level	The Mask Data

802.11be-EHT160 – Ant 0	
Channel 143 (6665MHz)	
The Reference Level	The Mask Data

802.11be-EHT320 – Ant 0	
Channel 31 (6105MHz)	
The Reference Level	The Mask Data
	

802.11be-EHT320 – Ant 0	
Channel 63 (6265MHz)	
The Reference Level	The Mask Data
	

802.11ax-HE 20 – Ant 1	
Channel 1 (5955MHz)	
The Reference Level	The Mask Data
Channel 49 (6195MHz)	
The Reference Level	The Mask Data
Channel 93 (6415MHz)	
The Reference Level	The Mask Data