6. SETUP PHOTOS

6.1. STANDARD CONFIGURATION

DYNAMIC FREQUENCY SELECTION MEASUREMENT SETUP

DFS FRONT PHOTO (STANDARD CONFIGURATION)



This report shall not be reproduced except in full, without the written approval of UL Verification Services Inc.

DFS BACK PHOTO (STANDARD CONFIGURATION)

This report shall not be reproduced except in full, without the written approval of UL Verification Services Inc.

6.2. BRIDGE MODE CONFIGURATION

DYNAMIC FREQUENCY SELECTION MEASUREMENT SETUP

DFS FRONT PHOTO (BRIDGE MODE CONFIGURATION)



This report shall not be reproduced except in full, without the written approval of UL Verification Services Inc.

DFS BACK PHOTO (BRIDGE MODE CONFIGURATION)

END OF REPORT

This report shall not be reproduced except in full, without the written approval of UL Verification Services Inc.