DRAFT

****ALL IMAGERY IS PLACEHOLDER/PRELIMINARY****

Disney Infinity [3.0 Edition]

[iOS product]

DRAFT

[ANY REQUIRED WARNINGS GO ON INSIDE/FRONT MANUAL COVER]

DRAFT

TABLE OF CONTENTS

QUICK START GUIDE XX
CONTROLS XX
TROUBLESHOOTING.....XX
SAFETY PRECAUTIONS XX
CUSTOMER SUPPORT INFORMATION ...XX
TERMS OF USE XX
FRENCH XX
SPANISH XX
PORTUGUESE XX

QUICK START GUIDE

Setting Up the Disney Infinity Base

Once removed from the packaging, the Disney Infinity Base (pictured below) needs to be placed on a stable, secure and even surface near the iOS device. Do not place on metal surfaces, or have metallic objects nearby.



A Disney Infinity Figure and Power Disc spot (Player 1)
B Disney Infinity Figure and Power Disc spot (Player 2)
C Disney Infinity Play Set Piece, Power Disc or Toy Box Expansion Game Piece spot

Pairing the Disney Infinity Base

1 The Disney Infinity Base needs to connect with the iOS device via wireless Bluetooth® technology. Make sure the iOS device is turned ON and Bluetooth® is turned ON in the Settings menu.

2 Plug in the Disney Infinity Base using the NA USB power adaptor.

3 The Disney Infinity Base will enter into pairing mode and the Blue LED light on the hexagonal spot C of the Disney Infinity Base will blink.

4 Once connected, the Blue LED light on the hexagonal spot C of the Disney Infinity Base will stop blinking.

Using the Disney Infinity Base

When a player enters gameplay, they will be prompted to place a Disney Infinity Figure on the Base after the introduction. For single player gameplay, be sure the Disney Infinity Figure is placed on the circular spot A of the Base. The Disney Infinity Play Set Piece or Toy Box Expansion Game Piece will need to be placed on the hexagonal spot C in order to enter a Play Set or Toy Box Expansion Game. For two-player gameplay, place a Disney Infinity Figure on each of the circular spots A and B to begin your adventure.

Using the Disney Infinity Power Discs

Expand your adventure with the Disney Infinity Power Discs. While playing in Play Sets or the Toy Box, place up to two circular Power Discs under a Disney Infinity Figure on the circular spots, A and/or B of the Disney Infinity Base, to power up character abilities or add a costume, team-up or event. You can also unleash new gadgets and customize your Toy Box by placing up to three hexagonal Power Discs on the hexagonal spot C.

Using the Disney Infinity Web Code Card

Use the Disney Infinity Web Code at Disney.com/Infinity to unlock new content on the web. Just enter the Web Code provided in the Disney Infinity Starter Pack.

CONTROLS

Biped Controls

Jump	A
Flight/Force Jump	A (hold)
Pick Up/Interact/Force Power	X
Combo Finisher	X (hold when prompted)
Drop Item/ Exit Vehicle	B
Block	B (hold)
Attack	Y
Special Ability	RB
Run	L stick
Camera Rotate	R stick

DRAFT

Tool/Packs Select	LB
Editor	Back button
Pause Menu	Start button
Aim/Target	LT (hold)
Shoot/Throw/Force Dash	RT

Note: Some of the Biped Controls do not apply to all characters.

Vehicle Controls	
Jump	A
Enter Vehicle/Tow/Interact	X
Attack/Honk Horn/Throw	Y
Move Forward	RT (hold)
Brake/Reverse	LT (hold)
Steer	L stick
Camera Rotate/Boost	R stick
Loadouts	LB
180 Degree Turn	RB
Drift	RT + LT + L stick

Spaceship Controls	
Take-Off/Land	A
Engage/Disengage X-foils	X
Fire Main Weapon	Y
Forward Thrusters	RT (hold)
Brake	LT (hold)
Steer	L stick
Bank Left	LB (hold)
Bank Right	RB (hold)
180 Degree Flip	R stick down
Forward Roll	R stick up
Left Barrel Roll	R stick left
Right Barrel Roll	R stick right

Editor Controls	
Place	A
Undo	Y
Exit	B
Add Favorite	X
Spark Mode	RB
Filters	LB
Move Selected Toy	L stick
Rotate Selected Toy	RT + Left stick LEFT/RIGHT
Raise/Lower Selected Toy	RT + Left stick UP/DOWN

DRAFT

Toy Scroll	D-pad LEFT/RIGHT
Toy Category Scroll	D-pad UP/DOWN
Camera Rotate	R stick

Spark Mode Controls

Move	A
Customize	Y
Delete	B
Assign Logic	X
Exit Spark Mode	RB
Move Selected Toy	L stick
Raise/Lower Selected Item	RT + L stick UP/DOWN
Camera Rotate	R stick

TROUBLESHOOTING

Disney Infinity Figure is not appearing in-game

Be sure the Base is on a flat surface and the Disney Infinity Figure is placed completely flush with the circular spot with nothing in between the Base and the Disney Infinity Figure (unless a Power Disc is being used). If a Power Disc or Power Discs are being used, be sure no more than two are used in each spot. Do not place Base on metal surfaces, or have metallic objects nearby.

How do I add a second player in Disney Infinity (3.0 Edition)?

1. Press the center **Xbox Button** on the second controller.
2. Select the second player profile or **Profile** to play as a guest.
3. Place your Disney Infinity Figure on the circular spot B on the Disney Infinity Base.
4. Press the **Start** button.
5. The game will go into split-screen mode and the second character will appear!

SAFETY PRECAUTIONS

WARNING! CHOKING HAZARD Small parts. Not suitable for children under 3 years. For your safety and the safety of others, please read the following product care information and the game manual before using this product. Keep all game manuals because they contain important information about using and caring for the product.

The USB Cable is used for power on the Disney Infinity base and does not transmit data.

SOUND PRESSURE WARNING

1) “To prevent possible hearing damage, do not listen at high volume levels for long periods.”
2) “Fully understand user manual before use.”
3) “Ensure your device is at low volume or powered off before ceasing to use device.”

DRAFT

PRODUCT CARE

(1) Only use the products with the gaming system for which they are designed. (2) Keep the products dry and away from open flames or other heat sources. (3) Do not modify or take apart the products. (4) Use a dry cloth to clean the products

Questions or issues when setting up your new products? Please refer to the game manual in your Disney Infinity Starter Pack for Customer Support details.

CUSTOMER SUPPORT INFORMATION

Internet Support

To access support for Disney Infinity on the internet, please visit our Customer Support website at **help.disney.com/Disney-Infinity**.

Game Hints and Tips

Game hints and tips are available on our Customer Support website. To view, please visit **help.disney.com/Disney-Infinity**.

Mailing Address

If you wish to write us, our address is: Disney Interactive Studios Customer Support, 1200 Grand Central Avenue, Glendale, CA 91201-8793

TERMS OF USE

DISNEY INTERACTIVE'S GENERAL TERMS OF USE GOVERNING ITS PRODUCTS AND SERVICES, INCLUDING DISNEY INFINITY, IS AVAILABLE AT WWW.DISNEYTERMSOFUSE.COM.

DRAFT

Model No.: INF-8040889

CE0890

FCC INFORMATION

FCC ID: QOF-8040889

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment and it also complies with Part 15 of the FCC RF Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

IC INFORMATION

IC: 10749A-8040889

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

DRAFT

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :
(1) l'appareil ne doit pas causer d'interférences, et
(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Legal

© Disney. *STAR WARS* © & ™ Lucasfilm Ltd. All rights reserved.

DRAFT