


# P-558

Use before reading carefully

## BT Wireless Connection

1. Turn on the speaker without TF card or USB flash; it will go into BT Wireless state directly.
2. If it has TF/USB flash or other device inserted, press and hold "MODO" button until the LED indicator blink in blue, then it will go into BT Wireless state.
3. Turn on your BT Wireless device such as cell phone or Mp3 player and find the speaker “P-558” listed, connect it to play music.
4. Turn off the speaker and then turn it on again, it will connect automatically to the last connected BT Wireless device.




## Operation guide map

### TF play




Turn on the power and put the TF card in in TF card solt it can play the music automatically the operation function can adjust the volume , switch puause and play.

### U disck play




Turn on the power and put the U disk in in U disk solt it can play the music automatically the operation function can adjust the volume , switch puause and play.

### Specification parameter

Speaker Unit: ∮45MM/4Ω3W
Frequency Response:150-20KHZ
Distortion factor: ≤0. 3%
Power bank:2200mA
output power:3w
SNR>75dB
music formate:MP3

### Connection diagram




1.Work indication light
2.mode switch/pause phone call
3.Voice discress/Previous
4.charge
5.Voice increass/next
6.TF slot
7.U disk slot
8.line in solt
9.power on/off

### USB charge/line in

Charging:with the equipment dedicate charging line, USB line putdown to MIC5PIN slot it can charge, with the equipment dedicate three to one line,put the 3.5 line to the devices line ine and long press mode switch line in state it can play the music from the equipment.

The devices






## FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.