Aj225手机支架蓝牙音箱



使用前请仔细阅读

功能简介

- 手机支架,小巧便携、易收纳
- 免提接打电话
- 蓝牙音箱功能
- 内置高容量可充电锂电池，户外使用更便携
- 低电提醒，提醒三次后关机

产品参数

蓝牙版本	V5.1	失 真 度	≤10%
蓝牙名称	AJ225	传输距离	≥10米
音箱功率	5W	信 噪 比	80dB
频响范围	65Hz-20kHz	喇叭参数	Φ40mm 4Ω 5W
电池容量	1800mAh	电源输入	5V 0.8A
产品尺寸	148x80x38mm		

接打电话

- 手机连接蓝牙音箱后,当有来电时可以双击 ❯ 键拒接。
- 当有来电时可以短按 ❯ 键接听,通话过程中短按 ❯ 键结束通话。
- 双击 ❯ 键可拨打最后一次通话的电话。

音箱使用

- 长按 ⏻ 键开机或关机，并伴有提示音，然后在手机端搜索蓝牙名称“AJ225”,连接成功后有提示音。
- 短按 — 键，音量减小，长按切换到上一曲。
- 短按 + 键，音量增加，音量最大时有提示音，长按切换到下一曲。
- 短按 ⏻ 键暂停或继续播放。
- 同时长按 + 和 — 键取消和手机连接。

音箱充电

将Type-C线插入产品背部USB孔进行充电，充电时提示灯亮红色，充满电后红灯熄灭。



产品售后服务保证卡

适用范围:

- 本产品自购买日起，正常使用情况下保证一年免费服务。若超过保质期限将收取一定零件成本费用。
- 如需更换零件的服务，依照本公司服务零件检修价目表收费。
- 在下列情况时，虽然在有效保证期间内，恕不免费保证。
  1.因天灾地震、鼠祸公害、未正常使用所导致故障或损坏的。
  2.购买后的运送、移动落下、保存不当等所造成的故障或损坏。
  3.损耗品如零附件、电池、灯珠等。
  4.保证书信息记录不完全，未填入购买日期、无购买店盖章的。
  5.特色环境不保修，如潮湿、硫磺区、海边高盐分及船上等易腐蚀地区。
  6.未按照使用说明书使用者。
  7.特殊约定销售的产品。
- 产品返厂维修时，送修时应自行妥善包装维修品，以免在运送途中造成损害。
- 自行拆装产品导致的产品故障，制造方概不负责。

尊贵的贵宾!
感谢您购买本产品,为保证您的权益,请认真填写,谢谢!

姓 名	
地 址	
电 话	
发票号码	
购买日期	
产品型号	
经 销 商	❗ 本栏请加盖经销商店章。

注意 *请妥善保留您的产品保证书，保修期需出示核对

注意事项

- 为了使用者正确使用音箱，确保音箱性能良好，请认真阅读并遵守:
- 切勿严重撞击主机
- 切勿接触苯、稀释剂等化学药品
- 请不要靠近磁场、电场
- 请避开直射光线或发热器具
- 切勿自行拆卸、修理、改造

折叠后尺寸80x120mm,双面印刷

Phone Stand Wireless Speaker

Please read carefully before use

Product Information

- Mobile phone holder, compact and portable, easy to store
- Hands-free phone calls
- Bluetooth speaker function
- Built-in high-capacity rechargeable lithium battery, more portable for outdoor use.
- Low battery reminder, switch off the phone after three reminders

Technical Parameters

Bluetooth Version	V5.1	Distortion	≤10%
Bluetooth Name	AJ225	Speaker Power	5W
Transmission Distance	≥10m	Noise Ratio	80dB
Frequency Range	65Hz-20kHz	Power Input	5V 0.8A
Speaker Parameters	Φ40mm4Ω 5W	Battery Capacity	1800mAh
Product Size	140x80x38mm		

Answer The Telephone

- When the phone is connected to the wireless speaker, you can double press the ❯ button to reject the call when there is an incoming call.
- When there is an incoming call, short press ❯ button to answer it. After the call is over, short press ❯ button to end the call.
- Double press ❯ button to dial the last call.

Speaker Operation

- Long press ⏻ button to turn on speaker and with a beep. Search bluetooth name “AJ225” on the phone.After the connection is successful，there will be a beep.
- Long press — button to switch to the previous song，short press to lower the volume.
- Long press + button to next song，short press to increase the volume.When the volume reaches the maximum，there will be a beep.
- Short press ⏻ button to pause or resume playing.
- Hold down the + and — button at the same time to cancel pairing with your phone.

Charging Instruction

Plug the Type-C cable into the USB port for charging,the red light will be on when charging,and it will go out when fully charged.



Attention:

- Please don’t charge the speaker under the temperature of 0°C-40°C.
- Not recommended for charging while using.
- Please pull out the USB cable after a full charge.
- Please don’t charge the speaker in high-humidity situation.

FCC Caution:
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception,
which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Warranty Card

Applicable for

- Since buying date, the user enjoys one year free repair services under normal use. After one year,will be charged according to each component part cost.
- In case change component part, will be charged according to our company’s component part cost list.
- The following situations without free repair services in warranty period
  1)Damage caused by natural earthquake, rat disaster, and abnormal use.
  2)Damage caused in transportation, fall, and improper storage.
  3)Consumable component, such as spare parts, batteries, light bulbs,etc.
  4)Warranty information records is not complete, no purchase date, no buying shop seal,etc.
  5)Featured using environment, such as humidity, sulfur area, high salty and on board,etc,easy corrosion area.
  6)Using not according to the instructions.
  7)Products sold by special agreement.
- When return to factory for repair, the user should make sure the product packed property to avoid any damage during transportation.
- Factory not responsible for the damages caused by the users themselves improper disassemble.