N9518

User Guide

ZTE Corporation

[UG template version 15a]

[boost_zte_N9518_ug_en_033115_d0]

Table of Contents

Contents

Table of Contents i

Introduction 1

About the User Guide 1

How to Use This Guide 1

Get Started 2

Parts and Functions 2

nano-SIM Card 3

Handling a SIM Card 3

SD Card 4

Unmount the SD Card 4

Format SD Card 4

Turn Your Phone On and Off 5

Use the Touchscreen 5

Activation and Service 7

Complete the Setup Screens 7

Basic Operations 8

Basics 8

Home Screen and Applications (Apps) List 8

Applications 8

Launch Applications 8

Enter Text 8

Touchscreen Keyboards 8

Google Keyboard 9

Swype 9

Google Voice Typing 9

Google Account 10

Create a Google Account 10

Sign In to Your Google Account 11

Google Play Store 12

Find and Install an App 13

Lock and Unlock Your Screen 13

Your Phone Interface 15
Home Screen Basics 15
Home Screen Layout 15
Extended Home Screens 16
Status Bar 16
Notifications Panel 17
Customize the Home Screen 17
Change the Wallpaper 17
Change the Theme 18
Add Shortcuts to the Home Screen 18
Add Widgets to the Home Screen 18
Add Folders to the Home Screen 19
Phone App 20
Place and Answer Calls 20
Call Using the Phone Dialer 20
Answer Phone Calls 21
Optional Services 22
Voicemail Setup 22
Contacts 23
Add a Contact 23
Search for a Contact 24
Messaging and Internet 26
Text and Multimedia Messaging 26
Send a Text Message 26
Send a Multimedia Message (MMS) 27
Save and Resume a Draft Message 28
New Messages Notification 29
Manage Message Conversations 29
Create and Send Gmail 30
Check Received Gmail Messages 31
Open New Gmail Messages 31
Open Gmail Messages 31
Email 31
Set Up an Email Account 31
Add an Email Account 32

Add an Exchange ActiveSync Account 33
Compose and Send Email 33
Open New Email Messages 34
Open Email Messages 34
Browser 35
Use the Browser 35
Camera and Video 37
Take Pictures and Record Videos 37
Take a Picture 37
Record Videos 38
View Pictures and Videos Using Gallery 38
Share Pictures and Videos 40
Send Pictures or Videos by Email 40
Send a Picture or Video by Multimedia Message 40
Send Pictures or Videos Using Bluetooth 41
Send Pictures or Videos to Drive 41
Share Pictures or Videos on Google+ 42
Send a Picture on Hangouts 42
Send Pictures or Videos to Photos 43
Send Pictures or Videos Using Wi-Fi Direct 43
Share Pictures and Videos on Facebook 44
Share Videos on YouTube 44
Useful Apps and Features 45
Navigation 45
Google Maps 45
Hangouts 46
Google Search 47
Use Google Search 47
Use Google Voice Search 48
Twitter 48
Install the Twitter App on Your Phone 48
Tweet on Twitter 48
Facebook 49
Install the Facebook App on Your Phone 49
Use Facebook 50

LinkedIn 50
Install the LinkedIn App on Your Phone 50
Sign In to Your LinkedIn Account 50
YouTube 51
View YouTube Videos 51
Post a Video to YouTube 51
Google Play Music App 51
Play Music with Google Play 52
Google Play Music Screen Layout 52
Connectivity 54
Connections Optimizer 54
Wi-Fi 55
Turn Wi-Fi On and Connect to a Wireless Network 55
Bluetooth 55
Bluetooth Information 56
Enable the Bluetooth Feature 56
Pair Bluetooth Devices 57
Connect to a Paired Bluetooth Device 58
Send Information Using Bluetooth 58
Settings 60
For Assistance 61
Boost Account Information and Help 61
Manage Your Account 61
Re-Boost 62
Index 65

Introduction

The following topics describe the basics of using this guide and your new phone.

About the User Guide

Thank you for purchasing your new ZTE Warp Elite. The following topics explain how best to use this guide to get the most out of your phone.

Before Using Your Phone

Read this guide and the Important Information booklet in the box thoroughly for proper usage.

Accessible services may be limited by subscription contract conditions.

Descriptions in the User Guide

Note that most descriptions in this guide are based on your phone's setup at the time of purchase. Unless otherwise noted, instructions begin from the phone's home screen, which is displayed by pressing the **Home Key** . Some operation descriptions may be simplified.

Screenshots and Key Labels

Screenshots in the user guide may appear differently on your phone. Key labels in the user guide are simplified for description purposes and differ from your phone's display.

Other Notations

In the user guide, the phone may be referred to either as "phone," "device," or "handset." A microSD™ or microSDHC™ card is referred to as an "SD Card" or a "memory card."

How to Use This Guide

You can easily navigate this user guide, which is displayed in a browser window that is divided into three areas.

These topics will teach you how to navigate the guide and use the features for each area.

Get Started

The following topics give you all the information you need to set up your phone and wireless service the first time.

Parts and Functions

These topics illustrate your phone's primary parts and key functions.

Phone Layout

The following illustration outlines your phone's primary external features and buttons.

Part	Description
Ambient Light and Proximity Sensor	Detects how close an object is to the surface of the screen. This is typically used to detect when your face is pressed up against the screen, such as during a phone call. While talking on the phone, the sensor detects talk activity and locks the keypad to prevent accidental keypresses.
Front Camera Lens	Takes pictures and records videos while facing the screen, and allows you to video conference.
Earpiece	Lets you hear the caller and automated prompts.
SD Card Tray	Allows you to install an optional SD card to your phone. See Insert SD Card and Remove SD Card.
nano-SIM Card Tray	Lets you install the nano-SIM card needed for connecting to the 4G network. See Insert nano-SIM Card.
Touchscreen	Displays all the information needed to operate your phone, such as the call status, the Contacts list, and the date and time. Also provides one-tap access to all of your features and applications.
Volume Button	Allows you to adjust the ringtone or media volume or adjust the voice volume during a call.
Power Button	Lets you turn the phone on or off, turn the screen on or off, restart the phone, or switch your phone to airplane mode.
Recent Apps Key	Displays a list of recently used applications.

Part	Description
Home Key	Returns you to the home screen. The light beneath the key illuminates when you charge the battery or you have a notification or alert.
Back Key	Lets you return to the previous screen, or close a dialog box, options menu, the Notifications panel, or onscreen keyboard.
Speaker	Lets you hear the different ringtones and sounds. The speaker also lets you hear the caller's voice in speakerphone mode.
Charging/micro-USB Jack	Allows you to connect the phone charger or the USB cable (included).
Microphone	Transmits your voice for phone calls or records your voice or ambient sounds for voice recordings and videos. The microphone on the back of the phone is useful for canceling ambient noise during a phone call.
Flash	Helps illuminate subjects in low-light environments when the camera is focusing and capturing a picture or video.
Back Camera Lens	Lets you take pictures and videos.
3.5 mm Headset Jack	Allows you to plug in either a stereo headset or an optional headset for convenient, hands-free conversations.

CAUTION! Inserting an accessory into the incorrect jack may damage the phone.

nano-SIM Card

The nano-SIM card is an IC card containing phone number and other customer information.

Handling a SIM Card

Keep the following in mind when handling a nano-SIM card.

- Customer is responsible for any damage caused by inserting nano-SIM card in another-brand IC card reader, etc. The company is not responsible in such case.
- Always keep the IC chip clean.
- Wipe clean with a dry, soft cloth.
- Avoid applying labels. May damage nano-SIM card.
- See instructions included with nano-SIM card for handling.
- nano-SIM card is the property of the company.

- nano-SIM card is replaceable (at cost) in case of loss/damage.
- Return nano-SIM card to the company when cancelling subscription.
- Returned nano-SIM cards are recycled for environmental purposes.
- Note that nano-SIM card specifications and performance may change without notice.
- It is recommended that you keep a separate copy of information that is stored on nano-SIM card. The company is not responsible for damages from stored information that is lost.
- Always follow emergency procedures to suspend service if your nano-SIM card or phone (nano-SIM card inserted) is lost/stolen. For details, contact Customer Service.
- Always power off phone before inserting/removing nano-SIM card.

SD Card

Your phone supports the use of an optional SD card (not included) to expand its storage capacity. It supports cards up to 32 GB. Some cards may not operate properly with your phone.

⚠️ SD Card Cautions

Data: Information stored on SD Card can become lost or changed accidently or as a result of damage. It is recommended that you keep a separate copy of important data. The company is not responsible for damages from data that is lost or changed.

Reading/Writing Data: Never power off or remove Battery while reading or writing data.

Battery Level: A low battery charge may prevent reading/writing to SD Card.

Handling SD Card: Use/store SD Cards away from the reach of infants. May cause choking if swallowed.

Unmount the SD Card

Always unmounts the SD card before removing it from your phone.

1. From home, tap **Apps** > **Settings** > **Storage**.

1. Tap **Unmount SD card** > **OK**.

❖ The icon appears in the status bar. The card is now unmounted.

Format SD Card

When you insert an optional SD card for the first time, it is recommended that you format it on your phone.

1. From home, tap **Apps** > **Settings** > **Storage**.

2. Tap **Erase external SD card** > **ERASE SD CARD > ERASE EVERYTHING**.

   - If you have set up a screen lock, you will be prompted to draw the pattern or enter the password or PIN. See Screen Lock.

❖ All data on the SD card is erased, and the card is formatted for use on your phone .

Turn Your Phone On and Off

The instructions below explain how to turn your phone on and off.

Turn Your Phone On

- Press and hold the **Power Button**.

❖ Your phone will power on.

- The first time you turn the phone on, you will see the startup screens. See Complete the Setup Screens for details.
- If your phone is not yet activated, see Activate Your Phone for more information.

Turn Your Phone Off

1. Press and hold the **Power Button** to open the phone options menu.

2. Tap **Power off** to turn the phone off.

❖ Your phone will power off.

Your screen remains blank while your phone is off (unless the battery is charging).

Use the Touchscreen

Your phone's touchscreen lets you control actions through a variety of touch gestures.

Tap or Touch

When you want to type using the onscreen keyboard, select items onscreen such as application and settings icons, or press onscreen buttons, simply tap or touch them with your finger.

Touch and Hold

To open the available options for an item (for example, a contact or link in a Web page), touch and hold the item.

Swipe or Slide

To swipe or slide means to quickly drag your finger vertically or horizontally across the screen.

Drag

To drag, press and hold your finger with some pressure before you start to move your finger. While dragging, do not release your finger until you have reached the target position.

Flick

Flicking the screen is similar to swiping, except that you need to swipe your finger in light, quick strokes. This finger gesture is always in a vertical direction, such as when flicking the contacts or message list.

Rotate

For most screens, you can automatically change the screen orientation from portrait to landscape by turning the phone sideways. When entering text, you can turn the phone sideways to bring up a bigger keyboard. See Touchscreen Keyboards for more details.

Note: The auto-rotate feature needs to be enabled for the screen orientation to automatically change. From home, tap > **Settings** > **Display** > **Auto-rotate screen** > **Rotate the contents of the screen**.

Tip: You can also access the screen rotation setting from the notifications window. Pull down the status bar and tap **Auto Rotate** to select or deselect the option.

Pinch and Spread

“Pinch” the screen using your thumb and forefinger to zoom out or “spread” the screen to zoom in when viewing a picture or a Web page. (Move fingers inward to zoom out and outward to zoom in.)

Activation and Service

Before using your phone, you must set up your service with Boost Mobile. You will need your phone's serial number (MEID), printed on a sticker inside the battery compartment.

For more information about your Boost Mobile account, see Boost Account Information and Help.

Create Your Account and Pick Your Plan

Set up your Boost Mobile account.

1. From your computer, visit boostmobile.com/activate.
2. Enter your phone's MEID and click **start activation process**.
   - Your phone's MEID (serial number) is printed on the sticker located on the back of your phone in the battery compartment. This number can also be found on the bottom panel of the phone's package.
3. Follow the remaining instructions to choose your plan and select a payment method.
4. Follow the activation instructions below and you'll be able to start using your phone.

Note: You can also activate by phone by calling **1-888-BOOST-4U** (1-888-266-7848) from any other phone.

Activate Your Phone

After setting up your account on boostmobile.com, simply turn your device on. Your device is designed to activate automatically. If you are swapping from another Boost Mobile device to a new one, be sure to turn off the old device before swapping the serial number (MEID). Once the MEID swap is complete, turn on the new device and the programming information will be pushed to your device automatically.

You can also start the activation process manually.

- From home, tap **Apps** > **Settings** > **Activate this device**.

Complete the Setup Screens

The setup screens help you set up certain features and preferences on your phone. Once your phone has been turned on, you will see a Welcome message. You can then complete the setup process.

Note: You may be able to complete the setup screens before your phone has been activated on your account.

Note: On the Welcome screen, there may also be an **Accessibility** button. If you are visually impaired or hard of hearing, tap **Accessibility** to change the accessibility settings.

Note: You do not need to sign up for a Google Account to use your phone. However, to download apps from the Google Play Store app, you must link your phone to a Google Account.

Basic Operations

The following topics outline basic features and operations of your phone.

Basics

The following topics offer an overview of your phone's basic operations.

Home Screen and Applications (Apps) List

Most of your phone's operations originate from the home screen or the apps list.

For information about using the home screen, see Home Screen Basics.

Applications

The following topics describe how to access the applications (apps) list and launch apps on your phone.

Launch Applications

All installed apps can be accessed and launched from the apps list.

1. From home, tap **Apps** .

   ❖ The apps list opens.

2. Tap and app icon to launch the corresponding application.

Enter Text

You can type on your phone using one of the available touchscreen keyboards or Google voice typing.

Touchscreen Keyboards

Your phone offers you a choice of four touchscreen keyboards for entering text. The keyboard appear automatically onscreen when you tap a text entry field, and they can be used in either portrait or landscape mode. You can also use the Google Voice typing option to enter text using your voice (see Google Voice Typing for details).

The methods available include:

- **Google keyboard** lets you use a traditional QWERTY setup to enter text. Additional options expand your ability to enter text faster and more accurately. See Google Keyboard for details.
- **Swype** lets you enter letters and words in one continuous motion by swiping your finger across the letters. See Swype for details.
- **TouchPal X** lets you use Curve® to speed up text input by replacing key-tapping gesture with a tracing gesture where you move your finger from letter to letter without lifting the finger until you reach the end of each word. See TouchPal X for details.
- **Japanese IME** lets you enter Japanese and English text as well as numbers and symbols. See Japanese IME for details.

Note: Keyboard layouts and options may change depending on where you're using them. For example, if you're entering text to do a Web search, a search icon may be available instead of an enter key.

Note: Along with the pre-installed keyboards, you can download additional keyboard options from Google Play Store. See Find and Install an App for details.

To change the input method:

1. Tap a text entry field, so that a keyboard displays on the screen.
2. Slide the status bar down and tap **Change keyboard**.
3. Select an available input method.

Note: If you cannot find the input keyboard that has been installed, it may have been disabled. To enable it, from the home screen, tap **Apps** > **Settings** > **Language & input** > **Current Keyboard** > **CHOOSE KEYBOARDS** and tap the input keyboard.

Google Keyboard

The Google keyboard offers a traditional QWERTY keyboard setup for entering text by tapping keys (like on a computer), along with enhancements and options that allow you to enter text faster and more accurately, such as continuous key input, personalized usage dictionaries, and more.

Swype

The Swype™ keyboard lets you enter words by drawing a path from letter to letter in one continuous motion. When you lift your finger after the last letter of a word, a space is automatically added.

Google Voice Typing

Google Voice typing uses Google voice recognition to convert speech to text.

To use Google Voice typing:

1. Slide the status bar down when entering text and tap **Change keyboard** > **Google voice typing**.

   – or –

Tap to access the voice typing feature when you are using the Google keyboard.

2. When you see the microphone image, speak what you want to type. The phone will work on your speech and display the transcription.

3. Continue entering text or touch **DELETE** to cancel the last dictated text.

Tip: Say "comma," "period," "question mark," "exclamation mark," or "exclamation point" to enter punctuation.

Google Account

You will need a Google Account to access several phone features such as Gmail, Google Maps, Hangouts, and the Google Play applications. Before you are able to access Google applications, you must enter your account information. These applications sync between your phone and your online Google Account.

Google Account Cautions

Be sure not to forget your Google Account ID or password.

Create a Google Account

If you do not already have a Google Account, you can create one online or using your phone.

Note: You can also create and sign into your Google/Gmail account through your phone's Setup application.

Note: Although you need a Gmail account to use certain features of your phone, such as Google Play, you do not need to use Gmail as the default account for your phone.

Create a Google Account Online

1. From a computer, launch a Web browser and navigate to google.com.

2. On the main page, click **Sign in** > **Create an account**.

3. Follow the onscreen prompts to create your free account.

4. Look for an email from Google in the email box you provided, and respond to the email to confirm and activate your new account.

Create a Google Account Using Your Phone

1. From home, tap **Apps** > **Settings** > **Accounts** > **Add account** > **Google**.

2. Tap **OR CREATE A NEW ACCOUNT**.

3. Enter your **First name** and **Last name**, and then tap **NEXT >**.

4. Enter a desired **Username**, and then tap **NEXT >**. Your phone then connects to Google and checks username availability. Change the username and try again if it is already in use.

5. When prompted, enter and reenter a password, and then tap **NEXT >**.

6. Confirm your country and phone number and tap **NEXT >**. The phone number can help you get back into your Google Account in case you forget your password. You can also tap **REMIND ME LATER** to set up the phone number later.

Note: To verify your phone number, Google will send a one-time text message to your phone. Tap **SEND IT** and wait for the verification to complete automatically.

7. On the Privacy and Terms screen, tap **AGREE >**. Now your Google Account is ready to go. Tap **NEXT >** to go to the next screen.

8. On the Google services screen, select your Google service options and tap **NEXT >**.

9. Select **Add credit or debit card** and tap **NEXT >** to set up your billing information for purchasing apps, games, movies, and books in the Google Play Store app from your phone. You can also select **Remind me later** and tap **NEXT >**.

❖ You are signed in to your Google Account, and your phone will synchronize the selected items.

Sign In to Your Google Account

If you have a Google Account but have not yet signed in with your phone, follow these instructions to sign in to your Google Account.

1. From home, tap **Apps** > **Settings** > **Accounts** > **Add account > Google**.

2. Enter your existing Google Account username or email, and then tap **NEXT >**.

3. Enter your password, and then tap **NEXT >**.

4. After your phone connects with the Google servers, tap **ACCEPT >**.to agree to Google privacy policy and terms of service.

5. Select **Add credit or debit card** and tap **NEXT >** to set up your billing information for purchasing apps, games, movies, and books in the Google Play Store app from your phone. You can also select **Remind me later** and tap **NEXT >**.

6. Select the items you would like to sync with your phone and then tap **NEXT >**. Your phone will synchronize the selected items with Google servers.

❖ You are signed in to your Google Account, and your phone will synchronize the selected items.

Google Play Store

Google Play™ is the place to go to find new Android apps, books, movies, and music for your phone. Choose from a wide variety of free and paid content ranging from productivity apps and games to bestselling books and blockbuster movies and music. When you find what you want, you can easily download and install it on your phone.

To access the Google Play store app, you must first connect to the Internet using your phone's Wi-Fi or mobile data connection and sign in to your Google Account. See Browser and Sign In to Your Google Account for details.

Installing Applications

Many different kinds of applications can be installed on your phone from Google Play (provided by Google Inc.). The company is not responsible in any way for user-installed applications (quality, reliability, legality, fitness for a purpose, credibility, accuracy, etc.) or resulting malfunctions (viruses, etc.).

Important: Our policies often do not apply to third-party applications. Third-party applications may access your personal information or require us to disclose your customer information to the third-party application provider. To find out how a third-party application will collect, access, use, or disclose your personal information, check the application provider's policies, which can usually be found on their website. If you aren't comfortable with the third-party application's policies, don't use the application.

Find and Install an App

When you install apps from Google Play app and use them on your phone, they may require access to your personal information (such as your location, contact data, and more) or access to certain functions or settings of your phone. Download and install only apps that you trust.

1. From home, tap **Play Store** .
2. When you open the Google Play store app for the first time, the Terms of Service window will appear. Tap **ACCEPT** to continue.
3. Browse through the categories (**Apps**, **Games**, **Movies & TV**, **Music**, **Books**, or **Newsstand**), find an item you're interested in, and tap the name. Browse through featured apps. Scroll through the list of featured apps when you open Google Play.
   - Search for an app. Tap on the Google Play home screen, enter the name or type of app you're looking for, and then tap the search key on the keyboard.
4. Tap an app to read a description about the app and user reviews.
5. Tap **INSTALL** (for free applications) or the price (for paid applications).

Note: You need a Google Wallet account to purchase items on Google Play. See Google Wallet to set up a Google Wallet account if you do not have one.

6. The subsequent screen notifies you whether the app will require access to your personal information or access to certain functions or settings of your phone. If you agree to the conditions, tap **ACCEPT** (for free apps) or **ACCEPT** and then **BUY** (for paid apps) to begin downloading and installing the app.
   - If you selected a paid application, after tapping **OK**, you're redirected to the Google Wallet screen to pay for the application before it's downloaded to your phone.

❖ The selected app is downloaded and installed on your phone.

Warning: Read the notification carefully! Be especially cautious with applications that have access to many functions or a significant amount of your data. Once you tap **ACCEPT** on this screen, you are responsible for the results of using this item on your phone.

Purchasing Applications

Purchase apps at your own risk. The company is not responsible for any disadvantage resulting for user or third parties.

Lock and Unlock Your Screen

Your phone allows you to quickly turn the screen off when not in use and to turn it back on and unlock it when you need it.

Turn the Screen Off When Not in Use

- To quickly turn the screen off, press the **Power Button**. Pressing the **Power Button** again or receiving an incoming call will turn on your phone screen and show the lock screen.

To save battery power, the phone automatically turns off the screen after a certain period of time when you leave it idle. You will still be able to receive messages and calls while the phone's screen is off.

Note: For information on how to adjust the time before the screen turns off, see Display Settings.

Turn the Screen On and Unlock It

1. To turn the screen on, press the **Power Button**.

   ❖ The lock screen appears.

2. Touch and hold an empty area of the screen to unlock it.

   ❖ The screen is unlocked.

   - If you have set up a screen lock, you will be prompted to draw the pattern or enter the password or PIN. See Screen Lock.

Tip: You can also swipe left on the lock screen to launch the camera.

Your Phone Interface

The following topics describe how to use and customize your phone's home screen, understand the status bar, and use the notifications panel.

Home Screen Basics

The home screen is the starting point for your phone's applications, functions, and menus. You can customize your home screen by adding application icons, shortcuts, folders, widgets, and more.

Home Screen Layout

Your home screen extends beyond the initial screen. Swipe the screen left or right to display additional screens.

Item	Description
Status bar	The status bar displays icons to notify you of phone and service status information on the right side (such as signal strength, battery status, Wi-Fi and data connectivity, ringer status, and time) and notifications on the left side (such as notifications for incoming messages, missed calls, and application updates).
Widget	Widgets are self-contained onscreen apps that reside on your phone's home screen.
Application icons	Application icons are shortcuts to favorite applications. You can add and remove these shortcuts as you wish.
Folder	You can group shortcuts on the home screen into folders for convenient access.
Primary shortcuts	Primary shortcuts are application shortcuts that appear in the same location on all of your phone's home screens. These are customizable except for the Applications (Apps) shortcut, which remains static.
Applications list (Apps)	Tap to open the applications (apps) list. The apps list key is a primary shortcut available from all home screens.
Recent Apps Key	Tap to display a list of recently used applications.
Home Key	Tap to display the main home screen.

Item	Description
Back Key	Tap to return to the previous screen.

Note: Your phone's home screens cycle through so that you can keep swiping in one direction and make it back to the main home screen. The small circles above the primary shortcuts let you know your current screen position.

Tip: Tap the **Home Key** to return to the main home screen from any other screen.

Extended Home Screens

In addition to the main home screen, your phone features extended home screens to provide more space for adding icons, widgets, and more. Tap the **Home Key** to display the main home screen and then drag across the screen to move from the main screen to an extended screen.

There are up to eight and at least two extended screens available in addition to the main home screen.

- If you are not already using the maximum number of screens for your phone, you can add more screens when adding a shortcut or widget to the home screen. See Add Shortcuts to the Home Screen and Add Widgets to the Home Screen.
- If there are more than two extended screens and you remove all contents from one screen, the empty screen is deleted automatically.
- While on an extended screen, tap the **Home Key** to return to the main home screen.

To delete or set the home screens:

- From any home screen, touch and hold an empty area to display thumbnail images of all screens.
  - To delete a home screen, tap on the corner of its thumbnail and select **OK**.
  - To set a home screen as the main home screen, tap at the bottom of its thumbnail.
  - To change the order of the screens, touch and hold a thumbnail and drag it left or right to a new position.

Status Bar

The status bar at the top of the home screen provides phone and service status information on the right side and notification alerts on the left. To view the notifications window or access the quick settings menu, tap the status bar and drag it down.

Notifications Panel

Drag the status bar down to open the notifications panel. From there, you can check notifications, download updates, open messaging apps, use the quick settings menu, and more.

Open the Notifications Panel

- Drag the status bar down. (Slide your finger down from the top of the screen.)

  - The notifications panel opens. To check notifications, tap an item in the list.

Close the Notifications Panel

- Drag the notifications panel up. (Slide your finger up from the bottom of the screen.)

  – or –

- Tap the **Back Key** to close the notifications panel.

Notifications Panel Layout

The notifications window gives you access both to notifications and the quick settings menu.

Customize the Home Screen

Learn how to set the wallpaper or theme, and add, move, or remove shortcuts, widgets, and folders from the home screen.

Operations for Rearranging the Home Screen

- **Moving Widgets and Icons**: From home, touch and hold an item and then drag it to the desired location.
- **Deleting Widgets and Icons**: From home, touch and hold an item and then drag it to **Delete** .
- **Displaying the Home Screen Menu**: From home, touch and hold an empty space to display the home screen menu. Menu options include Widgets, Wallpapers, Theme, and Effect.

Change the Wallpaper

Select and assign your phone's background wallpaper.

1. From home, touch and hold an empty space, and then tap **Wallpapers**.

- You can also access the wallpaper menu through settings. From home, tap **Apps** > **Settings** > **Display** > **Wallpaper**.

2. Tap an option to select the wallpaper.
3. If necessary, tap **Set wallpaper**.

❖ The wallpaper is set.

Note: If you select **Gallery**, you will need to select an album and a picture. Once selected, use the crop tool to resize and position the image and then tap .

Change the Theme

Each theme contains a unique set of icons. You can change the theme to the one you like.

1. From home, touch and hold an empty space, and then tap **Theme**.
2. Tap the theme you like.

❖ The theme is set.

Add Shortcuts to the Home Screen

You can add shortcuts for quick access to favorite apps from the home screen.

1. From home, tap **Apps** .

❖ The Apps list opens.

2. Touch and hold an app icon.

❖ The icon will disengage and you will see thumbnails of your home screens.

3. Drag the icon to an empty location on one of the home screens.

Note: If there are less than eight extended home screens, you can add a new extended home screen while you add a shortcut. Just drag the app icon to the right edge of the screen and drop it after you reach the right-most screen.

❖ The shortcut is added to the home screen.

Add Widgets to the Home Screen

You can add widgets to your phone's home screen. Widgets are self-contained apps that display on a home screen. Unlike a shortcut, a widget works like as an onscreen application. There are all kinds of

widgets, including links to a specific contact, Internet bookmarks, Gmail and email accounts, and many others.

1. From home, touch and hold an empty space, and then tap **Widgets**.

2. Touch and hold a widget icon.

   ❖ The icon will disengage and float with your finger.

3. Drag the icon to an empty location on one of the home screens.

Note: If there are less than eight extended home screens, you can add a new extended home screen while you add a widget. Just drag the widget icon to the right edge of the screen and drop it after you reach the right-most screen.

   ❖ The widget is added to the home screen.

Add Folders to the Home Screen

You can group home screen shortcuts into folders for convenient access.

1. From home, touch and hold a shortcut you want to place in a folder.

2. Drag the shortcut to **Folder** at the top left and release it.

   ❖ A new folder is created.

3. To add more app shortcuts to the folder, touch and hold a shortcut and drag it on top of the new folder.

   ❖ The new shortcut is added to the folder.

Change Folder Names

Once you have added folders, you can change the name easily from the folder display.

1. From home, tap the folder to open it, and then tap the folder name.

2. Type a new name and then tap **Done**.

Phone App

The following topics outline the use of your device's phone app to place and receive calls, use voicemail, set up and manage contacts, and more.

Place and Answer Calls

The following topics describe how to directly dial calls, how to answer incoming calls, and how to use the in-call screen options.

Adjust In-Call Volume

- **Adjusting Call Volume**: Press the **Volume Button** during the call.

Troubleshooting

Question: Difficulty during call.

Answer 1: It may not be possible to make a call properly in a noisy location.

Answer 2: When calling using Speaker, check the call volume. Raising the call volume may make calling difficult.

Question: Sound pops momentarily during a call.

Answer: Are you changing location while calling? Sound pops when signal is weak and the phone switches to a different area.

⚠️ Emergency Call Cautions

Emergency calls are restricted in Airplane mode.

Call Using the Phone Dialer

The most "traditional" way to place a call is by using the phone's dialer screen.

1. From home, tap **Phone** > to display the dialer screen.

   ❖ The dialer screen opens.

2. Tap the number keys on the dialpad to enter the phone number.

   - As you enter digits, Smart Dial searches for contacts that match. If you see the number you want to dial, tap it to place the call immediately without entering the rest of the number.

3. Tap to call the number.

   ❖ The phone dials the number. The call begins when the other party answers.

4. To end the call, tap .

   The call ends.

Troubleshooting

Question: Call does not connect.

Answer 1: Was the number dialed using the area code? If not, try dialing using the full 10-digit number including the area code.

Answer 2: Are you in an area with poor wireless coverage? Try calling again from another area.

Answer Phone Calls

The following information lets you know how to answer incoming calls, mute the ringer on incoming calls, reject incoming calls, and more.

When you receive a phone call from a contact, the Incoming call screen appears and displays the caller ID icon, name, and phone number of the calling party. When you receive a phone call from someone who is not stored in Contacts, only the default caller ID icon and phone number appear on the Incoming call screen.

Note: If your phone is turned off, all calls automatically go to voicemail.

Answer an Incoming Call

1. When a call arrives, drag down to answer it.

   ❖ The call begins.

2. To end the call, tap .

   ❖ The call ends.

Mute the Ringing Sound

- Press the **Power Button** or the **Volume Button** to mute the ringer without rejecting the call.

Reject an Incoming Call

- When a call arrives, drag up to reject it.

  ❖ The ringtone or vibration will stop and call will be sent directly to voicemail.

Reject a Call and Send a Text Message

You can reject an incoming call and automatically send a text message to the caller.

1. When a call arrives, drag up from the bottom of the screen.
   - ❖ You will see a list of preset text messages.
2. Tap one of the messages to send it to the caller.
   - ❖ The selected message will be delivered to the caller.
     - You can edit the reject messages through the Call settings menu. From the Phone app, tap **Menu** > **Settings** > **General settings** > **Quick responses** and tap a message to edit it.

Optional Services

The following topics outline additional voice-related services available with your phone, including call services, voicemail, and more.

Voicemail Setup

You should set up your voicemail and personal greeting as soon as your phone is activated. Always use a password to protect against unauthorized access. Your phone automatically transfers all unanswered calls to your voicemail, even if your phone is in use or turned off.

1. From home, tap **Phone** > to display the dialer screen.
2. Touch and hold to dial your voicemail number.
   - ❖ Your phone dials the voicemail access number.
3. Follow the system prompts to:
   - Create your password.
   - Record your name announcement.
   - Record your greeting.

Important: Voicemail Password – It is strongly recommended that you create a password when setting up your voicemail to protect against unauthorized access. Without a password, anyone who has access to your phone is able to access your voicemail messages.

Contacts

The Contacts application lets you store and manage contacts from a variety of sources, including contacts you enter and save directly in your phone as well as contacts synchronized with your Google Account, your PC, compatible email programs (including Exchange Server), and your Facebook friends.

Contacts Cautions

Information saved in Contacts may be lost or changed if the battery is removed for a long period or left uncharged. Accident or malfunction may also cause loss or change to information. It is recommended that you keep a separate copy of contacts and other important information. The company is not responsible for any damages from lost or changed contacts.

Add a Contact

You can add contacts from your phone's Contacts or Phone application. Enter details such as name, phone numbers, email addresses, mailing addresses, and more.

1. From home, tap **Apps** > **Contacts** .

   ❖ You will see the CONTACTS list.

2. Tap to add a contact.

   ❖ The Add new contact screen appears.

3. If you have multiple account types associated with your phone, tap the field above the name and select a contact type.
   - Select **Google** if you want to save contacts to your Google Account; these will be synced automatically with your Google Account online.
   - Select **Phone-only, unsynced** as the sync account if you want your contacts on your phone only; they will not be synced with your Google Account.

4. Use the keyboard to enter as much information as you want.
   - Contact photo: Tap to assign a picture to the contact.
   - Name
   - Phone
   - Email

- Address
- Ringtone
- Notification ringtone
- Special dates
- Groups
- Add another field: Tap **ADD ANOTHER FIELD** to include additional information such as IM address, Notes, Nickname, Website, etc.

Note: To select a type (label) for a phone number, email address, or postal address (such as Mobile, Home, Work, etc.), tap the type to the right of the field and select the appropriate type.

Note: To add more phone numbers, email addresses, etc., tap **Add new** below the entry field. To delete an entry, tap beside it.

5. When you have finished adding information, tap on the top left.

❖ The contact is added.

Save a Phone Number

You can save a phone number to Contacts directly from the phone dialpad.

1. From home, tap **Phone** > .

2. Enter a phone number and tap **Add to contacts**.

3. To add the number to an existing contact, scroll the contact list and tap the contact. To add a new contact, tap .
   - For an existing contact, tap the contact name and select a number type for the new number.
   - For a new contact, enter the name and any additional information.
4. Tap .

❖ The contact is added.

Search for a Contact

You can easily search for the contact you need.

1. From home, tap **Apps** > **Contacts** .

2. Tap at the top right to open the **Find contacts** field.

3. Input the contact name, phone number, or any other contact information. The contacts matched will be listed.

Messaging and Internet

With wireless service and your phone's messaging and data capabilities, you have the opportunity to share information through many different channels and accounts, including Gmail (Google), personal and corporate email, text and multimedia messaging, social networking accounts, and Hangouts.

Text and Multimedia Messaging

With Text Messaging (SMS), you can send and receive instant text messages between your wireless phone and another messaging-ready phone.

Multimedia messages, or MMS, can contain text and pictures, recorded voice, audio or video files, picture slideshows, contact cards (vCard), or appointments (vCalendar).

See your service plan for applicable charges for messaging.

Send a Text Message

Quickly compose and send text messages on your phone.

1. From home, tap **Messaging** .
2. On the Messaging screen, tap . The New message screen opens.
3. Fill in one or more recipients. You can:
   - Enter phone numbers directly in the To field. If you're sending the message to several phone numbers, tap **Next** or the return key on the keyboard after entering each number. As you enter information, any matching phone numbers from your contacts list are displayed. Tap a match to enter that number or address directly.
   - Tap the icon, and then select the contacts to whom you want to send the message. You can also select from call log, favorite contacts, or contact groups as recipients. When you have selected all the message recipients, tap **OK**.
   - Enter the first few letters of the recipient's name to display a matching list of names from your stored contacts. Tap a match to add the recipient.
4. Tap the "Type message" box and then start composing your message.

Note: A counter appears above the **Send** button ( ) to tell you how many characters are left. Once you go over the 160-character limit, a new message is created but automatically joined into one when received.

5. When done, tap **Send** to send the text message.

Send a Multimedia Message (MMS)

When you need to add a little more to a text message, you can send a multimedia message (MMS) with pictures, voice recordings, audio or video files, contact cards (vCard), or appointments (vCalendar).

1. From home, tap **Messaging** .
2. On the Messaging screen, tap . The New message screen opens.
3. Fill in one or more recipients. You can:
   - Enter phone numbers directly in the To field. If you're sending the message to several phone numbers, tap **Next** or the return key on the keyboard after entering each number. As you enter information, any matching phone numbers from your contacts list are displayed. Tap a match to enter that number or address directly.
   - Tap the icon, and then select the contacts to whom you want to send the message. You can also select from call log, favorite contacts, or contact groups as recipients. When you have selected all the message recipients, tap **OK**.
   - Enter the first few letters of the recipient's name to display a matching list of names from your stored contacts. Tap a match to add the recipient.

Note: You can add a subject line by tapping **Menu** > **Add subject**.

4. Tap the "Type message" box, and then start composing your message.
5. Tap .
6. In the Attach window, select from the following file attachments:
   - **Pictures.** Select a picture to attach to your MMS.
   - **Capture picture.** Open the camera and take a photo to attach to your MMS.
   - **Videos.** Select a video clip to attach to your MMS.
   - **Capture video.** Open the camcorder and shoot a video clip to attach to your MMS.
   - **Audios.** Select an audio file to attach to your MMS.
   - **Record audio.** Open Sound Recorder and record an audio file to attach to your MMS.
   - **Slideshow.** See "Create a Slideshow" for details.
   - **Files.** Open File Manager and select a file to attach to your MMS.
   - **Insert contacts.** Select a contact entry and add it to your MMS as a vCard attachment.
7. To make changes to your attachment, tap **REPLACE** or **REMOVE**.
8. Tap **Send** or **SEND** to send the MMS message.

Create a Slideshow

In a multimedia message, you can add slides, each containing a picture, video, or audio.

1. In the multimedia message you're composing, tap > **Slideshow**.
2. On the Edit slideshow screen, tap **Slide 1**.

Note: You can tap **Add slide** to add more slides.

3. To compose your slideshow, do any of the following:
   - Add a picture. Tap **ADD PICTURE**, > **Add picture** or **Capture picture**.
   - Add a video. Tap **Menu** > **Add video** or **Capture video**. (You cannot add both a picture and a video on the same slide.)
   - Add music or a voice recording. Tap **Menu** > **Add music** and then tap **Audios** or **Record audio**.
   - Add a caption. Tap the "Type message, or leave blank" box.
   - Add some preset text. Tap **Menu** > **Quick Text**.
   - Insert a smiley to the caption. Tap **Menu** > **Insert smile**.
   - Set text layout. Tap **Menu** > **Layout**.
   - Preview your slide. Tap **Menu** > **Preview**.
   - Remove the caption on the slide. Tap **Menu** > **Remove text**.
   - Set duration for a slide. Tap **Menu** > **Duration**.
   - Add a new slide. Tap **Menu** > **Add slide**.
   - View the next or previous slide. Tap or .
4. When you have finished composing the multimedia message, tap **SEND**.

Tip: To compose a slideshow, you can also simply attach multiple items separately to the MMS message. Tap and select a file type, location, and file and then repeat it for additional slides. Your phone will automatically compile a slideshow.

Save and Resume a Draft Message

While composing a text or multimedia message, tap the **Back Key** to automatically save your message as a draft.

To resume composing the message:

1. From home, tap **Messaging** .
2. On the Messaging screen, the draft messages are marked with a red word "Draft" next to them. You can also tap **Menu** > **Drafts** to view them.
3. Tap the message to resume editing it.
4. When you finish editing the message, tap **Send** or **SEND**.

New Messages Notification

Depending on your notification settings, the phone will play a ringtone, vibrate, or display the message briefly in the status bar when you receive a new text or multimedia message. To change the notification for new text and multimedia messages, see Text and MMS Options for details.

A new message icon (/) also appears in the notifications area of the status bar to notify you of a new text or multimedia message. The Messaging application icon (if shown on the home screen) also displays the number of new messages .

- To open the message, drag the status bar down to open the notifications panel. Tap the new message to open and read it. For information on reading and replying to messages see Manage Message Conversations.

Manage Message Conversations

Text and multimedia messages that are sent to and received from a contact (or a number) are grouped into conversations or message threads in the Messaging screen. Text or MMS conversations let you see exchanged messages (similar to a chat program) with a contact on the screen.

Read a Text Message

- Do one of the following:
  - On the Messaging screen, tap the text message or conversation to open and read it.
  - If you have a new message notification, drag the status bar down to open the notifications panel. Tap the new message to open and read it.

To return to the Messaging screen from a conversation, tap the **Back Key** .

Note: To view the details of a particular message, in the conversation, tap the message to open the options menu, and then tap **View details**.

Note: If a message contains a link to a Web page, tap the link in the message and then tap **Visit** to open it in the Web browser.

Note: If a message contains a phone number, tap the phone number or email address in the message to dial the number, send a message, send an email, or add it to your contacts.

View a Multimedia Message (MMS)

1. From home, tap **Messaging** .
2. On the Messaging screen, tap a multimedia message or conversation to open it.
3. Tap the attachment to open it. If the attachment is a vCard contact, touch View or Import to view the contact or import it to your contacts. For more information, see Contacts. If the attachment is a vCalendar file, you can import the calendar event. For information on using Calendar, see Calendar.
4. To save the attachment to device memory or a memory card, touch and hold the message with attachment, and then tap **Save attachment** on the options menu.

Note: When Auto-retrieve in MMS settings is disabled, only the message header is downloaded. To download the entire message, tap the **Download** button at the right side of the message. For details, see Text and MMS Options.

Note: If you are concerned about the size of your data downloads, check the multimedia message size before you download it.

Create and Send Gmail

Use Google's Gmail service and your Google Account to send, receive, and manage your Gmail messages. Before using Gmail, you must register a Google (Gmail) Account on your phone. See Google Account for details.

Use your phone to create and send Gmail messages.

1. From home, tap **Apps** > **Gmail** . If prompted, tap **TAKE ME TO GMAIL**.
   - ❖ The Gmail inbox opens.
2. In the inbox, tap **Compose** .
   - ❖ The Gmail composition window opens.
3. Enter the message recipient(s), subject, and message, and then tap **Send** .
   - ❖ The Gmail message is sent.

Gmail Composition Options

- **Adding Cc/Bcc**: In the mail composition window, tap , and then add recipients.
- **Attaching Pictures or Videos**: In the mail composition window, tap > **Attach file** or **Insert from Drive**. Locate and then tap the picture or video you want to attach.

- **Save as a Draft (Send Later)**: While composing your message, tap **Menu** > **Save draft**. The message is saved as a draft for later.

- **Delete Mail Being Composed**: In the mail composition window, tap **Menu** > **Discard** > **DISCARD**.

Note: To view your draft email messages, at the top left of the inbox, tap > **Drafts**.

Note: To view your sent messages, at the top left of the inbox, tap > **Sent**.

Check Received Gmail Messages

Your phone allows you to access, read, and reply to all your Gmail messages.

Open New Gmail Messages

When new Gmail arrives, you will see / in the status bar.

1. Drag the status bar down to display the notifications window.
2. Tap the new message from the notifications window.
   - ❖ The new Gmail message opens.
     - ▪ If you have two or more new Gmail messages, tapping the notification opens the Gmail inbox.

Open Gmail Messages

You can also read and reply to all your Gmail messages from the Gmail inbox.

1. From home, tap **Apps** > **Gmail** .
   - ❖ The Gmail inbox opens.
2. Tap the message thread you want to view.
   - ❖ The message thread opens, with the newest message displayed.

Email

Use the Email application to send and receive email from your webmail or other accounts, using POP3 or IMAP, or access your Exchange ActiveSync account for your corporate email needs.

Set Up an Email Account

Your phone supports several types of email accounts and allows you to have multiple email accounts set up at one time.

Before setting up an email account, make sure you have the username (user ID), password, server name, etc., so you can get set up successfully.

1. From home, tap **Apps** > **Email**.

   ❖ The Account setup screen for adding an account appears if no email account has been previously set up.

2. Follow the onscreen instructions to set up your email account.

   ❖ The email account is set up and you will begin receiving email.

Add an Email Account

You can add several types of personal email accounts, such as POP3 and IMAP accounts, on your phone.

Add an Email Account from the Email App

You can add email accounts directly from the email app, even if you have another email account set up.

1. From home, tap **Apps** > **Email**.

   ❖ The email inbox opens.

2. Tap **Menu** > **Settings**.
3. Tap **ADD ACCOUNT**.
4. Follow the onscreen instructions to complete the account setup.

   ❖ The email account is added and you will begin receiving email for the account.

Add an Email Account from the Settings Menu

You can also set up email accounts from the Settings > Accounts menu.

1. From home, tap **Apps** > **Settings** > **Accounts** > **Add account** > **Email**.

2. Select an email server. Tap **Others** if the server you use is not listed.
3. Enter the **Email address** and **Password** for the email account and then tap **Next**.

   ❖ Tapping **Next** prompts your phone to attempt a "regular" email setup and test the incoming and outgoing servers.

- If you have custom settings you need to configure, tap **Manual setup** and enter your settings. These may include mail type, user name, password, server, security type, etc.

4. Select your sync settings and then tap **Next**.

5. Enter an account name and a display name and tap **Next** to complete setup.

❖ The email account is set up and you will begin receiving email for the account.

Important: If the account type you want to set up is not in the phone database, you will be asked to enter more details. You should get all pertinent information for the email account, such as incoming and outgoing server settings, before you proceed.

Add an Exchange ActiveSync Account

If you synchronize your phone with your Exchange ActiveSync account, you can read, manage, and send email in the same easy way as with a POP3/IMAP account. However, you can also access some powerful Exchange features.

Important: Before setting up a Microsoft Exchange ActiveSync Account, contact your company's Exchange Server administrator for required account settings information.

1. From home, tap **Apps** > **Settings** > **Accounts** > **Add account** > **Corporate**.

2. Enter the **Email address** and **Password** for the email account and then tap **Next**.

❖ Tapping **Next** prompts your phone to attempt an automatic setup and test the incoming and outgoing servers.

- If the automatic setup fails, you need to enter your settings. These may include domain\username, password, server, security type, etc.

3. Follow the onscreen prompts to configure options for the account. Then tap **Next**.

4. Enter an account name and tap **Next** to complete setup.

❖ Your corporate email account is set up and you will begin receiving email for the account.

Compose and Send Email

Compose and send email using any account you have set up on your phone. Increase your productivity by attaching files such as pictures, videos, or documents to your email messages.

1. From home, tap **Apps** > **Email**.

   ❖ The email inbox opens.

   - If you want to switch to a different email account, tap the account name at the top left of the screen and select another account.

2. Tap **Compose**.

   ❖ The email composition window opens.

3. Enter the message recipient(s), subject, and message.

   ]

4. Tap **Send**.

   ❖ The email message is sent.

Open New Email Messages

When new email arrives, you will see in the status bar.

1. Drag the status bar down to display the notifications window.
2. Tap the new message from the notifications window.

   ❖ The new email message opens.

   - If you have two or more new email messages, tapping the notification opens the email inbox. Tap a message to open it.

Open Email Messages

You can also open and read email messages directly from the email inbox. Reading and replying to email on your phone is as simple as on your computer.

1. From home, tap **Apps** > **Email**.

   ❖ The email inbox opens.

2. Tap the message you want to view.

   ❖ The email message opens.

Tip: Tap the account name at the top left of the screen to switch to a different email account.

3. Tap **Reply** or **Reply all** to reply to the message.

Options when Reviewing Email Messages

- **Resetting Mail as Unread**: Tap the check box on the left side of a read message and then tap Mark as unread .
- **Deleting Email**: Tap the check box on the left side of a message or messages and then tap **Delete** .
- **Syncing Accounts Manually**: Sync sent and received email messages manually at any time regardless of the automatic sync settings. Switch to the account inbox you want to sync and then drag the message list downwards.
- **Replying to Email Messages**: With an email message open, tap **Reply** or **Reply all** , compose your reply message, and tap **Send** .
- **Forwarding Email Messages**: With the email message open, tap **Forward** , enter a recipient and an additional message, and tap **Send** .

Browser

Your phone's Chrome Web browser gives you full access to both mobile and traditional websites on the go, using 3G, 4G, or Wi-Fi data connections.

SSL/TLS

SSL (Secure Sockets Layer) and TLS (Transport Layer Security) are protocols for encrypting sent/received data. While in a screen connected by SSL/TLS, data is encrypted to safely send/receive private information, credit card numbers, corporate secrets, etc., and provide protection against online threats (eavesdropping, falsification, impersonation, etc.).

⚠️ SSL/TLS Cautions

When opening a secured page, users must decide as their responsibility whether or not to open the page with use of SSL/TLS. Boost Mobile and the applicable Certification Authorities make no guarantees whatsoever to users regarding security of SSL/TLS.

Use the Browser

Launching the browser is as easy as tapping an icon.

1. From home, tap **Chrome** .

❖ Chrome opens.

- The first time you launch Chrome, you may be prompted to enter your 10-digit wireless phone number to access the SprintWeb home page.

- You can also launch the browser by tapping a URL in a text message, email message, or Gmail message.

2. Tap the address bar at the top and enter search words (for a Google search) or a Web address (URL).

❖ The search results appear or a Web page opens.

Browser Use Options

- **Refreshing the Web Page**:
- **Going Forward to the Next Page**:
- **Returning to the Last Page**:
- **Opening a New Browser Tab**:
- **Opening a New Incognito Browser Tab**:
- **Switching Browser Tabs**:
- **Viewing Recently Opened Tabs**:
- **Viewing Browsing History**:
- **Sharing the Web Page URL**:
- **Printing the Web Page Wirelessly**:
- **Searching within a Web Page**: With a Web page displayed, tap **Menu** > **Find in page**, and enter your search text.
- Adding a Shortcut of the Web Page to the home screen:
- Opening Desktop Sites:

Camera and Video

You can use the camera or video camera to take and share pictures and videos. Your phone comes with a 13 megapixel back camera with an autofocus feature a front-facing camera that let you capture sharp pictures and videos.

Take Pictures and Record Videos

The following topics teach you how to take pictures and record videos with your phone's cameras.

Capturing Pictures/Videos

- **File Format for Pictures**: File format for pictures is JPEG.
- **File Format for Videos**: File format for videos is MPEG4.

Camera Cautions

If Lens Becomes Dirty: Fingerprints/smudges on lens prevent capturing of clear still images/videos. Wipe lens with a soft cloth beforehand.

Avoid Exposure to Direct Sunlight: Be careful not to expose lens to direct sunlight for long periods. May discolor color filter and affect color of images.

Flash light Warning

Do not shine flash light close to eyes. Do not look directly at flash light when shining. Do not shine flash light at other people's eyes. May affect eyesight, etc.

Take a Picture

You can take high-resolution pictures using your phone's cameras.

Note: If you have an SD card installed, pictures and videos are stored to the SD card by default. If no card is installed, pictures and videos are saved to your phone's memory. You can change this setting by tapping **Apps** from home, and select **Settings** > **Storage** > **Save location**.

1. From home, tap **Camera**.

   ❖ The camera viewfinder appears.

2. Before taking the picture, you can zoom in on your subject.

   - To zoom in, "spread" the screen with your thumb and finger or press the higher end of the **Volume Button**.

- To zoom out, "pinch" the screen or press the lower end of the **Volume Button**.

3. Frame your subject on the screen and configure other necessary settings. See Viewfinder Screen for details.

Tip: Hold the phone vertically when taking portrait shots or hold the phone horizontally when taking landscape shots.

4. You can either let the camera autofocus on the center of the screen, or you can tap another area of the screen that you want to focus on.

5. Tap to take the picture.

6. Tap the thumbnail at the corner of the screen and choose what you want to do with the picture you've just taken.

Record Videos

Record high-quality videos (resolution up to 1080p) using your phone's camcorder.

Note: If you have an SD card installed, pictures and videos are stored to the SD card by default.. If no card is installed, pictures and videos are saved to your phone's memory. You can change this setting by tapping **Apps** from home, and select **Settings** > **Storage** > **Save location**.

1. From home, tap **Camera** .

❖ The camera viewfinder appears.

2. Frame your subject on the screen. You can tap any area of the Viewfinder screen that you want the camera to focus on before and during recording.

3. Tap to start recording video. The recording duration appears.

Tip: During recording, you can pinch or spread on the screen or press the **Volume Button** to zoom in or out. You can also tap to take a picture.

❖ Video recording begins.

4. Tap to pause recording. Tap to stop recording.

[illustration, landscape]

❖ The camera stops recording and the video is captured and saved to your phone or SD card.

View Pictures and Videos Using Gallery

Using the Gallery application, you can view pictures and watch videos that you've taken with your phone's camera, downloaded, or copied onto your storage card or phone memory.

For pictures that are on your storage card or phone memory, you can do basic editing such as rotating and cropping. You can also easily assign a picture as your contact picture or wallpaper and share pictures with your friends.

View Pictures and Videos

You can access and view all your stored pictures and videos from your phone's Gallery.

1. From home, tap **Apps** > **Gallery**.

   ❖ The album list opens.

2. Tap an album (such as Camera).

   ❖ The list of pictures and videos for the album opens.

   - To select another album, tap **Back** to return to the Albums view.

3. Tap an image to view the picture or video.

   ❖ The picture or video snapshot opens and displays in full screen.

   - Tap to play the video.
   - When viewing pictures or videos in full screen, you can touch the screen to display a series of options and choose what to do with the picture or video.

Pictures and Videos: Review Screen

After capturing a picture or video, from the camera screen, tap the thumbnail image at the bottom right corner of the screen to see the item in the review screen. From there, you can access options such as save, view, send, or delete the picture or video.

Pictures and Videos: Options while Viewing

- **Zoom In or Out on a Picture or Video**: Tap the screen twice or pinch the screen to zoom in or out on a picture or video.
- **Viewing Videos**: Use the onscreen controls to play, pause, or stop the video playback.

After selecting an album from the Albums tab, you can browse through the pictures and videos of that album. Tap a picture or video to view it in full screen. By default, the pictures and videos in an album are displayed in grid view.

Note: When viewing pictures, you can touch and hold on a picture or video to open a selection menu and choose what to do with the picture or video.

Share Pictures and Videos

The Gallery application lets you send pictures and videos using email or multimedia messages. You can share pictures on your social networks (such as Facebook, Google+, and Twitter) and share videos on YouTube. You can also send them to another phone, your computer, or your Google Account using Bluetooth, Wi-Fi Direct, or Drive.

Send Pictures or Videos by Email

You can send several pictures, videos, or both in an email or Gmail message. They are added as file attachments in your email. For more information about using email and Gmail, see Compose and Send Email or Create and Send Gmail.

1. From home, tap **Apps** > **Gallery**.

   ❖ The album list opens.

2. Tap the album that contains the pictures or videos you want to share.
3. Tap the pictures or videos you want to share.
   - To select multiple items, touch and hold a thumbnail to turn on multiple select. Tap all the items you want to include.
4. Tap **Share** and then on the Share menu, tap **Email** or **Gmail**.

   ❖ Follow onscreen prompts to complete and send the message.

Note: If you selected **Email** and you have multiple email accounts, the default email account will be used. To change the account, tap the sender address displayed above the recipients line and select the desired email account.

Send a Picture or Video by Multimedia Message

Multimedia Messaging (MMS) lets you send pictures and videos using your phone's messaging app. Although you can send several pictures or videos in a multimedia message, it may be better to just send one at a time, especially if the files are large in size.

1. From home, tap **Apps** > **Gallery**.

   ❖ The album list opens.

2. Tap the album that contains the pictures or videos you want to share.
3. Tap the pictures or videos you want to share.

- To select multiple items, touch and hold a thumbnail to turn on multiple select. Tap all the items you want to include.

4. Tap **Share** and then on the Share menu, tap **Messaging**.

❖ Follow the onscreen prompts to complete and send the message.

For more information about sending multimedia messages, see Send a Multimedia Message (MMS).

Send Pictures or Videos Using Bluetooth

You can select several pictures, videos, or both and send them to someone's phone or your computer using Bluetooth.

1. From home, tap **Apps** > **Gallery**.

❖ The album list opens.

2. Tap the album that contains the pictures or videos you want to share.
3. Tap the pictures or videos you want to share.
   - To select multiple items, touch and hold a thumbnail to turn on multiple select. Tap all the items you want to include.
4. Tap **Share** and then on the Share menu, tap **Bluetooth**.

❖ Follow the onscreen prompts to complete and send the files.

For more information, see Bluetooth.

Send Pictures or Videos to Drive

You can store files in Drive so they are backed up safely. You need to be signed in to a Google Account to upload pictures and videos to Drive.

1. From home, tap **Apps** > **Gallery**.
2. Tap the album that contains the pictures or videos you want to share.
3. Tap the pictures or videos you want to share.

- To select multiple items, touch and hold a thumbnail to turn on multiple select. Tap all the items you want to include.

4. Tap **Share** and then on the Share menu, tap **Drive**.

5. Select the account that you want to sign in with and choose a folder for the uploaded files.

6. Tap **OK**.

Share Pictures or Videos on Google+

Share pictures and videos directly with your circle using Google+. You need to be signed in to a Google Account to post a picture or video on Google+.

1. From home, tap **Apps** > **Gallery**.

2. Tap the album that contains the pictures or videos you want to share.

3. Tap the pictures or videos you want to share.

   - To select multiple items, touch and hold a thumbnail to turn on multiple select. Tap all the items you want to include.

4. Tap **Share** and then on the Share menu, tap **Google+**.

5. Select the account that you want to sign in with if prompted.

6. Tap **Choose people to share with** to add the circles or contacts you want to share the content with. Add some comment in the text field.

7. Tap **Send**.

Send a Picture on Hangouts

You can send a picture to your Hangouts contacts. You need to be signed in to a Google Account to use Hangouts.

1. From home, tap **Apps** > **Gallery**.

2. Tap the album that contains the picture you want to share.

3. Tap the picture you want to share.

4. Tap **Share** and then on the Share menu, tap **Hangouts**.

5. Select the account that you want to sign in with if prompted.
6. Tap a contact you want to send the picture to, or tap **New message** at the bottom to select other contacts.
7. Add some comment in the text field below the picture if needed and then tap **Send**.

Send Pictures or Videos to Photos

You need to be signed in to a Google Account to upload pictures and videos to Photos.

1. From home, tap **Apps** > **Gallery**.
2. Tap the album that contains the pictures or videos you want to share.
3. Tap the pictures or videos you want to share.
   - To select multiple items, touch and hold a thumbnail to turn on multiple select. Tap all the items you want to include.
4. Tap **Share** and then on the Share menu, tap **Photos**.
5. Select the account that you want to sign in with.
6. Tap **UPLOAD**.

Send Pictures or Videos Using Wi-Fi Direct

You can select several pictures, videos, or both and send them to someone's phone using Wi-Fi Direct.

Before sending pictures or videos to another device using Wi-Fi Direct, you need to connect to the device via Wi-Fi Direct. See Connect to Another Device via Wi-Fi Direct.

1. From home, tap **Apps** > **Gallery**.
2. Tap the album that contains the pictures or videos you want to share.
3. Tap the pictures or videos you want to share.
   - To select multiple items, touch and hold a thumbnail to turn on multiple select. Tap all the items you want to include.
4. Tap **Share** and then on the Share menu, tap **WiFi Direct**.
5. Tap a device the phone has connected with or wait for it to search for new devices and tap one of them.

Share Pictures and Videos on Facebook

You can share pictures and videos from your phone directly to your Facebook account. You need to be logged in to your Facebook account to upload pictures and videos.

1. From home, tap **Apps** > **Gallery**.

   ❖ The album list opens.

2. Tap the album that contains the pictures or videos you want to share.

3. Tap the pictures or videos you want to share.

   - To select multiple items, touch and hold a thumbnail to turn on multiple select. Tap all the items you want to include.

4. Tap **Share** and then on the Share menu, tap **Facebook**.

5. Add a caption and any other information you want for the pictures or videos and post it.

Share Videos on YouTube

You can share your videos by uploading them to YouTube™. Before you do this, you must have a YouTube or Google Account and sign in to that account on your phone.

1. From home, tap **Apps** > **Gallery**.

   ❖ The album list opens.

2. Tap the album that contains the videos you want to share.

3. Tap the videos you want to share.

   - To select multiple videos, touch and hold a thumbnail to turn on multiple select. Tap all the videos you want to include.

4. Tap **Share** and then on the Share menu, tap **YouTube**.

5. Select the account that you want to sign in with and tap **OK**.

6. Enter the prompted information, such as description and tags, and select a privacy option.

7. Tap .

   ❖ The upload is completed.

Useful Apps and Features

The following topics detail many of your phone's tools and features such as news services, maps and navigation, calendar, clock, social networking apps, music, memos, and more.

Navigation

Your phone offers a number of location-based navigation programs to help you figure out where you are and get you where you're going.

Enable Location Services on Your Phone

Befgmailore using any location-based services, you must enable your phone's location feature. For information about setting your phone's location options, see Location Access Settings.

Google Maps

Use the Google Maps app to determine your location, find directions, browse local businesses and attractions, rate and review places, and more.

View Maps of Specified Places

Use Google Maps to locate and map a specific address or destination.

1. From home, tap **Apps** > **Maps** .

   ❖ Google Maps opens.

   - If prompted, follow the onscreen instructions to accept terms of use.

2. Tap the search box at the top.

3. Enter an address, city, facility name, etc., and then tap a candidate in the results list.

   ❖ A map of the specified location opens.

   - Slide the card up from the bottom to find more information about the location. You can find out its address, open hours, street view, people's review, how to get there, give the place a call, save it to your Google Account, and more.

Google Maps Operations

- **Viewing Current Location**: From the Maps app, tap .
- **Obtain Useful Area Information for Current Location**: From the Maps app, pan to your area. Then tap the top search box, enter the information you're looking for, and then tap a result to view it.
- **View Traffic Information, Aerial Photos, Etc., in Maps**: From the Maps app, tap **Menu** and then tap **Traffic**, **Satellite**, **Google Earth**, etc.
- **Check Route to Destination**: From the Maps app, tap , select a method of transport (car, public transit, or on foot), and then enter your current location and your destination.
  - Route candidates appear in a list. Tap one to get more information.
- Check Detailed Operation for Maps: From the Maps app, tap **Menu** > **Help**.

Hangouts

Hangouts is Google's instant messaging service. Use to communicate with other Hangout users, and also use video calling. Log in to a Google account beforehand (see Google Account).

Using Hangouts

1. From home, tap **Apps** > **Hangouts** .

   ❖ The Hangouts app will open.

2. Tap **Add** to start a new Hangout.

3. Type a name, email, number, or circle, or select a contact from the list.

4. Type a message and tap **Send** , or tap or to make a voice call or start a video chat.

   - If a friend is not in a Hangout, you will see a message. Tap **INVITE** to invite them to join the Hangout.

Hangouts Operations

- **Deleting a Chat**: In the chats tab of the Hangouts window, touch and hold a chat and then tap Delete .

- **Ending a Video Chat**: In the video chat window, tap .
- **Disabling Chat History**: If you don't want to keep chat history, in the chat window, tap **Menu** > **Turn history off**.
- **Delete Chat History**: To delete all your chat history, in the chat window, tap **Menu** > **Delete** > **DELETE**.

Note: You can use Hangouts as your phone's default messaging app, or as a standalone IM app. If you set Hangouts as the default messaging app, the Messages app will be disabled. For more information, see Default Messaging App Settings.

Google Search

Search information saved on the phone and in phone applications as well as on the Internet.

Use Google Search

Type search terms in the Google Search bar to find information on your phone and around the globe.

1. From home, tap the Google search bar or tap **Apps** > **Google** .

   ❖ The Search window opens.

   - If confirmation appears, follow onscreen instructions.
   - If a description for Google Now appears, tap **Next** and read information. Enable Google Now on the last page if you want to use the feature.

2. Type your search keywords and tap the search key on the keyboard.

   ❖ Search results appear.

   - To search by voice, tap in the search bar and speak your search terms.

Google Search Operations

- **Changing Search Information**: From home, tap **Apps** > **Google Settings** > **Search & Now** > **Phone search** and select where to search.
- **Using or Canceling Google Now**: Google Now automatically searches for information based on search keywords used, your current location, etc., and presents search results in the search screen. Google Now also informs users of scheduled events.
  - To enable Google Now, from home, tap **Apps** > **Google Settings** > **Search & Now** > **Now cards** and tap the **Show cards** slider.

- To use all of Google Now's functions, ensure that Google Location Reporting and Location History are turned on in your location settings. From home, tap **Apps** > **Google Settings** > **Location** > **Google Location Reporting** and select your options.

Use Google Voice Search

Use your voice to search instead of typing, with Google Voice Search.

1. From home, tap **Apps** > **Voice Search**.

   ❖ The Voice Search window opens.

2. Speak your search terms

   ❖ Search results appear.

Twitter

Tweet (post messages) and view other people's tweets on Twitter. Login may be required to use Twitter. For details on Twitter, visit twitter.com.

Install the Twitter App on Your Phone

Before you can use Twitter on your phone, you have to download and install the app from Google Play.

1. From home, tap **Apps** > **Play Store**.
2. Tap and search for "twitter".
3. Tap **Twitter** from the results list.
4. Tap **INSTALL**, and then tap **ACCEPT**.

   ❖ The app will be downloaded and installed on your phone.

5. When the download has completed, tap **OPEN**.

   - To open the app from the home screen, tap **Apps** > **Twitter**.

Tweet on Twitter

Read Twitter feeds, follow your friends, and tweet your own updates right from your phone.

1. From home, tap **Apps** > **Twitter**.

   ❖ The Twitter app launches.

- If this is the first time you've used Twitter on your phone, tap **Log in** to sign in to an existing account, or tap **Sign up** to set up a new Twitter account.

2. Tap the "What's happening?" text box, type a tweet, and tap **TWEET**.

❖ The tweet is sent and appears on your Twitter feed.

Facebook

Post updates, read what your friends are up to, upload pictures and check-ins, and more with on-the-go Facebook access.

Install the Facebook App on Your Phone

Before you use Facebook on your phone, you must download and install the app from the Google Play Store app.

1. From home, tap **Apps** > **Play Store** .
2. Tap and search for "facebook".
3. Tap **Facebook** from the results list.
4. Tap **INSTALL**, and then tap **ACCEPT**.

❖ The app will be downloaded and installed on your phone.

5. When the download has completed, tap **OPEN**.

- To open the app from the home screen, tap **Apps** > **Facebook** .

Sign in to Your Facebook Account from Account Settings

1. From home, tap **Apps** > **Settings** > **Accounts** > **Add account**.

   [illustration]

2. Tap **Facebook**.

   [illustration]

3. Read the disclaimer and tap **I accept** to continue.
4. Enter your Facebook username and password and tap **Next**.
5. Tap **Done**.

❖ Your Facebook account is added to your phone.

Use Facebook

Once you've downloaded the app and signed in, you can post and read updates, upload pictures, tag locations, and more, all from your phone.

1. From home, tap **Apps** > **Facebook** .

   ❖ The Facebook app launches.

   - If this is the first time you've used Facebook on your phone, enter your Facebook ID and password and tap **Log in** to sign in to an existing account, or tap **Sign Up for Facebook** to set up a new Facebook account.

2. Tap **Status** and type an update, tap **Photo** and upload a picture from the gallery, tap **Check In** to share your location, "Like" and comment on friends' posts, and more.

LinkedIn

Find and connect with members worldwide, read the latest industry news, keep up-todate you're your groups, and more with on-the-go LinkedIn access.

Install the LinkedIn App on Your Phone

Before you use LinkedIn on your phone, you must download and install the app from the Google Play Store app.

1. From home, tap **Apps** > **Play Store** .
2. Tap and search for "linkedin".
3. Tap **LinkedIn** from the results list.
4. Tap **INSTALL**, and then tap **ACCEPT**.

   ❖ The app will be downloaded and installed on your phone.

5. When the download has completed, tap **OPEN**.

   - To open the app from the home screen, tap **Apps** > **LinkedIn** .

Sign In to Your LinkedIn Account

Once you've downloaded and installed the LinkedIn app, sign in to your account.

1. From home, tap **Apps** > **LinkedIn** .
2. Follow the onscreen prompts to enter your LinkedIn username and password to sign in. You can also create a new LinkedIn account.

YouTube

View videos uploaded to YouTube and upload your own videos to your YouTube account.

View YouTube Videos

You can use the YouTube app to view videos on YouTube even if you aren't signed in to a YouTube account.

1. From home, tap **Apps** > **YouTube** .

   ❖ The YouTube app launches.

   - If you're prompted to provide confirmation to use the site, follow the onscreen instructions to continue.

2. Search through the YouTube channels and tap a video you want to see.

   ❖ The video plays on your phone screen.

   - Tap the screen to pause or resume play while watching.

Post a Video to YouTube

You can post videos to your YouTube account from your phone. Before posting, you must set up a YouTube account and sign in to it on your phone.

1. From home, tap **Apps** > **YouTube** .

   ❖ The YouTube app launches.

2. Tap **Options** > **Uploads** > .

   ❖ The Open from menu appears.

3. Select a video to upload.

   - Enter a title, description, and tags, and select a privacy setting.

4. Tap .

   ❖ The video is uploaded to your YouTube channel.

Google Play Music App

The Google Play Music app lets you browse, shop, and play back songs purchased from Google Play as well as songs you have loaded from your own music library. The music you choose is automatically stored in your Google Play Music library and instantly ready to play via streaming or download.

For more information about Google Play Music, visit play.google.com/about/music.

Note: For information about loading music onto your phone, see Transfer Files Between Your Phone and a Computer.

Play Music with Google Play

Use the Google Play Music app to listen to all your music on your phone.

1. From home, tap **Apps** > **Play Music** .

   ❖ The Play Music app opens.

2. Tap a recommendation in the Listen Now screen, or tap > **My Library** or **Playlists** to view all the music or playlists. To change views of your library, swipe left or right.

3. Tap a song to play it. The song title and player control appears at the bottom of the screen. You can touch it or drag it up to display the player screen.

   ❖ The song begins playing.

Google Play Music Screen Layout

The following diagram outlines the main features of the Play Music app player screen.

Feature	Description
Song and artist	Shows the names of the song and the artist. Tap the area to close the player screen and return to the music library.
Album image	Displays the album artwork (if available). Swipe left or right to switch to the next or previous song in the current playlist.
Play/Pause	Tap to resume or pause the player.
Repeat	Tap to switch repeat modes. You can repeat the current song, the current playlist, or turn off repeat.
Previous song	Tap to restart the current song; tap twice to switch to the previous song in the playlist.
Next song	Tap to switch to the next song in the playlist.
Shuffle	Tap to turn on or off shuffle.
Progress bar	Shows the progress of the current song. Drag or tap it to jump to any part of song.
Rate	Give the song a thumbs-up or thumbs-down.

Feature	Description
Current playlist	Tap to display the current music list (queue).
Options	Tap to access more player options.

Connectivity

The following topics address your phone's connectivity options, including USB file transfer and tethering, Wi-Fi, Bluetooth, IR connectivity, and more.

Connections Optimizer

The Connections Optimizer is a tool that automatically selects the best mobile network for your phone, including "remembered" Wi-Fi networks.

About Connections Optimizer

The Connections Optimizer helps you manage and enhance your data experience by finding and connecting to "remembered" Wi-Fi networks on your phone. Remembered Wi-Fi networks are networks with which you have previously chosen to connect. Active Wi-Fi connections may offer improved performance and generally improve battery life while allowing you to talk on the phone and use data at the same time.

The Connections Optimizer works by searching for available "remembered" Wi-Fi networks. If you do not leave your Wi-Fi antenna on all the time, you will only notice the Connections Optimizer operating at certain times of the day in a small number of locations on the network. Your Wi-Fi antenna will conserve battery by scanning for connections periodically (not continuously), and if no connection is achieved, the antennas will be turned off. You may also manually turn the antennas off during the scan period.

To facilitate quality assurance and enable feature enhancements, information is collected about your battery levels, Wi-Fi and network connections and usage. No personal information is collected.

Enable Connections Optimizer

1. From home, tap > **Settings** > **Mobile networks** > **Connections optimizer**. You will see a disclaimer.

   [illustration]

2. Read the disclaimer and tap **I Agree** to turn Connections Optimizer on.

   ❖ Connections Optimizer will turn on and automatically analyze your phone's connection options.

Disable Connections Optimizer

1. From home, tap > **Settings** > **Mobile networks** > **Connections optimizer**.

   [illustration]

2. Uncheck the box on the Connections Optimizer page.

   ❖ Connection Optimizer will turn off.

Wi-Fi

Wi-Fi provides wireless Internet access over distances of up to 300 feet. To use your phone's Wi-Fi, you need access to a wireless access point or "hotspot."

The availability and range of the Wi-Fi signal depends on a number of factors, including infrastructure and other objects through which the signal passes.

Turn Wi-Fi On and Connect to a Wireless Network

Use the Wireless & networks setting menu to enable your phone's Wi-Fi radio and connect to an available Wi-Fi network.

1. From home, tap **Apps** > **Settings** > **Wi-Fi**.

   ❖ The Wi-Fi settings menu appears.

2. Tap the Wi-Fi slider to turn Wi-Fi on.

   ❖ Wi-Fi is enabled. You will see the names and security settings of in-range Wi-Fi networks.

   - To disable Wi-Fi, tap the slider again.

3. Tap a Wi-Fi network to connect, enter the password (if it's not an open network), and then tap **CONNECT**.

   ❖ Your phone is connected to the Wi-Fi network. You will see ( ) in the status bar.

   - The password, for a household wireless LAN router, is sometimes found on a sticker on the router (WEP, WPA, KEY, etc.). Contact the router manufacturer for information. For password for a public wireless LAN, check with user's service provider.
   - Entering a password is not required if an access point is not security protected.

Note: The next time your phone connects to a previously accessed secured wireless network, you will not be prompted to enter the password again, unless you reset your phone to its factory default settings or you instruct the phone to forget the network.

Note: Wi-Fi networks are self-discoverable, which means no additional steps are required for your phone to connect to a Wi-Fi network. It may be necessary to provide a user name and password for certain closed wireless networks.

Bluetooth

Bluetooth® is a short-range communications technology that allows you to connect wirelessly to a number of Bluetooth devices, such as headsets and hands-free car kits, and Bluetooth-enabled handhelds,

computers, printers, and wireless phones. The Bluetooth communication range is usually approximately 30 feet.

Bluetooth Hints

Question: Can't use Bluetooth?

Answer: Is your phone in airplane mode? Bluetooth is unavailable in airplane mode.

⚠ Bluetooth Function Cautions

Information may not appear correctly on connected devices depending on the transferred data.

Bluetooth Information

Bluetooth is a technology that enables wireless connection with PCs, Bluetooth devices with hands-free features, etc.

Function	Description
Audio output	Listen to music, etc., wirelessly.
Hands-free calls	Call hands-free, using Bluetooth-capable hands-free devices and headsets.
Data exchange	Exchange data with Bluetooth devices.

Enable the Bluetooth Feature

Use the settings menu to enable or disable your phone's Bluetooth capabilities.

- Wireless connection to all Bluetooth® functions is not guaranteed for the phone.
- The phone may not connect properly depending on the other device.
- Noise may be experienced with wireless calls and hands-free calls depending on the conditions.

To enable Bluetooth

1. From home, tap **Apps** > **Settings** > **Bluetooth**.

   ❖ The Bluetooth settings open.

2. Tap the slider to turn Bluetooth on.

   ❖ Bluetooth is enabled.

- To disable Bluetooth, tap the slider again.

Tip: You can also turn Bluetooth on or off with the toggle menu in the notifications panel. Drag the status bar down to display the notifications panel and then tap **Bluetooth** to turn Bluetooth on or off.

Note: Turn off Bluetooth when not in use to conserve battery power, or in places where using a wireless phone is prohibited, such as aboard an aircraft and in hospitals.

Pair Bluetooth Devices

Search for and pair nearby Bluetooth devices. Registered Bluetooth® devices can be connected simply.

- Enable the Bluetooth function on the Bluetooth devices being paired beforehand.

To pair Bluetooth devices:

1. From home, tap **Apps** > **Settings** > **Bluetooth**.

   - The Bluetooth settings open.

2. If Bluetooth is not turned on, tap the slider to turn Bluetooth on.

   - Nearby devices appear in the “Available devices” list.
   - If a target device is not detected, tap Menu > **Refresh** to search again.

3. Tap a device from the “Available devices” list, and follow the onscreen instructions to pair with the device.

   - The Bluetooth device is paired to your phone.
   - Methods to accept a Bluetooth connection differ depending on the devices used.

Unpairing from a Paired Device

1. From the Bluetooth settings menu, tap **Settings** next to the paired device you wish to unpair.

2. Tap **FORGET**.

   - The device is unpaired from your phone. To make another connection with the device, you will need to pair again.

Connect to a Paired Bluetooth Device

You can listen to music over a Bluetooth stereo headset, or have hands-free conversations using a compatible Bluetooth headset or car kit. It's the same procedure to set up stereo audio and hands-free devices.

1. From home, tap **Apps** > **Settings** > **Bluetooth**.

   ❖ The Bluetooth settings open.

   - Paired Bluetooth devices appear in the "Paired devices" list.

2. Tap a device from the "Paired devices" list.

   ❖ Your phone connects to the paired device.

The pairing and connection status is displayed below the device's name in the Paired devices section.

When the device is connected to your phone, the Bluetooth connected icon is displayed in the status bar. Depending on the type of device you have connected, you can then start using the headset or car kit to listen to music or make and receive phone calls.

Note: Due to different specifications and features of other Bluetooth-compatible devices, display and operations may be different, and functions such as transfer or exchange may not be possible with all Bluetooth-compatible devices.

Send Information Using Bluetooth

You can use Bluetooth to transfer information between your phone and another Bluetooth-enabled device such as a phone or notebook computer.

Types of Data You Can Send via Bluetooth

You can send the following types of information, depending on the device you are sending to:

- Images and videos
- Calendar events
- Contacts
- Audio files

In the instructions below, Contacts data is being used as an example.

Sending Contacts Data via Bluetooth

1. From home, tap **Apps** > **Contacts**.

- ❖ You will see the Contacts list.

2. Tap a contact to send.

3. Tap **Menu** > **Share** > **Bluetooth**.

4. If you are prompted to turn on Bluetooth, tap **Turn on**.
5. Tap the name of the receiving device.

6. If prompted, accept the connection on the receiving device, and enter the same passcode on both your phone and the other device, or confirm the auto-generated passcode.
7. On the receiving device, accept the file.

- ❖ The contact information is sent.

Settings

The following topics provide an overview of items you can change using your phone's **Settings** menus. The settings menu is grouped into the following categories, all of which are available through the main settings screen.

- **WIRELESS & NETWORKS** menu options include Airplane mode, Wi-Fi, Bluetooth, Mobile networks, Data usage, Mobile hotspot and More.
- **DEVICE** menu options comprise Sound & notifications, Display, Date & time, Language & input, Storage, Battery, Apps, and Connect to PC.
- **PERSONAL** settings include Location, Security, Backup & reset, and Accounts.
- **SYSTEM** menu options include Accessibility, Printing, Activate this device, System updates, and About phone.

For Assistance

The following topics address areas of support for your phone, including troubleshooting, specifications, account information, warranty information, and customer service contact information.

Boost Account Information and Help

Find out about managing your account online and on your phone, buying additional minutes for your plan, and getting help.

For more information about your Boost Mobile account, as well as other Boost Mobile services, visit us at: boostmobile.com.

Manage Your Account

Access information about your account. You can:

- Check your minutes.
- Re-Boost® (add money to your account).
- Change plans.
- And more.

From Your Phone

Access account information and other self-service tools from BoostZone.

- From home, tap **Apps** > **BoostZone**.

You can also dial directly for access to certain information:

- Dial (#BAL) to check account balance.
- Dial (#ADD) to make a payment.
- Dial to launch BoostZone or call Boost Customer Care (depending on your Settings) to get answers to other questions.

From Your Computer

- Visit boostmobile.com, click **My Account**, and log in with your wireless phone number and account PIN.

From Any Other Phone

- Boost Customer Care: **1-888-BOOST-4U** (1-888-266-7848).

Re-Boost

Boost Mobile makes it easy to add money to your account. You decide exactly how and where you want to pay. Keep your account active by using your phone and adding money to your account.

Pay with Cash

Find an Authorized Re-Boost Retailer near you. Pick up a Re-Boost Card or recharge for as low as $10 at the register, where available.

Pay Anytime with a Credit/Debit Card

Dial **#ADD** (□□□□) to add money from your phone or visit **My Account** at boostmobile.com to do it online. Securely register your credit/debit card with Boost for more convenient one-time payments or to set up easy Auto Re-Boost payments.

Set Up Worry-Free Payments with Auto Re-Boost℠

It's the easiest way to make sure your account stays on and active. Use a credit card, debit card or bank account—whatever's best for you.

Visit boostmobile.com/reboost to get the details on all your Re-Boost options.

FCC Regulations:

●This mobile phone complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

●This mobile phone has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiated radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF Exposure Information (SAR)

This phone is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the United States.

During SAR testing, this device was set to transmit at its highest certified power level in all tested frequency bands, and placed in positions that simulate RF exposure in usage against the head with no separation, and near the body with the separation of 10 mm. Although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output.

The exposure standard for wireless devices employing a unit of measurement is known as the Specific Absorption Rate, or SAR.

The SAR limit set by the FCC is 1.6W/kg.

This device is complied with SAR for general population /uncontrolled exposure limits in ANSI/IEEE C95.1-1992 and had been tested in accordance with the measurement methods and procedures specified in IEEE1528. This device has been tested and meets the FCC RF exposure guidelines when tested with the device directly contacted to the body.

The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of www.fcc.gov/oet/ea/fccid after searching on FCC ID: SRQ-ZTEN9518.

For this device, the highest reported SAR value for usage against the head is 0.74 W/kg, for usage near the body is 1.27 W/kg.

While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirements.

SAR compliance for body-worn operation is based on a separation distance of 10 mm between the unit and the human body. Carry this device at least 10 mm away from your body to ensure RF exposure level compliant or lower to the reported level. To support body-worn operation, choose the belt clips or holsters, which do not contain metallic components, to maintain a separation of 10 mm between this device and your body.

RF exposure compliance with any body-worn accessory, which contains metal, was not tested and certified, and use such body-worn accessory should be avoided.

Hearing Aid Compatibility (HAC) regulations for Mobile phones

In 2003, the FCC adopted rules to make digital wireless telephones compatible with hearing aids and cochlear implants. Although analog wireless phones do not usually cause interference with hearing aids or cochlear implants, digital wireless phones sometimes do because of electromagnetic energy emitted by the phone's antenna, backlight, or other components. Your phone is compliant with FCC HAC regulations (ANSI C63.19- 2011). While some wireless phones are used near some hearing devices

(hearing aids and cochlear implants), users may detect a buzzing, humming, or whining noise. Some hearing devices are more immune than others to this interference noise and phones also vary in the amount of interference they generate. The wireless telephone industry has developed a rating system for wireless phones to assist hearing device users in finding phones that may be compatible with their hearing devices. Not all phones have been rated. Phones that are rated have the rating on their box or a label located on the box. The ratings are not guarantees. Results will vary depending on the user's hearing device and hearing loss. If your hearing device happens to be vulnerable to interference, you may not be able to use a rated phone successfully. Trying out the phone with your hearing device is the best way to evaluate it for your personal needs.

This phone has been tested and rated for use with hearing aids for some of the wireless technologies that it uses. However, there may be some newer wireless technologies used in this phone that have not been tested yet for use with hearing aids. It is important to try the different features of this phone thoroughly and in different locations, using your hearing aid or cochlear implant, to determine if you hear any interfering noise. Consult your service provider or the manufacturer of this phone for information on hearing aid compatibility. If you have questions about return or exchange policies, consult your service provider or phone retailer.

M-Ratings: Phones rated M3 or M4 meet FCC requirements and are likely to generate less interference to hearing devices than phones that are not labeled. M4 is the better/higher of the two ratings.

T-Ratings: Phones rated T3 or T4 meet FCC requirements and are likely to be more usable with a hearing device’s telecoil (“T Switch” or “Telephone Switch”) than unrated phones. T4 is the better/ higher of the two ratings. (Note that not all hearing devices have telecoils in them.)

Your phone meets the M4/T4 level rating.

Hearing devices may also be rated. Your hearing device manufacturer or hearing health professional may help you find this rating. For more information about FCC Hearing Aid Compatibility, please go to http://www.fcc.gov/cgb/dro.

Index

Activation, 12

Answer a Call, 43

Apps

  Find and install, 27

Back Key, 3

Bluetooth

  Connect, 105

  Send information, 106

  Share pictures and videos, 76

  Turn on or off, 102

Browser

  Launch connection, 66

Camera, 68

  Take a picture, 68

Car Kit

  Connect, 105

Charging/micro-USB Jack, 3

Connections Optimizer, 99

Contacts, 45

  Add contact, 45

  Save a phone number, 48

Drag, 10

Drive

  Send pictures and videos, 78

Email

  Add account, 58

  Add Exchange ActiveSync account, 62

  Compose and send, 63

  Setup, 57

  Share pictures, 72

  View and reply, 64

Enter Text, 15

Exchange ActiveSync

  Add account, 62

Extended Home Screen, 31

Facebook, 94

  Share pictures and videos, 85

Flash, 3

Flick, 10

Folders, 38

Gallery, 71

  View pictures and videos, 71

Gmail

  Create account, 17

  New messages, 57

  Read and reply, 56

  Read messages, 57

  Share pictures, 72

Google

  Create account, 17

  Hangouts, 90

  Sign in, 22

  Voice search, 93

Google Keyboard, 16

Google Maps, 87

Google Play

Find and install apps, 27
Store, 27
Google Play Music, 97
Google Search, 92
Google Voice Typing, 16
Google+
Share pictures and videos, 80
Hangouts, 90
Send a picture, 82
Headset
Connect, 105
Headset Jack, 3
Home Screen, 30
Add Folders, 38
Add Shortcuts, 36
Add Widgets, 37
Customize, 34
Extended, 31
Incoming Call
Answer, 43
Reject, 43
Internet, 50
Keyboard
Google keyboard, 16
Swype, 16
Touchscreen, 15
LinkedIn, 95
Maps, 87
Messaging, 50
MMS
Send messages, 51
Multimedia Messaging
Share pictures and videos, 74
Music
Google Play Music, 97
Navigation, 87
Google Maps, 87
Phone
Dialer, 40
Phone Calls, 40
Answer, 42
Using phone keypad, 40
Phone Layout (illustration), 2
Phone Number
Save to contacts, 48
Photos
Send pictures or videos, 84
Pictures
Send to Drive, 78
Send to Photos, 84
Send via Hangouts, 82
Send via Wi-Fi Direct, 85
Share via Bluetooth, 76
Share via email, 72
Share via Facebook, 85
Share via Google+, 80
Share via messaging, 74
Take with camera, 68
View, 71
Pinch, 11
Play Music, 97
Play Store, 27

Find and install apps, 27
Power Button, 3
Power Off, 9
Power On, 8
Reject Incoming Call, 43
Rotate, 11
Save a Phone Number, 48
Search
Google, 92
Settings, 110
Setup Screens, 12
Slide, 10
Speaker, 3
Spread, 11
Status Bar, 32
Swipe, 10
Swype, 16
Tap, 9
Text Entry, 15
Text Messaging
Conversations, 54
Draft messages, 53
Notifications, 54
Send messages, 50
Touch, 9
Touch and Hold, 9
Touchscreen
Keyboard, 15
Turn off, 28
Turn on, 28
Turn Device Off, 9
Turn Device On, 8
Twitter, 93
Typing, 15
Video Camera
Record video, 70
Videos
Record, 70
Send to Drive, 78
Send to Photos, 84
Send via Wi-Fi Direct, 85
Share via Bluetooth, 76
Share via Facebook, 85
Share via Google+, 80
Share via messaging, 74
Share via YouTube, 85
View, 71
Voice Search, 93
Voice Typing, 16
Voicemail
Setup, 44
Volume
Button, 3
Wallpaper, 34
Web
Launch connection, 66
Widgets, 37
Wi-Fi, 100
Turn on and connect, 100
Wi-Fi Direct
Send pictures or videos, 85
YouTube, 96

Share videos, 85
Zoom, 11