

KTS-808
Bluetooth Speaker

USER MANUAL

Features:
Bluetooth wireless connectivity
Support USB/TF card
FM Radio
AUX function
Rechargeable Lithium battery
Built-in microphone
Hands –free Call

Specification:

Driverunit size	:2.5inch
Impedance	:4 Ohm
S/Nratio	:≥80dB
Separation	:≥45dB
Distortion	:≤1.0%
Frequency response	:100Hz-20KHz
Bluetooth version	:V2.1
Bluetooth range	:10meters
Bluetoothpairing name	:KTS-808
Bluetoothprofiles supported	:A2DP
USB& TFmax.memory supported	:16GB
FMradio	:87.5-108.0MHz
Battery capacity	:Built-in1500mAh
Battery type	:Li-ion
Playback time	:1.5hrs at maxvolume
Charging indicator	:Yes
Input power	:DC5V

Accessory:
USB charging cable: 1 piece;
3.5MM audio cable: 1 piece;
User manual: 1 piece

Connect to Bluetooth device
Turn on the speaker unit and the Bluetooth switch on your mobile or other device and search for the speaker model name "NT-890W". Pair the device. Once device is paired Bluetooth will automatically connect when unit is turned on subsequently.



1. OFF/ON : Power Switch, switch to ON to turn on the unit, and OFF to turn off the unit.
2. Aux: Audio input jack when connect. Enable the sound source connection active devices(PC, digital media player, mobile phones and other audio-visual products).
3. DC-5V: Please use the original charging cable to charge. The red LED is on when charging, when charging is completed m the red LED will be off.
4. USB slot: Used to read the Mp3 files in FAT32 format with maximum size of 16GB
5. TF slot: Used to read the Mp3 files in FAT32 format with maximum size of 16GB
6. Play/Pause: Under USB/TF/Bluetooth mode, short press for play and pause;
7. M: Press to change mode during USB/TF, Bluetooth, FM and Aux-in mode.
8. -: Under USB/TF/Bluetooth/FM/Aux-in mode, Long press to move to previous channel/track. Short press to turn down the volume.
9. +: Under USB/TF/Bluetooth/FM/Aux-in mode, Long press to move to next channel/track. Short press to turn up the volume.

Bluetooth

Turn on the speaker, It come into the Bluetooth model directly .After pair the device, it can play the music, Short time Press to Play/Pause, Long press - and the + to Prev and Next. Short press - and + button to turn down and turn up the Volume.

AUX-IN

AUX-IN, Using the audio cable into AUX jack, or press M to switch to Aux in Model . Short time press - and + button to turn down and turn up the Volume.

In the AUX IN status, it couldn't shift Prev and Next by Bluetooth speaker, but can control by connection device.

USB/TF Card

Insert the U flash memory or Micro-TF card into the USB/TF slot. NT-890W will read the MP3 format music automatically. Press to Play/Pause, Long press - and + to Prev. and Next, Short press - and + button to turn down and turn up the Volume.

Charging

Please use the original charging cable to charge,
Red LED on when charging.

WARNING

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment .

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.