无线立体声音响耳机

Stereo Wireless Headset
With Speaker

快速入门指南

Quick Guide

SX-809

无线立体声音响耳机的使用

为确保正确而安全地使用本耳机，请在使用前详细阅读本手册，并保存好。

使用耳机时应注意下列事项：

应尽量避免长期高音量使用耳机模式，以避免损伤听力。

如所处环境存在潜在危险，请暂停使用耳机，以确保安全。

应合理控制使用耳机时的音量大小和时间。

不应把音量调得太高，导致您听不到四周的声音 。如果出现耳鸣可能是音量调得太高，请将音量调低。

不建议在驾驶时使用耳机听歌。

用干的软布擦拭使可！应避免耳机进水，以免导致耳机损坏或者音质下降。

如果使用耳机感觉到明显不适，或有刺激感等其他不良反应时，应立即停止使用本耳机。

不应将耳机储存或使用于温度低于-15°C(5°F)或高于55°C（ 131°F ）的环境，以免影响耳机寿命。

充电和电池：

给本耳机充电前，请先检查充电线是否为原装。

敬告：建议使用原装配套的充电线给耳机充电，如果使用不配套的充电线可能会损坏耳机。

本耳机使用内置式不可拆卸充电电池。请勿尝试从耳机中取出电池，以免损坏耳机。

（1）

1. 充电前，请关闭耳机。

2. 连接充电器后，耳机开始充电。充电时，红灯亮。

3. 耳机充满电，约需3.5小时，充满后红灯熄灭。

▌耳机包装清单：

- 耳机1个
- USB充电线1条
- 耳塞套2对
- 说明书1本



（2）

开机/关机：

1. 在关机状态下长按“多功能键”3秒，直到指示灯闪动，耳机提示“开机”并伴有振动。

2. 在开机状态下，长按“多功能键”3秒, 耳机提示“关机” ，此时，耳机关机，指示灯熄灭。



（3）

蓝牙配对步骤：

1. 请将耳机和手机（或其他作用连接的装置）的距离控制在1米范围内，越近越好。

2. 在开机状态下，长按“多功能键”3秒，直到指示灯闪动，耳机提示“开机”“电量**”，继续长按5秒后会进入配对状态，耳机提示“进入配对”，此时红蓝灯交替闪烁。

3. 打开手机或其他所需连接装置的蓝牙搜索功能，手机上会显示已找到“SX-809”。

4. 选择“SX-809”（部分手机需输入“0000”作为配对密码，耳机会自动与手机连接，蓝灯闪烁）。此时，耳机会语音提示“已连接”。

将耳机跟两部手机连接

1. 与第一部手机配对成功后，关闭第一部手机蓝牙，长按SX-809的“多功能键”3秒，将耳机关机；

2. 按照与第一步手机配对的步骤与第二部手机配对；

3. 打开第一步手机蓝牙功能，选择SX-809，完成与两部手机的配对。

温馨提示：

1、当已经配对过的蓝牙设备处于蓝牙开启状态，并在连接范围内，只需要将SX-809开机就可以自动回连到上次连接的设备；如果不能自动回连，请打开蓝牙设备的蓝牙菜单，点击已连接过的“SX-809”就可以回连。

2、配对时间超过3分钟，耳机会自动关机 ；超出连接范围断开连接后3分钟内回到有效距离就可以自动回连上一次连接的设备 。

3、同时连接两部手机的情况下，两部手机不能同时播放音乐；需暂停其中一部手机的音乐播放，才能让另一部手机继续播放音乐。两部手机都可进行蓝牙电话功能，可在iPhone上显示耳机剩余电量。

（4）

接通与挂断/来电震动提醒

接听来电：
当手机与耳机连接后，有来电时，耳机会有提示音并伴随着振动，播报来电号码“134……”,按“多功能键”1次可接听来电；或用您的手机直接听来电。

挂断通话：
正在通话时，可按一次耳机的“多功能键”即可挂断通话，或用您的手机直接挂断通话。

拒绝通话：
当听到有来电时，耳机会有提示音并伴随着振动，此时，双击“多功能键”通话便会被拒绝; 或用您的手机拒绝通话。

来位重拨：
双击“ 多功能键” 即可拨出手机最后一次拨打的号码。

电话转移：
通话时,可双击“ ━ ” ，在手机与耳机间相互切换通话。

语音拨号:
手机在解锁状态下双击“ ＋ ”听到提示音后说“打电话给XXX” ，手机就会自动拨出该电话（手机内需存有XXX电话），部分手机不适用。

挂1拨2：
当第一个电话正在通话中，第二个电话呼入，如果你想接听第二个来电，双击“多功能键” ，就可以结束第一个通话，接听第二个来电。

EQ切换：
在播放音乐时可双击“ ━ ”键切换不同的音效：高音加强，正常，低音加强。默认高音加强，根据不同的音乐，不同的爱好，选择最舒适的音效。

中英文切换：
同时按住“ ＋ ”和“ ━ ”键2秒：中、英文可相互转换。

耳机/外响：
将开关推到“ ”模式，SX-809就会进入耳机状态，将开关推到“ ”模式，SX-809会进入外响状态。

（5）

播放/暂停

耳机正在音乐播放期间，单击“多功能键”可暂停音乐播放；再次单击“多功能键”可恢复音乐播放。

上一首/音量减：在播放音乐时可短按“ ━ ”,选择上一首音乐，长按“ ━ ”降低音量。

下一首/音量加：在播放音乐时可短按“ ＋ ”,选择下一首音乐，长按“ ＋ ”增加音量。

电量提示：
SX-809每次开机时会提示耳机的剩余电量情况，如“电量满、电量充足、电量中等、电量低、电量低请及时充电”。

手机防丢提示

当手机与耳机连接后，耳机离开手机约10米外，耳机就会语音提示“蓝牙已断开”如果在三分钟内回到有效距离，可自动与手机连接，超过3分钟不回到有效距离，10分钟后自动关机。

恢复出厂设置

关机状态下充电时，长按“多功能键” ，蓝灯闪3次，恢复出厂设置。

技术参数

符合蓝牙标准：Bluetooth V4.1
发送功率：Class 2
操作频率范围：2.402 GHz-2.480GHz
待机时间：≥300小时
扬声器通话时间：≥11小时
扬声器听歌时间：=5小时
支持：HSP . HFP . A2DP . AVRCP
连接范围：≤10m
充电时间：≤3.5小时
耳机通话时间：≥18小时
耳机听歌时间：≥16小时

（6）

温馨提示：

正确收线方式

为了延长耳机线和喇叭使用寿命，建议收线缠冲，按下图所示步骤操作！



不正确收线方式



（7）

For user’s safety, please read this manual before using the headset.

The following matters should be paid attention to when using headset:

Please avoid long-term use of high volume mode, because it will lead to hearing loss caused by noise.

If you are in bad condition of potential danger, please stop using headset, in order to ensure safety.

Users should reasonably control the volume and time when listening to the headset.

The volume should not be too high,otherwise you can’t hear the voice around. If volume is too high that may appear tinnitus, please lower down the volume.

Don’t listen to the music while driving.

Use dry soft cloth to clean the headset! Should avoid the headset into the water, that will cause headset damage.

If you feel obvious discomfort, stimulation, or other adverse reaction when using the headset, stop using it immediately .

The headset should not be stored or used in temperature below 15 c(5 F) or higher than 55 c(131 F),otherwise will reduce the battery life.

（8）

Charging and Battery:

Before charge this headset with charging cable, please check whether the charge cable is original.

Warning :

Please charge the headsets with original charging cable, it may damage the battery or the headset if you are using improper charging cable, This headset has built-in rechargeable battery, so do not attempt to remove the battery from the headset to avoid damaging it.

1. Before charging, it’s best to turn off the headset.

2. Insert the USB charging cable to earpiece jack, the other end of the USB port into the USB charger or any other devices to start charging. The headphones red light flashing means it is charging.



（9）

3. The headset need about 3.5 hours for fully charging, the red light goes off when fully charged.

▌Package content:

- Headset 1pcs
- Earbud 2pcs
- USB charging cable 1pcs
- User Manual 1pcs

ON/OFF

1. Long press “MFB” button for 3 seconds, the headset will prompts “Power ON” with vibration; if red and bluelight flashing alternately means it’s ready for pairing with your device.

2. Long press “MFB” button for 3 seconds, to turn off the headset.



（10）

Bluetooth connection steps:

1. Please keep your headset and mobile phone as close as you can, within 1 meter.

2. Press to “Power On” it will prompts “pairing” after 5 seconds, and then Red and blue lights flashing alternately when headset is on and ready for pairing.

3.Turn on “Bluetooth” in setting(your device) and find headset name SX-809.

4. Click SX-809 Bluetooth headset gets connected with your mobile phone automatically. Some may require pass code which is 0000.

Pairing the headset with 2 mobile phones

1. After successfully paired with a mobile phone, close the Bluetooth function of the mobile phone, Long press “MFB” button for 3 seconds, headset will power off.

2. Same procedure to get the 2nd mobile phone paired with the Bluetooth headset.

3. Turn on the Bluetooth function of the 1st mobile phone; choose “SX-809” to finish the pairing status with the 2nd mobile phones.

Note :

1. With you perviously paired device’s Bluetooth turned on and in range , turn on SX-809. The headset will automatically reconnect to the same Bluetooth device that connected last time. If you have a previously paired device that does not auto-reconnect , navigate to the Bluetooth settings menu on your device , turn on the Bluetooth feature , and select “SX-809” from your list of paired Bluetooth devices .

（11）

2. Pairing time exceeds 3 minutes, SX-809 will automatically shut down ; in 3 minutes back to the effective distance can automatically return to the last connected device .

3. If connected with two mobile phones, only mobile phone 1 supports wireless music and you can start conversation for both mobile phones. Battery check up through iPhone.

Answer & End call / Incoming call vibration remind

Answer phone call :

When there is a incoming call, there will be a voice Prompts, 134...578 (phone number will be broadcasted). short press MFB to answer, or just operate your mobile phone.

End Call :

Short the “MFB” button to hang up calls, or by direct hang up your phone call.

Reject call :

When there is an incoming call, headphone will broadcast the phone number with vibration. Double click the “MFB” to reject, or just reject it on your mobile phone.

Last number redial :

Double click “MFB” button.

Call Transfer :

Double click the volume “ ━ ” To transfer incoming call between phone and headset.

（12）

Voice Dial :

Unlock the mobile phone and double click the volume “ ＋ ” to launch the voice dial, and then just speak the people name you want to call. This function can work only if your mobile phone support it.

Hang up the phone call and answer other incoming call

If there is an incoming call when you are answering the phone call, and you want to Answer the other incoming call, double click the “MFB” button, you can hang up the phone call, and answer the incoming call.

EQ Shift :

Double click the volume “ ━ ” when playing music to have different sound effect (high bass boost, normal, low pitch boost). Default setting is high bass boost. Choose your favorite sound effect base on your habit and music style.

Chinese/English Shift :

Long press the “ ＋ ” and volume “ ━ ” simultaneously for 2 seconds.

Headphone/speaker:

Push the switch to “ ”, SX-809 will work as headphone, and switch it to “ ”, it will work as speaker.

Play/Pause

During music playing, Short press “MFB” to pause music, and click again MFB back to play .

During music playing, Short press “ ＋ / ━ ” to change songs.

（13）

During the call or listening to music, user can long press “ ＋ ” or “ ━ ” button to adjust the volume.

Mobile phone anti-lost indicator

When the headphone connected with smart phone, if the distance between device and headphone out of 10 m, headset will prompts “Beyond the range of connections” . If coming back to the working distance within 3 min or after, the headset will reconnect Automatically with smart phone. If not coming back to the working distance in 10 min, headphone will be power off, please switch the button to the OFF then switch to ON ,headset will reconnect with smart phone.

Power prompt :

Each time turning on SX-809, it will report headset battery power remaining, such as “battery full” , “battery level high” , “battery level medium” , “battery level low” , “recharge headset” .

Restore Factory Settings

Turn off the headset and in charge state, long press “MFB” button for three seconds, the blue light flashes three times, it will back to Factory setting.

▌Technical Index

- Correpond With : Bluetooth V4.1
- Support : HSP . HFP . A2DP . AVRCP
- Transmitting Power : Class 2
- Working Distance : ≤10m
- Frequency Range : 2.402 GHz-2.480GHz
- Charge Time : ≤3.5 Hours
- Standby Time :≥300 Hours
- Talk Time of Earphone : ≥18 Hours
- Music Time of Earphone : ≤16 Hours
- Talk Time of Speaker : ≥11 Hours
- Music Time of Speaker : =5 Hours

（14）

Tips:

Correct way of setting back the wire

In order to prolong the working life of the headset, please setback the wire slowly, and follow the steps shown below.



Wrong way of setting back the wire

Press the Earbud Retract Button directly. In this way, the earbuds will hit the headset aggressively.



（15）

A1

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance

could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may

cause undesired operation.