1. External Photograph of EUT

Brand Name: ZEBRA; Model Name: PS30JB

Brand Name: ZEBRA; Model Name: PS30JB

Brand Name: ZEBRA; Model Name: PS30JB

Brand Name: ZEBRA; Model Name: PS30JB

Brand Name: ZEBRA; Model Name: PS30JB

Brand Name: ZEBRA; Model Name: PS30JB

2. Photograph of Accessory

Brand Name: ZEBRA; Model Name: PS30JB

List of Accessory:

Specification of Accessory				
Battery 1	**Brand Name**	Zebra	**Part Number**	BT-000355-0020
Battery 2	**Brand Name**	Zebra	**Part Number**	BT-000355-5020

Remark: For accessories equipped with this EUT, please refer to the following photos.

Brand Name: ZEBRA; Model Name: PS30JB



Brand Name: ZEBRA; Model Name: PS30JB



Brand Name: ZEBRA; Model Name: PS30JB

Brand Name: ZEBRA; Model Name: PS30JB