OTL

TECHNOLOGIES

KIDS WIRELESS HEADPHONES

USER GUIDE

EN CONTENTS

- Headphones
- Micro USB recharging cable (16.5cm)
- 3.5mm AUX cable (1.2m)
- User guide
- Warranty leaflet



SPECIFICATION

- Speaker: 40mm
- Bluetooth version: V5.0
- Support profile: A2DP, AVRCP, HFP, HID, AVCTP, AVDTP, SPP
- Sensitivity: 95 dB ±3 dB
- Frequency Response: 20Hz – 20KHz
- Operation distance: 10 m
- Music play time: 30 hours
- Charge time: 2-3 hours
- Battery: 3.7V, 500 mAh, Lithium Battery

CONTROL OVERVIEW



PAIR WITH BLUETOOTH DEVICES

Please ensure that the Bluetooth function has been turned on in the settings of your Bluetooth enabled device. You must pair the headphones with a Bluetooth enabled device before it can be used wirelessly.

You only need to pair your headphones to each Bluetooth enabled device once. They will automatically reconnect to each device when turned on in their vicinity. If two or more devices are available, the last device paired will be the one that reconnects.

FIRST TIME USE / PAIR TO NEW DEVICE

The Bluetooth device should automatically start searching for the new play device (some may require you to select "search for / add new device").

1. On your Bluetooth device, go to "settings" –> "Bluetooth" –> turn on Bluetooth
2. Turn the headphones on by pressing the power / multifunction button for 3 seconds until LED indicator light begins to flash. The LED indicator light will flash to detect Bluetooth enabled devices near you and will enter pairing mode.
3. "OTL BTKIDS1" will appear on the Bluetooth device list, select "OTL BTKIDS1" to establish pairing.
4. When pairing is successful, the LED on your headphones will glow solid BLUE.

When you want to play audio from another Bluetooth device, disconnect the headphones from the original device and follow steps 1-4 to re-pair the headphones with a new Bluetooth enabled device.

USING AUX CABLE

Connect the wireless headphones to a smartphone, audio device or laptop (see overview diagram for location) with the 3.5mm AUX cable (included).



CHARGING THE HEADPHONES

Please charge your headphones before first time use.

- When the battery is low, please charge via the included USB cable. The charging time is approximately 2-3 hours and provides up to 30 hours of continuous operation.
- The LED indicator light will be red during charging and will turn off once it is fully charged. When the battery is low, the LED indicator light will flash red.



Note: Headphones will not work if charging cable is still connected.

TROUBLESHOOT

- When an error occurs with the headphones, please turn off the headphones and restart it to troubleshoot.
- When the headphones power is low, the Bluetooth range may be affected. Please charge the headphones to avoid disruption during use.
- Please see our website www.otltechnologies.com for general trouble shooting method instructions.

WARNING

- This product is not a toy.
- Do not disassemble, repair or modify the headphones.
- Avoid storage at extreme temperatures, this can shorten the battery life and may affect the headphones.
- Do not place product in or near fire to avoid danger, as it uses a lithium battery.
- Keep the headphones dry and do not store the headphones in damp areas to avoid damage to the headphones.
- Avoid dropping the headphones as it may cause damage to the product.
- Do not immerse in water.
- Do not insert jack plug into electric sockets.

SAFETY

- To prolong the headphones life span and to avoid hearing damage, please do not listen to music under high volume for long periods of time.
- Unsuitable for use by children under the age of three due to small parts which may cause choking.
- Supervise children when using the equipment.
- Do not use these headphones whilst operating machinery, driving, riding a motorbike or bicycle or in situations where an inability to hear surrounding noise may present a danger to yourself or others.
- Set volume to low before turning on sound.

INFORMATION ON DISPOSAL FOR USERS OF WASTE ELECTRICAL & ELECTRONIC EQUIPMENT (PRIVATE HOUSEHOLD)

This symbol on the products and/or accompanying documents means that used electrical and electronic products should not be mixed with general house hold waste. For proper treatment, recovery and recycling, please take these products to designated collection points, where they will be accepted on a free of charge basis. Alternatively, in some countries you may be able to return your products to your local retailer upon the purchase of an equivalent new product. Disposing of this product correctly will help to save valuable resources and prevent any potential negative effects on human health and the environment which could otherwise arise from inappropriate waste handling. Please contact your local authority for further details of your nearest designated collection point. Penalties may be applicable for incorrect disposal of this waste, in accordance with national legislation.

Bluetooth™

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Oceania Trading Limited (OTL) is under license. Other trademarks and trade names are those of their respective owners.

www.otltechnologies.com
Made in PRC
Oceania Trading Ltd, London SW12 9PS / info@otltechnologies.com

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.