NAUTIZ X81

QUICK START GUIDE

handheld

① WHAT´S IN THE BOX

The pictures shown below may differ from the actual products. To purchase additional or optional products, contact our customer center.

Nautiz X81 Main Body



Standard Battery



Hand Strap

USB Cable



Adaptor

② YOUR NAUTIZ X81





③ INSERT/REMOVE BATTERY

To insert the battery

1. Remove the battery cover by sliding the door's lock left and lift up the cover.

2. Insert the battery.

3. Close the battery cover.



To remove the battery

1. Power off the PDA.

2. Open the battery cover by slidig the door's lock left and lift up the cover.

3. Remove the battery.



④ INSERTING/EXRTRACTING SIM/MICRO SD CARD

This is how you insert and remove the SIM/micro SD.



⑤ POWERING ON/OFF

Press the [Power] button at the bottom of the keypad to turn the Nautiz X81 unit on/off.

⑥ BATTERY CHARGING

Use supplied power adapter and USB cable to charge the Nautiz X81. Charge the Nautiz X81 before using the device for the first time.



⑦ BOTTOM PANEL LAYOUT



Please go to www.handheldgroup.com/knowledgebase to download more information.

1. FCC

▪ 1.1 Part 15.21

15.21

You are cautioned that changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment

▪1.2 Part 15. 105

15.105(b)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

▪1.3 Part 15. 19

This device complies with Part 15 of the FCC Rules,

operation is subject to the following two conditions:

1) this device may not cause harmful interference and

2) this device must accept any interference received, including

interference that may cause undesired operation.

▪ 1.4 RF EXPOSURE

FCC RF Radiation Exposure Statement:

1. This Transmitter must not be co-located or operating in

conjunction with any other antenna or transmitter.

2.For portable operation,this device has been tested and meets

FCC RF exposure guidelines.When used with an accesory

that contains metal may not ensure compliance with FCC RF

exposure guidelines.

2. ISED

▪ 2.1

Canadian Notice

This device contains licence-exempt transmitter(s)/receiver(s)

that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.

2. This device must accept any interference, including

interference that may cause undesired operation of the device.

Avis Canadien

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux

appareils radio exempts de licence. L'exploitation est autorisée

aux deux conditions suivantes :

1. L’appareil ne doit pas produire de brouillage;
2. L’appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d’en compromettre le fonctionnement

exposure guidelines.

- 2.2 RF EXPOSURE

Caution: Exposure to Radio Frequency Radiation.
1.To comply with the Canadian RF exposure compliance requirements, this device and its antenna must not be colocated or operating in conjunction with any other antenna or transmitter.
2.To comply with RSS 102 RF exposure compliance requirements, a separation distance of at least 5mm must be maintained between the antenna of this device and all persons.
Attention: exposition au rayonnement radiofréquence.
1. Pour se conformer aux exigences de conformité RF canadienne l’exposition, cet appareil et son antenne ne doivent pas être co-localisés ou fonctionnant en conjonction avec une autre antenne ou transmetteur.
2. Pour se conformer aux exigences de conformité CNR 102 RF exposition, une distance de séparation d’au moins 5mm doit être maintenue entre l’antenne de cet appareil et toutes les personnes.

- 2.3 WI-FI 5GH

Operation in the band 5150-5250 MHz is only for indoor use to reduce the potential for harmful interference to cochannel mobile satellite systems.
La bande 5 150-5 250 MHz est réservés uniquement pour une utilisation à l’intérieur afin de réduire les risques de brouillage préjudiciable aux systèmes de satellites mobiles utilisant les mêmes canaux.

For the frequency 5600-5650 MHz, no operation is permitted
Pour la fréquence 5600-5650 MHz, aucune opération est autorisée.

3. NOTE

1. If the product has any abnormal state, please contact the manufacturer to deal with it, and the product must be serviced by a skilled person.
2. This equipment is not suitable for use in locations where children are likely to be present.
3. Replace the micro SDXC card, nano SIM card or battery pack, the DC powered equipment must be removed
4. This device does not have phone-calling functionality.

handheld

Version 1.0

www.handheldgroup.com