60mm

70mm

TW-601A

True Wireless Earbuds



USER MANUAL

FCC ID:ZBCTW601A

USER GUIDE

Congratulations on your purchase.
To get the most out of your new device, we recommend that you carefully read this user manual.

PRODUCT DESCRIPTION:
" True wireless earbuds. These earbuds must be used with compatible devices that support wireless connection technology"

SAFETY INFORMATION:
Please carefully read the following safety instructions before using the product for the first time.

WARNINGS:

- Do not use earbuds while driving or cycling.
- Stop using the earbuds temporarily in potentially dangerous situations. The risk of an accident increases considerably when you cannot hear the sounds around you.
- Keep this product out of reach of children to prevent them from swallowing small parts.

SAFETY WARNINGS

HEARING DAMAGE PREVENTION:

- Check the volume of the device to be connected before using your earbuds.
- Sudden exposure to loud sounds could cause hearing damage.
- We recommend you listen to music at a comfortable, moderate volume for a reasonable length of time.
- Prolonged use of the earbuds on full power may cause hearing loss.
- Remove the earbuds or adjust your volume to ensure you can hear the surrounding sound, including alarms and warning signals.

OPERATION:
Do not attempt to disassemble or modify this device. This could cause damage or malfunction and void the warranty.

SAFETY GUIDELINES :

- Do not store your device in a very hot or cold areas. Operating conditions: 0°C to 40°C.
- Do not expose to rain or snow. Keep away from heat sources, direct sunlight, combustible gas, water or other liquids.
- Do not store your earbuds in a dusty or dirty place.
- Do not subject the earbuds to crushing, bending, puncturing, or shredding. Avoid dropping or placing heavy objects on the earbuds.
- Do not replace the built-in battery with an incompatible model.
- Do not subject or pull on the charging cable with extreme forces, otherwise it may cause damage or mulfunction.

CLEANING AND CARE :

- Unplug your earbuds from any power source before cleaning them.
- Only clean the earbuds with dry soft cloth.
- Stop using the earbuds immediately if they cause severe discomfort, irritation, rash, or any other uncomfortable reaction.

WASTE SORTING GUIDELINES:
At the end of their life cycle, the case and cable must be separated from household waste and must be entrusted to an authorized collection point.

WHAT' S IN THE BOX



HOW TO WEAR



*Try different sizes of ear tips best fit and seal.

*Place the earbud in the ear canal and slightly rotate to adjust for best fit.

HOW TO CHARGE



To charge the case, connect the USB-C of charging cable to the case and then connect USB-A to your computer (Figure 1) or any other USB-A charger (Figure 2).

When the case is charging, white LED is flashing.
Place the earbuds in the charging case to start charging(Figure 3).

PAIRING NEW DEVICE

Step 1: Take out from charging case

Step 2: Flashing Green and White LED

Step 3: Find and click "Infinitive SoundPro" from your mobile device

Step 4: The LED goes off after successful pairing

Successful pairing with the phone, the Green and White lights are off



Remark: Just pick up from case, and BT connected automatically for BT paired device(Re connected).

POWER OFF



BATTERY INDICATION



HOW TO CONTROL



SPECIFICATIONS

ITEM	SPEC
Bluetooth version	5.3
Codec	Supports SBC/AAC codec
Range	Up to 10 metres
Frequency range	2.4 GHz to 2.48 GHz
Earbuds Battery Capacity	30mAh
Charging case Battery Capacity	300mAh
Input	5V ⎓ 300mA (Charging case)
Charging time	About 1.5 Hours (Earbuds) About 2 Hours (Charging case)
Earbuds charging time on charging case	Up to 3 times
Listening time	Up to 4 hours
Talk time	Up to 2.5 hours
Speaker diameter	8 mm
Charging port	USB-C

FCC Statement

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on,the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into outlet on a circuit different form that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning:

Changes or modifications to this unit not espressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device,pursuant to Part 15 of the FCC Rules.These limits are designed to provide reasonable protection against harmful interference in a residential installation.This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.