Antenna and Device Information



K580 Antenna Distance

[ANT1] Tx,PRx
LTE : B5,B8,B20
GSM : 850,900
WCDMA : B5,B8

[ANT2] Tx,PRx
LTE : B1,B3,B4,B7,B38
GSM : 1800,1900
WCDMA : B1,B2

[ANT3] DRx
LTE : B1,B4,B5,B7,B8,B20
3G : B1,B5,B8

[ANT4] Tx,Rx
BT/WIFI 2.4G

[ANT5] Rx only
GPS
LTE : B3, B38

[ANT6] NFC
NFC (13.56MHz)

1. #6 ANT is placed on battery cover.
2. #3, #4, #5 are placed on Rear case.
3. #1,# 2 ANT are placed on SPK&ANT module.

Unit : mm

SAR Test Setup Photographs

■ Test Setup Photo (Left All)



■ Test Setup Photo(Left Touch/Tilt)





■ Test Setup Photo (Right All)

■ Test Setup Photo (Right Touch/Tilt)



■ Test Setup Photo (Body All)



■ Test Setup Photo (Rear)



[Distance of 1.0 cm from the EUT]

■ Test Setup Photo (Front)



[Distance of **1.0 cm** from the EUT]

■ Test Setup Photo (Left)



[Distance of 1.0 cm from the EUT]

■ Test Setup Photo (Right)



[Distance of 1.0 cm from the EUT]

■ Test Setup Photo(Top)

[Distance of 1.0 cm from the EUT]

■ Test Setup Photo(Bottom)

[Distance of 1.0 cm from the EUT]