Band1(10H) QPSK BW=10MHz Channel=18550 RB Size=50 Position=#0 Range30 MHz-1000 MHz



Band1(10H) QPSK BW=10MHz Channel=18550 RB Size=50 Position=#0 Range1000 MHz-1955.00 MHz

複製禁止



Band1(10H) QPSK BW=10MHz Channel=18550 RB Size=50 Position=#0 Range1995.00 MHz-3000 MHz



Band1(10H) QPSK BW=10MHz Channel=18550 RB Size=50 Position=#0 Range3000 MHz-12.75 GHz

複製禁止



Band1(10H) QPSK BW=10MHz Channel=18550 RB Size=50 Position=#0 Range470 MHz-710 MHz



Band1(10H) QPSK BW=10MHz Channel=18550 RB Size=50 Position=#0 Range770 MHz-773 MHz

複製禁止



Band1(10H) QPSK BW=10MHz Channel=18550 RB Size=50 Position=#0 Range860 MHz-890 MHz

Band1(10H) QPSK BW=10MHz Channel=18550 RB Size=50 Position=#0 Range773 MHz-803 MHz

複製禁止



Band1(10H) QPSK BW=10MHz Channel=18550 RB Size=50 Position=#0 Range945 MHz-960 MHz



Band1(10H) QPSK BW=10MHz Channel=18550 RB Size=50 Position=#0 Range1475.9 MHz-1496.6 MHz

複製禁止

Band1(10H) QPSK BW=10MHz Channel=18550 RB Size=50 Position=#0 Range1805 MHz-1845 MHz



Band1(10H) QPSK BW=10MHz Channel=18550 RB Size=50 Position=#0 Range1496.6 MHz-1510.9 MHz

複製禁止



Band1(10H) QPSK BW=10MHz Channel=18550 RB Size=50 Position=#0 Range1845 MHz-1880 MHz

Band1(10H) QPSK BW=10MHz Channel=18550 RB Size=50 Position=#0 Range1906.6 MHz-1910 MHz

複製禁止



Band1(10H) QPSK BW=10MHz Channel=18550 RB Size=50 Position=#0 Range1910 MHz-1915.7 MHz



Band1(10H) QPSK BW=10MHz Channel=18550 RB Size=50 Position=#0 Range2010 MHz-2025 MHz

複製禁止



Band1(10H) QPSK BW=10MHz Channel=18550 RB Size=50 Position=#0 Range2110 MHz-2144.4 MHz



Band1(10H) QPSK BW=10MHz Channel=18550 RB Size=50 Position=#0 Range2144.4 MHz-2170 MHz



Band1(10H) QPSK BW=10MHz Channel=18550 RB Size=50 Position=#0 Range2330 MHz-2370 MHz



Band1(10H) QPSK BW=10MHz Channel=18550 RB Size=50 Position=#0 Range3400 MHz-3419.3 MHz



Band1(10H) QPSK BW=10MHz Channel=18550 RB Size=50 Position=#0 Range3419.3 MHz-3500.7 MHz



Band1(10H) QPSK BW=10MHz Channel=18550 RB Size=50 Position=#0 Range3500.7 MHz-3574.7 MHz

Band1(10H) QPSK BW=10MHz Channel=18550 RB Size=50 Position=#0 Range3574.7 MHz-3590.3 MHz



Band1(10H) QPSK BW=10MHz Channel=18550 RB Size=50 Position=#0 Range3600 MHz-4100 MHz

複製禁止

Band1(10H) QPSK BW=10MHz Channel=18550 RB Size=50 Position=#0 Range3590.3 MHz-3600 MHz



Band1(10H) QPSK BW=10MHz Channel=18550 RB Size=50 Position=#0 Range4500 MHz-4900 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#0 Range9 kHz-150 kHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#0 Range30 MHz-1000 MHz

複製禁止



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#0 Range150 kHz-30 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#0 Range1000 MHz-1955.00 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#0 Range3000 MHz-12.75 GHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#0 Range1995.00 MHz-3000 MHz

複製禁止



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#0 Range470 MHz-710 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#0 Range770 MHz-773 MHz

複製禁止



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#0 Range773 MHz-803 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#0 Range860 MHz-890 MHz

複製禁止



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#0 Range945 MHz-960 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#0 Range1475.9 MHz-1496.6 MHz

複製禁止



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#0 Range1496.6 MHz-1510.9 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#0 Range1805 MHz-1845 MHz

複製禁止



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#0 Range1906.6 MHz-1910 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#0 Range1845 MHz-1880 MHz

複製禁止

Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#0 Range1910 MHz-1915.7 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#0 Range2010 MHz-2025 MHz

複製禁止



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#0 Range2110 MHz-2144.4 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#0 Range2144.4 MHz-2170 MHz

複製禁止



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#0 Range2330 MHz-2370 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#0 Range3419.3 MHz-3500.7 MHz

複製禁止



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#0 Range3400 MHz-3419.3 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#0 Range3500.7 MHz-3574.7 MHz

複製禁止

Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#0 Range3590.3 MHz-3600 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#0 Range3574.7 MHz-3590.3 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#0 Range3600 MHz-4100 MHz

Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#0 Range4500 MHz-4900 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#Max Range150 kHz-30 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#Max Range9 kHz-150 kHz

Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#Max Range30 MHz-1000 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#Max Range1000 MHz-1955.00 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#Max Range1995.00 MHz-3000 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#Max Range3000 MHz-12.75 GHz

複製禁止



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#Max Range470 MHz-710 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#Max Range773 MHz-803 MHz

複製禁止



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#Max Range770 MHz-773 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#Max Range860 MHz-890 MHz

複製禁止



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#Max Range945 MHz-960 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#Max Range1475.9 MHz-1496.6 MHz

複製禁止



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#Max Range1496.6 MHz-1510.9 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#Max Range1805 MHz-1845 MHz

複製禁止



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#Max Range1906.6 MHz-1910 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#Max Range1845 MHz-1880 MHz

複製禁止

Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#Max Range1910 MHz-1915.7 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#Max Range2010 MHz-2025 MHz

複製禁止



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#Max Range2110 MHz-2144.4 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#Max Range2144.4 MHz-2170 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#Max Range3400 MHz-3419.3 MHz

Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#Max Range2330 MHz-2370 MHz

複製禁止



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#Max Range3419.3 MHz-3500.7 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#Max Range3500.7 MHz-3574.7 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#Max Range3574.7 MHz-3590.3 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#Max Range3590.3 MHz-3600 MHz

複製禁止



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#Max Range3600 MHz-4100 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=1 Position=#Max Range4500 MHz-4900 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=50 Position=#0 Range9 kHz-150 kHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=50 Position=#0 Range150 kHz-30 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=50 Position=#0 Range1000 MHz-1955.00 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=50 Position=#0 Range30 MHz-1000 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=50 Position=#0 Range1995.00 MHz-3000 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=50 Position=#0 Range3000 MHz-12.75 GHz

複製禁止



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=50 Position=#0 Range470 MHz-710 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=50 Position=#0 Range770 MHz-773 MHz

複製禁止



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=50 Position=#0 Range773 MHz-803 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=50 Position=#0 Range860 MHz-890 MHz

複製禁止



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=50 Position=#0 Range945 MHz-960 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=50 Position=#0 Range1475.9 MHz-1496.6 MHz

複製禁止



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=50 Position=#0 Range1496.6 MHz-1510.9 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=50 Position=#0 Range1805 MHz-1845 MHz

複製禁止



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=50 Position=#0 Range1845 MHz-1880 MHz

Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=50 Position=#0 Range1906.6 MHz-1910 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=50 Position=#0 Range1910 MHz-1915.7 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=50 Position=#0 Range2010 MHz-2025 MHz

複製禁止



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=50 Position=#0 Range2110 MHz-2144.4 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=50 Position=#0 Range2144.4 MHz-2170 MHz

複製禁止



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=50 Position=#0 Range3400 MHz-3419.3 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=50 Position=#0 Range2330 MHz-2370 MHz

複製禁止



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=50 Position=#0 Range3419.3 MHz-3500.7 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=50 Position=#0 Range3500.7 MHz-3574.7 MHz

複製禁止



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=50 Position=#0 Range3574.7 MHz-3590.3 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=50 Position=#0 Range3590.3 MHz-3600 MHz

複製禁止



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=50 Position=#0 Range3600 MHz-4100 MHz



Band1(10H) QAM16 BW=10MHz Channel=18550 RB Size=50 Position=#0 Range4500 MHz-4900 MHz

複製禁止



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#0 Range9 kHz-150 kHz



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#0 Range150 kHz-30 MHz



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#0 Range30 MHz-1000 MHz



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#0 Range1000 MHz-1905.00 MHz



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#0 Range1945.00 MHz-3000 MHz



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#0 Range3000 MHz-12.75 GHz



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#0 Range470 MHz-710 MHz



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#0 Range770 MHz-773 MHz

複製禁止



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#0 Range860 MHz-890 MHz

Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#0 Range773 MHz-803 MHz

複製禁止



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#0 Range945 MHz-960 MHz



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#0 Range1496.6 MHz-1510.9 MHz

複製禁止



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#0 Range1475.9 MHz-1496.6 MHz



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#0 Range1805 MHz-1845 MHz

複製禁止



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#0 Range1906.6 MHz-1910 MHz



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#0 Range1845 MHz-1880 MHz



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#0 Range1910 MHz-1915.7 MHz

Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#0 Range2110 MHz-2144.4 MHz

複製禁止



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#0 Range2010 MHz-2025 MHz



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#0 Range2144.4 MHz-2170 MHz



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#0 Range2330 MHz-2370 MHz



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#0 Range3419.3 MHz-3500.7 MHz

複製禁止



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#0 Range3400 MHz-3419.3 MHz



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#0 Range3500.7 MHz-3574.7 MHz

複製禁止



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#0 Range3574.7 MHz-3590.3 MHz



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#0 Range3590.3 MHz-3600 MHz



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#0 Range3600 MHz-4100 MHz



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#0 Range4500 MHz-4900 MHz



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#Max Range150 kHz-30 MHz



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#Max Range9 kHz-150 kHz

Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#Max Range30 MHz-1000 MHz



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#Max Range1000 MHz-1905.00 MHz



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#Max Range1945.00 MHz-3000 MHz



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#Max Range3000 MHz-12.75 GHz



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#Max Range470 MHz-710 MHz



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#Max Range770 MHz-773 MHz

複製禁止



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#Max Range773 MHz-803 MHz



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#Max Range860 MHz-890 MHz

複製禁止



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#Max Range1475.9 MHz-1496.6 MHz



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#Max Range945 MHz-960 MHz



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#Max Range1496.6 MHz-1510.9 MHz

Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#Max Range1805 MHz-1845 MHz

複製禁止



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#Max Range1845 MHz-1880 MHz

Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#Max Range1906.6 MHz-1910 MHz



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#Max Range2010 MHz-2025 MHz



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#Max Range1910 MHz-1915.7 MHz

複製禁止

Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#Max Range2110 MHz-2144.4 MHz



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#Max Range2144.4 MHz-2170 MHz



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#Max Range2330 MHz-2370 MHz



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#Max Range3400 MHz-3419.3 MHz

複製禁止



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#Max Range3419.3 MHz-3500.7 MHz



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#Max Range3500.7 MHz-3574.7 MHz

複製禁止



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#Max Range3574.7 MHz-3590.3 MHz



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#Max Range3590.3 MHz-3600 MHz

複製禁止



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#Max Range4500 MHz-4900 MHz



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=1 Position=#Max Range3600 MHz-4100 MHz



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=50 Position=#0 Range9 kHz-150 kHz



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=50 Position=#0 Range150 kHz-30 MHz

Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=50 Position=#0 Range30 MHz-1000 MHz



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=50 Position=#0 Range1000 MHz-1905.00 MHz

複製禁止



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=50 Position=#0 Range1945.00 MHz-3000 MHz



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=50 Position=#0 Range470 MHz-710 MHz

複製禁止

Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=50 Position=#0 Range3000 MHz-12.75 GHz



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=50 Position=#0 Range770 MHz-773 MHz

複製禁止



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=50 Position=#0 Range773 MHz-803 MHz



Band1(10L) QPSK BW=10MHz Channel=18050 RB Size=50 Position=#0 Range860 MHz-890 MHz

複製禁止