



A U.S. Department of Labor report says that RSI (Repetitive Strain Injury) of the part above the waist (e.g. wrist, elbow, shoulder) accounts for 2/3 of the occupational diseases having been reported, among which CTS (Carpal Tunnel Syndrome) is the most often. Therefore U.S. Department of Labor declares that CTS is the main occupational disease in 2000's, and it has made employees disable in a large scale.

Around 36% of the people suffering from CTS will take a surgery. And among them nearly 50% will relapse within 6 weeks to 6 months if they do the same work as before. Only 23.12% of them will fully recover.



Common mouse makes
your arm twisted



EZmouse5 keeps your arm in a neutral position
and away from CTS

Packing list

Wireless

Minicute EZmouse5	1
USB mini receiver	1
User manual	1
Large palm rest	1
Small palm rest	1


Specifications

Rated current	30mA/3V
Buttons	5
Resolution	800/1200/1600/2000DPI
Type	Optical
Weight	120~144g
Mouse dimensions	75X72X106mm
Large palm rest	155X99X5mm
Small palm rest	113X103X5mm

1. Take out the mouse and the receiver underneath, and then plug it into an empty USB2.0 or better port.
2. Get 2 AA batteries and put them into the mouse with correct polarity.
3. Switch the on / off switch under the mouse to "on".
4. Now the mouse is ready to work.

Functions

1. The button on the left is by default a backward button. There is one forward on the right. Both buttons can be programmed with other functions.
2. A DPI switch and an on / off button are under the mouse. **Wireless** EZmouse resolutions are 800 / 1200 / 1600/ 2000DPI, and 500 / 1000 / 1500 / 2000DPI for **wired**. Press DPI button and the indicator of **wireless** EZmouse will flash, once for 800DPI, twice for 1200DPI, three times for 1600DPI, and four times for 2000DPI. For the **wired**, if the DPI button is pressed, colors will change to indicate which resolution will be selected – red for 500DPI, green for 1000DPI, blue for 1500DPI, light blue for 2000DPI.
3. The slot underneath is used to adjust weight by adding coins inside.



FCC WARNING

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.